


CAN-BUS
CAN-BUS
EMULATOR
id-v5
Adblue SCR
Emulator



CAN-BUS EMULATOR id-v5 Adblue SCR Emulator User Manual


[Home](#) » [CAN-BUS EMULATOR](#) » CAN-BUS EMULATOR id-v5 Adblue SCR Emulator User Manual 

Contents

- [1 CAN-BUS EMULATOR id-v5 Adblue SCR Emulator](#)
- [2 Product Information](#)
- [3 Description](#)
- [4 INSTALLATION STEPS](#)
- [5 Specification](#)
- [6 Frequently Asked Questions \(FAQ\)](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)

CAN-BUS

CAN-BUS EMULATOR id-v5 Adblue SCR Emulator




Product Information

Specifications

- Product: Ford 1846 Adblue Emulator
- Model: Euro 5
- Manufacturer: canbusemulator.com

Description

Ford Cargo 1846 - 460 PS - 9 Pin Diagnostic Socket



Join the brown wire to D coded pin

Join the White wire to C coded pin

Join the Red wire to B coded pin
Ignition: +24 or 12 volt

Join the Black wire to A coded pin
GND - Chasis

INSTALLATION STEPS


INSTALLATION OF ADBLUE EMULATOR FOR FORD 1846 EURO 5


Firstly, the fault detection socket will be as seen. The table below will help you better.

PIN NO CABLE TYPE

- A GND (Chassis) Black Cable
- B + POWER (+24 or + 12) Red Cable
- C White Cable
- D Brown Cable

As seen above, we remove the fuses from the 12th and 16th Sockets in the car fuse box. We leave the sockets empty.





Then, the connection between the emulator and the vehicle will be provided with the help of the table below.

Specification

Cable Type of Emulator

- Red (Power)
- Black (GND)
- White
- Brown

Cable Type of Vehicle

- Thick white-brown (Power)
- Black-Gray (Chasis)
- Brown-Green
- Brown-Blue

After the connection, we start the vehicle. Adblue level will be full when the vehicle starts.

NOTE: If the Adblue level flashes (if there is an error) when the connection is made and started, let's try again by connecting the White cable in the CAN line to the Brown-blue one and the Brown cable to the Brown-green one.



- www.canbusemulator.com
- +90 530 937 46 36
- erenakarsubasi

Frequently Asked Questions (FAQ)

Q: What should I do if the Adblue level flashes with an error after installation?

A: In case of an error, reconnect the White cable in the CAN line to the Brown-blue cable and the Brown cable to the Brown-green cable.

Documents / Resources



[CAN-BUS EMULATOR id-v5 Adblue SCR Emulator](#) [pdf] User Manual
1846, id-v5 Adblue SCR Emulator, id-v5, Adblue SCR Emulator, SCR Emulator, Emulator

References

- [Adblue \(SCR\) İptali İçin Emülatörler, DTC ve NOx Hataları Temizleme - Can Bus Emulator](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.