

Home » Carrier » Carrier EMS SC-62-0210-0001-99 SmartCell Wireless Remote Indicator Instruction Manual





Contents

- 1 Carrier EMS SC-62-0210-0001-99 SmartCell Wireless Remote **Indicator**
- 2 Technical specifications
- 3 Overview
- 4 Installation
- **5 Battery Installation and Replacement**
- **6 Operation**
- 7 FAQs
- 8 Documents / Resources
 - 8.1 References



Carrier EMS SC-62-0210-0001-99 SmartCell Wireless Remote Indicator



Technical specifications

General

• Wireless frequency 868 MHz

Electrical

- · Power supply type Batteries
- Batteries 3 x ER14505M 3.6 V lithium thionyl chloride batteries (Fanso or Titus)
- Power consumption 1.46 W max.
- Operating voltage 2.7 to 3.65 VDC
- Current consumption 0.1 to 400 mA

Physical

- Physical dimensions 110 x 39 mm (Ø x D)
- · Colour White
- · Mounting type Wall mount
- · Mounting base Wireless

Environmental

- · Vandal proof Yes
- Operating temperature -10 to +55 °C
- Storage temperature -10 to +30 °C (with batteries)
- Relative humidity 0 to 95% noncondensing

Environment Indoor

• IP rating IP21C

Regulatory

- · Compliancy CE
- · Certification CPR
- Standards EN54-13
- EN54-25

Overview

The SmartCell wireless remote indicator is quick and easy to install and offers individual addressing at the SmartCell control panel. Features include red fire indication LED, bidirectional 868 MHz communication and an anti-tamper locking mechanism. This device is third party certified and compatible with the full SmartCell product range.

Details

- · Fully wireless
- · Quick and easy to install

- Red fire indication LED
- · Unique design
- · Inbuilt locking mechanism

Installation

- 1. Choose a suitable location for mounting the wireless remote indicator.
- 2. Mount the device securely on the wall using the provided mounting base.
- 3. Ensure the indicator is within communication range of the SmartCell control panel.

Battery Installation and Replacement

- 1. Open the battery compartment on the back of the device.
- 2. Insert 3 x ER14505M 3.6 V lithium thionyl chloride batteries.
- 3. Close the battery compartment securely.
- 4. If replacing batteries, follow the same steps with new batteries.

Operation

The wireless remote indicator will display red fire indication LED when triggered by the SmartCell control panel. In case of an alert, take necessary actions as per your safety protocols.

As a company of innovation, Carrier Fire & Security reserves the right to change product specifications without notice. For the latest product specifications, visit <u>firesecurityproducts.com</u> online or contact your sales representative.

Last updated on 11 January 2024 - 12:40

FAQs

Q: Is the SmartCell wireless remote indicator compatible with other fire alarm systems?

A: The SmartCell wireless remote indicator is designed to work seamlessly with the full SmartCell product range and may not be compatible with other systems.

Q: How do I know when the batteries need to be replaced?

A: The device may emit a low battery warning or fail to function properly when the batteries are running low. It is recommended to replace the batteries promptly to ensure continuous operation.

Q: Can the wireless remote indicator be used outdoors?

A: No, the device is designed for indoor use only and should not be exposed to outdoor environmental conditions.

Documents / Resources



Carrier EMS SC-62-0210-0001-99 SmartCell Wireless Remote Indicator [pdf] Instruction Ma

EMS SC-62-0210-0001-99 SmartCell Wireless Remote Indicator, EMS SC-62-0210-0001-99, S martCell Wireless Remote Indicator, Wireless Remote Indicator, Remote Indicator

References

- © Fire Security Products
- TCPDF
- User Manual

Manuals+, Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.