

# **CARSON LF-10 LIGHTFLEX 1.5 Inches LED Task Lamp Instructions**

Home » Carson » CARSON LF-10 LIGHTFLEX 1.5 Inches LED Task Lamp Instructions



#### **Contents**

- 1 CARSON LF-10 LIGHTFLEX 1.5 Inches LED Task
- 2 Instructions for Use
- 3 To change batteries
- 4 Documents / Resources
- **5 Related Posts**



**CARSON LF-10 LIGHTFLEX 1.5 Inches LED Task Lamp** 




### Instructions for Use

- Attach task lamp to flat metal surface using built-in magnet located in magnifier base (Fig. 1).
- To use with table clamp, attach the clamp to the table and tighten securely (Fig 2). Attach task lamp to top portion of clamp using built-in magnet located in magnifier base (Fig. 3).
- Plugin the power adapter to the standard wall outlet and insert the plug into the power jack located on the left side of the magnifier base (Fig. 4).
- To use with battery power, remove the plug from the power jack. The unit will automatically switch to battery power.
- Position task lamp head as desired. Turn on the light using the switch located on the front of the task lamp base (Fig. 5).

## To change batteries

- Remove the battery door and then remove the battery case from the compartment (Fig. 6-7).
- Replace exhausted batteries with 4 fresh AA 1.5V batteries according to polarity indicators printed inside the
  case.
- Place loaded battery case into the battery compartment with metal contacts facing upwards and towards the inside of the battery compartment (Fig. 8).
- · Replace the battery door when finished.

Caution: Do not look at the LED light directly to avoid harming your eyes.



## **Documents / Resources**



CARSON LF-10 LIGHTFLEX 1.5 Inches LED Task Lamp [pdf] Instructions LF-10, LIGHTFLEX 1.5 Inches LED Task Lamp, LF-10 LIGHTFLEX 1.5 Inches LED Task Lamp,

LF-10, LIGHTFLEX 1.5 Inches LED Task Lamp, LF-10 LIGHTFLEX 1.5 Inches LED Task Lamp LED Task Lamp

Manuals+,