



CDP AVR5008 Enterprise Level Monitoring Solutions User Manual

[Home](#) » [CDP](#) » CDP AVR5008 Enterprise Level Monitoring Solutions User Manual 

CDP AVR5008 Enterprise Level Monitoring Solutions



Contents

- [1 Introduction](#)
- [2 Feature](#)
- [3 Specification](#)
- [4 Warranty Limitations](#)
- [5 Customers Support](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Introduction

Thank you for purchasing the R-AVR2408/3008/5008 series voltage regulator. To enjoy the benefits offered by this unit, please read this user manual and follow the instructions below. We recommend that you keep this manual for future reference.

Feature

1. Main power button.

Turn the equipment on and off.

2. High voltage LED indicator [Buck] illuminates when the equipment corrects a high voltage condition.
3. Power LED indicator. The LED illuminates when the AVR supplies power to the connections.



4. LED indicator under voltage. [Boost] Illuminates when the equipment corrects a low voltage condition.
5. Low voltage LED indicator [Super Boost]
6. Coaxial protection.

Protect your equipment against dangerous voltage spikes.



7. Breaker overload.
It allows the easy recovery of an overload.
8. AVR plus surge protection outlets.



9. Delay device.

- **30 seconds:** Recommended for normal AC power. [recommended for microwave]
- **1 minute:** Allows longer time for normalization and stabilization of electrical fluids. [recommended for electronic equipment]
- **3 minutes :** Recommended for mechanical products, refrigerators, air conditioners or for areas where energy quality is poor.

Connect the equipment that protects from voltage variations to any of the sockets of your regulator. The 9 sockets offer regulation and protection against voltage spikes.

Press the power switch, the regulator will click a few times. The center LED will light up. Remember that your regulator has a “PROTECTION DELAY” system and it will take the time established to deliver power to the connected equipment. The above is manifested when the center LED (2) is lit intermittently.

If the LED above lights [4]the regulator is reducing voltage, if the LED on the bottom of your regulator is lit, the voltage is increasing. [Read full explanation in the table of technical specifications]



WARNING

This is not a toy. Not intended to be used by children.
Danger of electrical shock.

Specification

MODEL	R-AVR5008
Capacity	5000VA/2500W
Input.	
Voltage	120VAC
Frequency range	50/60 Automatic
Voltage range	82Vac-144Vac
Output	
Voltage	92Vac-144Vac 120Vac +/-10% >144Vac 120Vac +/-15%
Frequency range	50/60 Hz
Type of output connector	9 outputs NEMA5-15R and NEMA 5-2DR regulated and surge protection
Delay device	30 seconds – 1 minute – 3 minutes
Coaxial	Integrated coaxial
Protections	
Overload/ Reload Breaker	Thermomagnetic Breaker 20 Amp.
Surge Protection	525 joules
Overcharge	Thermomagnetic breaker
LEOS[4]	
LED 1 [Up]	Reducing
LED 2 (Central)	Power ON
LED 3 [Down)	Boost Immerse
LED 4 [Down)	Last/ Super Boost Increase
Physical	
Dimensions	25Dx1 57x1 57 mm
Environment	
Temperature range	0°-40°C
Humidity range	<95% non condensed
Noise	<40dB

Specifications subject to change without notice”

Chicago Digital Power warranties this product against defective materials or workmanship for one year from the date of original purchase [With the possibility to be extended to 2 years). Proof of purchase is required.

1. To make this warranty valid Proof of purchase is required. Bring the product to the original purchase place or to the nearest CDP Service Center. Make sure to bring also this warranty Policy. For information about Service Centers in your country please call the following numbers. [If your country is not here please send a mail to

servicio@cdpups.com)

Bolivia: 800-100156

Colombia: 01800-5181617

Costa Rica: 8004357237

Salvador: 800-6773

Honduras: 800-25616099

Mexico: 001800-5148611

Panama: 01100800-2268611

Peru: 0800-54674

Dominic Republic: 1888-7514876

Venezuela: 0800-1627 485

2. Chicago Digital Power will repair or replace the product at its own criteria without a cost during the warranty period.
3. Repair or replacement time should never exceed 30 days from the date that the unit is received at the CDP Service Center.
4. In case this warranty policy is lost please a copy at the original purchase place.

Warranty Limitations

- **a)** This warranty does not include damages which arise from negligence, misuse or use not in accordance with the product instruction.
- **b)** When the product has been opened or serviced by a non authorized service facility, has been altered or changed.
- **c)** Warranty is voided if utility wiring is reversed or lacks of ground.
- **d)** Warranty not valid for normal wear and tear.

Customers Support




A full line of products designed for the modern family with advanced features and characteristics needed for todays modern devices.

www.cdpenergy.com



Documents / Resources



[CDP AVR5008 Enterprise Level Monitoring Solutions](#) [pdf] User Manual
AVR5008 Enterprise Level Monitoring Solutions, AVR5008, Enterprise Level Monitoring Solutions, Level Monitoring Solutions, Monitoring Solutions, Solutions

References

- [User Manual](#)

[Manuals](#) · [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.