

***cincoze***  
CO-100 Series  
TFT LCD Open  
Frame Display  
Module



# CINCOZE CO-100 Series TFT LCD Open Frame Display Module User Manual

[Home](#) » [cincoze](#) » CINCOZE CO-100 Series TFT LCD Open Frame Display Module User Manual 

## Contents

- 1 CINCOZE CO-100 Series TFT LCD Open Frame Display Module
- 2 Preface
- 3 Declaration of Conformity
- 4 FCC
- 5 Product Warranty Statement
- 6 Technical Support and Assistance
- 7 Safety Precautions
- 8 Product Introductions
- 9 System Setup
- 10 Documents / Resources
  - 10.1 References

***cincoze***

**CINCOZE CO-100 Series TFT LCD Open Frame Display Module**



## Preface

## Revision

Revision	Description	Date
1.00	First Released	2022/09/05
1.01	Correction Made	2022/10/28
1.02	Correction Made	2023/04/14
1.03	Correction Made	2024/01/30

## Copyright Notice

2022 by Cincoze Co., Ltd. All rights are reserved. No parts of this manual may be copied, modified, or reproduced in any form or by any means for commercial use without the prior written permission of Cincoze Co., Ltd. All information and specifications provided in this manual are for reference only and remain subject to change without prior notice.

## Acknowledgment

Cincoze is a registered trademark of Cincoze Co., Ltd. All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

## Disclaimer

This manual is intended to be used as a practical and informative guide only and is subject to change without notice. It does not represent a commitment on the part of Cincoze. This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## Declaration of Conformity

## **FCC**

This equipment has been tested and found to comply with the limits for a Class A digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## **CE**

The product(s) described in this manual comply with all application European Union (CE) directives if it has a CE marking. For computer systems to remain CE-compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

## **RU (For CO-W121C only)**

UL Recognized Components have been evaluated by UL for factory installation within equipment where the component's limitations of use are known and investigated by UL. UL Recognized Components have conditions of acceptability that describe how components can be used within end products.

## **Product Warranty Statement**

### **Warranty**

Cincoze products are warranted by Cincoze Co., Ltd. to be free from defects in materials and workmanship for 2 years (2 Years for the PC Module, and 1 Year for the Display Module) from the date of purchase by the original purchaser. During the warranty period, we shall, at our option, either repair or replace any product that proves to be defective under normal operation. Defects, malfunctions, or failures of the warranted product caused by damage resulting from natural disasters (such as lightning, flood, earthquake, etc.), environmental and atmospheric disturbances, other external forces such as power line disturbances, plugging the board in under power, or incorrect cabling, and damage caused by misuse, abuse, and unauthorized alteration or repair, and the product in question is either software or an expendable item (such as a fuse, battery, etc.), are not warranted.

### **RMA**

Before sending your product in, you will need to fill in the Cincoze RMA Request Form and obtain an RMA number from us. Our staff is available at any time to provide you with the most friendly and immediate service.

### **RMA Instruction**

- Customers must fill in the Cincoze Return Merchandise Authorization (RMA) Request Form and obtain an RMA number before returning a defective product to Cincoze for service.
- Customers must collect all the information about the problems encountered note anything abnormal and describe the problems on the "Cincoze Service Form" for the RMA number application process.
- Charges may be incurred for certain repairs. Cincoze will charge for repairs to products whose warranty period has expired. Cincoze will also charge for repairs to products if the damage resulting from acts of God, environmental or atmospheric disturbances, or other external forces through misuse, abuse, or unauthorized alteration or repair. If charges will be incurred for a repair, Cincoze lists all charges and will wait for the customer's approval before performing the repair.
- Customers agree to ensure the product or assume the risk of loss or damage during transit, to prepay shipping charges, and to use the original shipping container or equivalent.
- Customers can be sent back the faulty products with or without accessories (manuals, cable, etc.) and any components from the system. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, Cincoze is not responsible for the devices/parts.

- Repaired items will be shipped along with a “Repair Report” detailing the findings and actions taken.

### **Limitation of Liability**

Cincoze’s liability arising out of the manufacture, sale, or supply of the product and its use, whether based on warranty, contract, negligence, product liability, or otherwise, shall not exceed the original selling price of the product. The remedies provided herein are the customer’s sole and exclusive remedies. In no event shall Cincoze be liable for direct, indirect, special, or consequential damages whether based on a contract or any other legal theory.

### **Technical Support and Assistance**

1. Visit the Cincoze website at [www.cincoze.com](http://www.cincoze.com) where you can find the latest information about the product.
2. Contact your distributor our technical support team or sales representative for technical support if you need additional assistance. Please have the following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

### **Conventions Used in this Manual**

#### **WARNING**

- This indication alerts operators to an operation that, if not strictly observed, may result in severe injury.

#### **CAUTION**

This indication alerts operators to an operation that, if not strictly observed, may result in safety hazards to personnel or damage to equipment.

#### **NOTE**

This indication provides additional information to complete a task easily.

### **Safety Precautions**

Before installing and using this device, please note the following precautions.

1. Read these safety instructions carefully.
2. Keep this User’s Manual for future reference.
3. Disconnect this equipment from any AC outlet before cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
8. Use a power cord that has been approved for use with the product and that matches the voltage and current marked on the product’s electrical range label. The voltage and current rating of the cord must be greater than

the voltage and current rating marked on the product.

9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.

If one of the following situations arises, get the equipment checked by service personnel:

- The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment does not work well, or you cannot get it to work according to the user's manual.
  - The equipment has been dropped and damaged.
  - The equipment has obvious signs of breakage.
14. **CAUTION:** Risk of Explosion if Battery is replaced by an Incorrect Type. Dispose of Used Batteries According to the Instructions.  
**ATTENTION:** Risque d'explosion si la batterie est remplacée par un type incorrect. Mettre au rebut les batteries usagées selon les instructions.
  15. Equipment intended only for use in a RESTRICTED ACCESS AREA.
  16. Ensure to connect the power cord of the power adapter to a socket outlet with earthing connection.
  17. Dispose of the used battery promptly. Keep away from children. Do not disassemble and do not dispose of in fire.

### Package Contents

Before installation, please ensure all the items listed in the following table are included in the package.

#### CO-119C-R10

Item	Description	Q'ty
1	CO-119C Display Module	1

**Note:** Notify your sales representative if any of the above items are missing or damaged.

#### CO-W121C-R10

Item	Description	Q'ty
1	CO-W121C Display Module	1

**Note:** Notify your sales representative if any of the above items are missing or damaged.

### Ordering Information

#### Display Module with Projected Capacitive Touch


Model No.	Product Description
CO-119C-R10	19" TFT-LCD SXGA 5:4 Open Frame Display Module with Projected Capacitive Touch
CO-W121C-R10	21.5" TFT-LCD Full HD 16:9 Open Frame Display Module with Projected Capacitive Touch

## Product Introductions

### Overview

Cincoze open frame display modules (CO-100) use our patented CDS (Convertible Display System) technology to connect with a computer module (P2000 or P1000 series) to form an industrial panel PC or connect with a monitor module (M1100 series) to form an industrial touch monitor. Designed for equipment manufacturers, easy installation is the main advantage of the CO-100. The integrated structure, exclusive adjustable mounting bracket, and support for various mounting methods enable a perfect fit in cabinets of different materials and thicknesses. The robust design also meets the application needs of harsh industrial environments.

### Highlights



### Flexible Design and Easy Installation

The CO-100 series includes the exclusive adjustable mounting bracket with thickness adjustment setting, as well as panel and boss-type locking. Flat and standard mount options make integration in industrial machinery easy and convenient.

- Patent No. I802427, D224544, D224545



### Integrated Structure

The CO-100 series is flexible and reliable. As standard, the open frame display module can be deployed in equipment machines, but remove the mounting bracket and it becomes a standalone display module for use with a VESA mount or in a 19" rack.



### **Strong, Reliable and Durable**

The CO-100 series integrated structure design enables wide temperature support (0–70°C) in addition to front IP65 dustproof and waterproof protection, meeting HMI application requirements.




### **Highly Adaptable CDS Design**

Through the patented CDS technology, the CO-100 can be combined with a computer module to become an industrial panel PC, or with a monitor module to become an industrial touch monitor. Easy maintenance and upgrade flexibility are its main advantages.

- **Patent No.** M482908

## Display Module (CO Series)



### Key Features

- TFT-LCD with Projected Capacitive Touch
- Cincoze Patent CDS Technology Support
- Designed with an Adjustable Mounting Bracket
- Support Flat / Standard / VESA / Rack Mount
- Front Panel IP65 Compliant
- Wide Operating Temperature

### Hardware Specification


**CO-119C-R10**



<b>Model Name</b>	<b>CO-119C</b>
Display	
LCD Size	• 19" (5:4)
Resolution	• 1280 x 1024
Brightness	• 350 cd/m2
Contract Ratio	• 1000:1
LCD Color	• 16.7M
Pixel Pitch	• 0.294(H) x 0.294(V)
Viewing Angle	• 170 (H) / 160 (V)
Backlight MTBF	• 50,000 hrs (LED Backlight)
<b>Touchscreen</b>	
Touchscreen Type	• Projected Capacitive Touch
<b>Physical</b>	
Dimension (WxDxH)	• 472.8 x 397.5 x 63 mm
Weight	• 6.91KG
Construction	• One-piece and Slim Bezel Design
Mounting Type	• Flat / Standard / VESA / Rack Mount
Mounting Bracket	• Pre-installed Mounting Bracket with Adjustable Design ( Support 11 different stages of adjustment)
<b>Protection</b>	
Ingress Protection	• Front Panel IP65 Compliant * According to IEC60529
<b>Environment</b>	
Operating Temperature	• 0°C to 50°C (with Industrial Grade peripherals; Ambient with airflow)
Storage Temperature	• -20°C to 60°C
Humidity	• 80% RH @ 50°C (non-condensing)


- Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.

## External Layout



## Dimension

Unit: mm




CO-W121C-R10

<b>Model Name</b>	<b>CO-W121C</b>
<b>Display</b>	
LCD Size	• 21.5" (16:9)
Resolution	• 1920 x 1080
Brightness	• 300 cd/m2
Contract Ratio	• 5000:1
LCD Color	• 16.7M
Pixel Pitch	• 0.24825(H) x 0.24825(V) mm
Viewing Angle	• 178 (H) / 178 (V)
Backlight MTBF	• 50,000 hrs
<b>Touchscreen</b>	
Touchscreen Type	• Projected Capacitive Touch
<b>Physical</b>	
Dimension (WxDxH)	• 550 x 343.7 x 63.3
Weight	• 7.16KG
Construction	• One-piece and Slim Bezel Design
Mounting Type	• Flat / Standard / VESA / Rack Mount
Mounting Bracket	• Pre-installed Mounting Bracket with Adjustable Design ( Support 11 different stages of adjustment)
<b>Protection</b>	
Ingress Protection	• Front Panel IP65 Compliant * According to IEC60529
<b>Environment</b>	
Operating Temperature	• 0°C to 60°C (with Industrial Grade peripherals; Ambient with air flow)
Storage Temperature	• -20°C to 60°C
Humidity	• 80% RH @ 50°C (non-condensing)
Safety	• UL, cUL, CB, IEC, EN 62368-1


- Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.

## External Layout

Front




Rear



## Dimension

Unit: mm



## System Setup

### Connecting to PC or Monitor Module

#### WARNING

In order to prevent electric shock or system damage, must turn off the power and disconnect the unit from the power source before removing the chassis cover.

- **Step 1.** Locate the male connector on the display module and the female connector on the PC or monitor module. (Please assemble the wall mount brackets and remove the CDS cover plate on the PC or monitor module first according to its user manual.)




**PC module**




**Monitor module**

- Step 2. Connect the modules.



- Step 3. Fasten the 6 screws to fix the PC module or monitor module on the display module.



### Standard Mount

The CO-100 series currently features two types of Mounting Bracket designs. For example, the Mounting Bracket designs of CO-W121C and CO-119C as illustrated below.



CO-W121C



CO-119C

CO-119C is essentially identical to CO-W121C in terms of installation, with the only difference being the design of the Mounting Bracket. The following steps will demonstrate the installation using CO-W121C as an example. Before doing the following steps, please make sure the screw positions are fastened at the default positions as indicated in the following picture. The default positions are the correct positions for Standard Mount, so it does not need to change the screw positions additionally for Standard Mount.






Step 1. Put the CO-100 module onto the cabinet's backside.



There are two methods for fastening the CO-100 module onto the cabinet to complete the standard mount. One is to fix the CO-100 module from the front side of the cabinet, which is illustrated in chapter 2.2.1. The other one is to fix the CO-100 module from the rear side of the cabinet, which is illustrated in chapter 2.2.2.


#### **Fixing from front side**

Step 2. Fasten the screws from the cabinet's front side. Please prepare 12 pcs of M4 screws for fixing the module through the circle holes (with screw thread).




### Fixing from rear side

Step 2. If the cabinet panel is with stud bolts as the following figure, user can prepare 16 pcs of nuts for fixing the module through the oblong holes (oblong hole size: 9mmx4mm, without screw thread).



If the cabinet panel is with bosses as the following figures, user can prepare 16 pcs of M4 screws for fixing the module through the oblong holes (oblong hole size: 9mmx 4mm, without screw thread).





### Flat Mount

The CO-100 series currently features two types of Mounting Bracket designs. For example, the Mounting Bracket designs of CO-W121C and CO-119C as illustrated below.



CO-W121C



CO-119C

CO-119C is essentially identical to CO-W121C in terms of installation, with the only difference being the design of the Mounting Bracket. The following steps will demonstrate the installation using CO-W121C as an example.

- **Step 1.** Locate the left and right-side mounting brackets.




- Step 2. Remove the two screws on the left and right-side mounting brackets.



- Step 3. Loosen the three screws on the left and right-side mounting brackets.



- Step 4. Measure the rack thickness. The thickness is measured 3mm in this example.



- Step 5. According to the thickness = 3mm for the example, push down the left and right-side mounting brackets to the place at screw hole = 3mm.



- Step 6. Fasten the two screws on the left and right-side mounting brackets.



- Step 7. Fasten the three screws on the left and right-side mounting brackets.



- Step 8. Locate the top and bottom-side mounting brackets.



- Step 9. Remove the two screws on the top and bottom-side mounting brackets.




- Step 10. Loosen the three screws on the both side's mounting brackets.



- Step 11. According to the thickness = 3mm for the example, push down the top and bottom-side mounting brackets to the place at screw hole = 3mm.





- Step 12. Fasten the two screws on the top and bottom-side mounting brackets.



- Step 13. Fasten the three screws on the top and bottom-side mounting brackets.




- Step 14. Put the CO-100 module onto the cabinet's backside.



There are two methods for fastening the CO-100 module onto the cabinet to complete the flat-mount. One is to fix the CO-100 module from the front side of the cabinet, which is illustrated in Chapter 2.3.1. The other one is to fix the CO-100 module from the rear side of the cabinet, which is illustrated in Chapter 2.3.2.


### Fixing from front side

Step 15. Fasten the screws from the cabinet's front side. Please prepare 12 pcs of M4 screws for fixing the module through the circle holes (with screw thread).




### Fixing from rear side

Step 15. If the cabinet panel is with stud bolts as the following figure, user can prepare 16 pcs of nuts for fixing the module through the oblong holes (oblong hole size: 9mmx4mm, without screw thread).




If the cabinet panel is with bosses as the following figures, user can prepare 16 pcs of M4 screws for fixing the module through the oblong holes (oblong hole size: 9mmx 4mm, without screw thread).




2023 Cincoze Co., Ltd. All rights reserved. The Cincoze logo is a registered trademark of Cincoze Co., Ltd. All other logos appearing in this catalog are the intellectual property of the respective company, product, or organization associated with the logo. All product specifications and information are subject to change without notice.

- [www.cincoze.com](http://www.cincoze.com)

## Documents / Resources

	<p><a href="#">CINCOZE CO-100 Series TFTP LCD Open Frame Display Module</a> [pdf] User Manual CO-119C-R10, CO-W121C-R10, CO-100 Series TFTP LCD Open Frame Display Module, CO-100 Series, TFTP LCD Open Frame Display Module, Open Frame Display Module, Display Module</p>
---	---

## References

-  [Cincoze – Expertise in Embedded Computing](#)
-  [Cincoze – Expertise in Embedded Computing](#)
- [User Manual](#)

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.