

CinusLinus
B0D6GRPWM
1 Laser Level
360 Self
Leveling



CinusLinus B0D6GRPWM1 Laser Level 360 Self Leveling Instructions

[Home](#) » [CinusLinus](#) » CinusLinus B0D6GRPWM1 Laser Level 360 Self Leveling Instructions 

Contents

- [1 CinusLinus B0D6GRPWM1 Laser Level 360 Self Leveling](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Product Overview](#)
- [5 Four-Beam Green 360-degree Laser Level](#)
- [6 Product Specifications](#)
- [7 What's in the box](#)
- [8 All Professional Features](#)
- [9 Versatile Operating Modes](#)
- [10 Initial Operation](#)
- [11 Please Pay Attention to the Safety Notes](#)
- [12 Daily Maintenance & Precautions](#)
- [13 Troubleshooting](#)
- [14 One-Year NO-Cost Warranty](#)
- [15 Documents / Resources](#)
 - [15.1 References](#)
- [16 Related Posts](#)

CinusLinus

CinusLinus B0D6GRPWM1 Laser Level 360 Self Leveling



Product Information

Specifications:

- **Brand:** CinusLinus
- **Email:** support@cinuslinus.com
- **Function:** Measuring tool for determining and checking horizontal and vertical lines
- **Orientation Planes:** Up to four – two vertical dual-beam lasers and two dual-beam horizontal lasers, all 360 degrees
- **Technology:** Smart laser technology for enhanced accuracy

Product Usage Instructions

Horizontal and Vertical Line Measurement:

The CinusLinus is designed to accurately determine and check both horizontal and vertical lines. Ensure the device is properly calibrated before use.

Orientation Planes:

This device features up to four orientation planes, including two vertical dual-beam lasers and two dual-beam horizontal lasers, all covering 360 degrees. This allows for comprehensive coverage and efficient completion of tasks.

Smart Laser Technology:

The CinusLinus laser level utilizes smart laser technology to simplify meticulous tasks. Familiarize yourself with the high-tech features to make your work more straightforward and precise.

Frequently Asked Questions (FAQ)



- **Q: How do I calibrate the CinusLinus laser level?**

A: To calibrate the device, follow the instructions provided in the user manual. Typically, calibration involves setting the device on a stable surface and adjusting the laser beams using the built-in controls until they align perfectly.

- **Q: Can the CinusLinus be used outdoors?**

A: The CinusLinus can be used outdoors, but ensure that it is not exposed to extreme weather conditions such as heavy rain or direct sunlight for prolonged periods, as this may affect its accuracy.

Product Overview



Control panel display




Switch indication

Four-Beam Green 360-degree Laser Level


- **8 line level**

360°Surround Beam Orientation 4 horizontal lines and 4 vertical lines.




- **12 line level**

360°Surround Beam Orientation 4 horizontal lines and 8 vertical lines.



- **16 line level**

360°Surround Beam Orientation 8 horizontal lines and 8 vertical lines.



Product Specifications










- Laser Class: Class II, <1mW power output
- Laser Wavelength: 505-532nm
- Laser Type / Color: Green light
- Beam Orientation: Vertical, horizontal, 360-degree
- Horizontal / Vertical Accuracy: \pm (1/25" at 30ft)
- Working Distance (Line): Range Up to 30m / 100ft
- Pulse Mode Range: 200ft requires receiver)
- Remote distance: 10m / 33ft
- Self Leveling / Range: +3°
- Mounting threads for tripods: 1/4"-20 and 5/8"-11
- Power Supply: Rechargeable Li-ion battery
- Battery Capacity: 2400mAh (Two Included 4800mAh Total)
- Battery Runtime: Supply 4-8h power(Upon the lines opened)
- Recharge Time: 3hours recharge

- IP Rating: IP54 dust-proof & waterproof
- Operation Temperature Range: -10°C ~ +40°C

What's in the box

1 4 x 360 Laser Level	2 Robust Portable Case	3 2 Rechargeable Batteries	4 Lifting Base Stand
5 Rotary Base Mini Tripod	6 Target Plate with Scale	7 Magnetic Bracket	8 User Instruction Manual
9 Equipped Remote Control	10 Laser Adapter	11 Tripod Thread Adapter	12 Wall Panel Stand

All Professional Features



-  Class-2 Laser is Bright and Long-ranging
-  16 LINES 4 x 360° Beam Orientation Options
-  Auto-Leveling + Ingenious Manual Tilt Function
-  ALL-in-One Versatile Flexible Mounting Options
-  Multiple Add-ons Enables Smooth Workflow
-  Provide 2 Flexible Battery Sources to Extend Run Time
-  Rugged Exterior Build Overmolded Housing
-  Integrated 360° Mounting Bracket for Tripods
-  Laser Class: Class II, <1mW power output

Versatile Operating Modes

1. Auto Self-leveling Mode



- To switch on the measuring tool, slide Lock Switch to “ON ” position.
- Immediately after switching on, the measuring tool could easily switch line and sends out 2 horizontal beam and 2 vertical beams with automatic leveling range of +3°.
- To turn off the measuring tool, slide lock switch to “OFF ” position.

2. Manual Mode / Tilt Line Mode

- To switch on the measuring tool, slide Lock Switch to ” ON” position.
- Long Press the “ ” key (Equivalent to ” Out ” Key in Remote Control) to open the Manual / Tilt Mode.
- When the line laser is in Manual/Tilt Mode, long press the “ ” key (Equivalent to ” Out * Key in Remote Control) enables to switch to the Self Leveling Mode.
- To turn off the measuring tool, slide Lock Switch to “OFF ” position.
- In manual mode, the measuring tool won't be self-leveling. It could be held by hand or placed on an inclined surface to project a rigid laser beam in any orientation.

3. Pulse Mode / Outdoor Mode

- To switch on the measuring tool, slide Lock Switch to ” ON” position.

- Short Press the “” key Equivalent to “Out” Key in Remote Control) to open the Outdoor Pulse Mode.
- When the line laser is in Outdoor Pulse Mode, short press the “” key (Equivalent to ” Out” Key in Remote Control) enables to switch to the Normal Working Mode.
- To turn off the measuring tool, slide Lock Switch to “OFF ” position.
- When you open pulse mode, you can use a laser receiver to carry out leveling at long distances or when the laser beams are not visible. The Laser Receiver did not come with our package. So you have to source it separately if you need to use the Outdoor Pulse Mode. It is up to you.

Intended Use

1. The measuring tool is intended for determining and checking horizontal and vertical lines.
2. The CinusLinus models with up to four orientation planes: two vertical dual-beam lasers and two dual-beam horizontal, and all of these planes are 360 degrees. This made the job easier and quicker to complete.
3. To add to it, the CinusLinus laser level uses smart laser technology, which promises to make your meticulous tasks more straightforward with its high-tech features.

Initial Operation

1. Do not subject the measuring tool to extreme temperatures or variations in temperature. In case of large variations in temperature, allow the measuring tool to adjust to ambient temperature before putting it into operation.
2. Avoid heavy impact to or falling down of the measuring tool.
3. Switch the measuring tool off during transport.

Please Pay Attention to the Safety Notes

1. Working safely with the measuring tool is possible when the operating and safety information are read completely and the instructions contained therein are strictly followed.
2. While the product is in operation, be careful not to expose your eyes to the emitting laser beam. Exposure to the beam of a Class 2 laser is considered safe for a maximum of 0.25 seconds. Eyelid reflexes will normally provide adequate protection.
3. Do not stare directly into the beam or view directly with optical instruments or set up the laser at eye level.
4. Do not allow children to use the laser measuring tool without supervision. They could unintentionally blind other people or themselves
5. Do not operate the measuring tool in an explosive environment, such as in the presence of flammable liquids, gases, or dust.
6. The product shall be placed in a ventilated, dry, heat-insulated and reproof warehouse, and it is strictly forbidden to contact with corrosive articles.
7. The loading, unloading and use of the products are suitable for handling care and shall not be thrown or dropped.
8. Do not make any modifications to the laser equipment.

Daily Maintenance & Precautions

1. Routine maintenance

- Please store the machine in dry, ventilated, constant temperature and dust-free place.
- Please wipe the shell glass frequently to ensure light transmission.
- When not in use for a long time, please release the locking switch regularly for half an hour. to ensure that the bearing swings flexibly.
- Please pay attention to lock the locking switch after use.
- Do not leave the battery in the machine to avoid the leakage of battery liquid.
- Do not look directly at the laser line. Use with protective glasses.
- Do not wipe the instrument with organic solvent.

2. Matters needing attention

- Nonprofessionals, please do not disassemble the machine.
- Please avoid violent vibration, collision and falling of the machine.

Troubleshooting

- After the receiving switch is turned on, the bubble backlight will flash, Which is a normal signal indicating that the receiver is in the receiving stat.
- The laser line flickers to prove that the machine is not in the safe and level range. Please adjust the level through the outrigger.
- If the laser line is blurred, please wipe the shell glass with clean cotton cloth.

The company's product appearance, and internal technical improvement without notice. The company reserves the right to modify the specification parameters and the right to final interpretation.

One-Year NO-Cost Warranty

We are confident in our products and offer excellent and professional service to our customers. This statement is in addition to your effective rights and does not injure your statutory rights.

The following conditions are not covered during the warranty period

- Man-made damage caused by improper use
- Any product that has been remodeled and repaired by itself
- The product is damaged after being sold due to improper transportation
- Replacement of easily worn parts
- Damage caused by failure to use our original accessories as required
- Any natural wear and tear


Questions or Concerns?

We have warranty time for your purchased laser level, so please do not worry about it.

E-mail: support@cinuslinus.com

Contact with Customer Support Team and Remember attach your order ID.

Documents / Resources

	CinusLinus B0D6GRPWM1 Laser Level 360 Self Leveling [pdf] Instructions B0D6GRPWM1 Laser Level 360 Self Leveling, B0D6GRPWM1, Laser Level 360 Self Leveling, Level 360 Self Leveling, Self Leveling, Leveling
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.