

Clikit RUBY Monkey Magnets Instruction Manual

Home » Clikit » Clikit RUBY Monkey Magnets Instruction Manual



Contents

- 1 Clikit RUBY Monkey Magnets
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 IMPORTANT SAFETY**

INSTRUCTIONS

- **5 PACKAGE INCLUDES**
- **6 PRODUCT MATERIALS**
- 7 PARTS
- **8 INSTALLATION**
- **9 LIMITATION OF LIABILITY**
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



Clikit RUBY Monkey Magnets



Product Information

Specifications:

- Manufacturer: Telebrands Corp. d/b/a Bulbhead
- · Origin: Made in China
- Materials: Iron with Nickel Plating (Metal Plates and Screws), Neodymium Magnet, Two-Sided Adhesive Tape
- Patents: US and Worldwide Patents Pending

Product Usage Instructions

Important Safety Instructions:

Read and follow all warnings and instructions before using this product to prevent injury or property damage. Save these instructions.

Parts Included:

- · Strike Plate
- · Magnetic Base

Installation:

Option 1: Screw Installation (Recommended for wood only)

- 1. Mark the installation location of both the magnetic base plate and the strike plate ensuring alignment when closed.
- 2. Drill pilot holes at marked locations for the magnetic base and strike plates.
- 3. Screw in the magnetic base and strike the plate with a screwdriver, ensuring the logo faces out.
- 4. Confirm magnets hold together by bringing them close. Adjust if needed.

Option 2: Adhesive Installation

- 1. Clean surfaces with rubbing alcohol and let dry.
- 2. Mark placement locations for the base plate and strike plate by bringing magnets together.
- 3. Apply tape adhesive to the back of the plates, pressing down firmly to remove air bubbles. Wait 30 minutes.
- 4. Peel off the other side of the tape adhesive and press firmly for at least 30 seconds. Allow adhesive to cure for 24 hours before testing closure strength.
- 5. To remove, apply heat with a hairdryer for about a minute. Peel off slowly. Use caution if using a razor blade or dental floss to detach.

Warning:

Removing adhesive tape may damage the surface, especially drywall.

FAQ

- Q: Can I use this product on surfaces other than wood?
 - A: It is recommended for wood surfaces, but adhesive installation can be used on other surfaces with caution regarding potential damage.
- Q: How do I adjust the magnetic closure strength?
 - A: Bring the magnets closer or further apart to adjust the closure strength as needed.

IMPORTANT SAFETY INSTRUCTIONS

READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE USING THIS PRODUCT. Injury or damage to property can result from improper use. SAVE THESE INSTRUCTIONS. PRODUCT MAY VARY FROM IMAGES SHOWN

WARNING


- Choking Hazard Small Parts. Keep away from children. This product is not a toy.
- THIS PRODUCT CONTAINS A SMALL MAGNET: Swallowed magnets can stick together across intestines causing serious infection and death. Seek immediate medical attention if the magnet is swallowed or inhaled.
- Do not use in damp locations.
- Do not exceed the weight limit of 2 kg (4.4 lbs).

PACKAGE INCLUDES

- (8) 2-Piece RUBY® Monkey MagnetsTM, 32 Mounting Screws,
- 16 pcs Mounting Peel & Stick Tape

PRODUCT MATERIALS

- Metal Plates and Screws: Iron with Nickel Plating
- Magnet: Neodymium Magnet
- Mounting Tape: Two-Sided Adhesive Tape




Each RUBY® Monkey MagnetsTM Set consists of (1) Strike Plate and (1) Magnetic Base

INSTALLATION

RUBY® MONKEY MAGNETSTM CAN EASILY BE INSTALLED 2 WAYS.


OPTION 1: SCREW INSTALLATION (Recommended for wood only)




1. Mark the installation location of both the magnetic base plate and the strike plate to ensure they align when the door, drawer, or cabinet is closed.

Note: The logo should face out.


2. Drill pilot holes about the length of each screw at the pencil marks for magnetic base and strike plates.







- 3. Screw the magnetic base and strike the plate with a screwdriver, ensuring that the logo faces out.
- 4. Bring magnets together to confirm that they hold together. Adjust as needed

OPTION 2: ADHESIVE INSTALLATION




- 1. Clean the surfaces of the base plate, strike plate, and areas where you intend to stick them with rubbing alcohol. Allow to dry.
- 2. Bring magnets together and mark with pencil where both the base plate and strike plate should be placed.





- 3. Peel off one side of the tape adhesive, and stick to the back of the base and strike plates. Press the tape down hard, removing any air bubbles. Wait a minimum of 30 minutes.
- 4. Peel off other side of the tape adhesive and press firmly for at least 30 seconds to make sure the adhesive sticks well to the surface.



- 5. Let the adhesive tape cure for at least 24 hours before testing the closure strength
- 6. To remove, apply heat with a hair dryer to tape for about 1 minute. Then peel slowly off. If still too stuck, using caution, use a single-edge razor blade or dental floss under the edge of the tape to detach.

Warning: Removing adhesive tape may damage the surface. May damage drywall.

LIMITATION OF LIABILITY

Liability is limited to the purchase price of this product. Supertek Canada Inc. shall not be liable for any incidental or consequential damages or any implied warranty on this product.

Distributed by Supertek Canada Inc. Mont-Royal, QC H4T 1 X2 02022 DaVinci CS], LLC <u>www.clikit.ca</u> Customer Service: <u>client@supertek.ca</u> 1-800-304-8354

The product may vary from the images shown. US and Worldwide Patents Pending.

Documents / Resources



References

- WELCOME TO CLIKIT.CA THE PLACE FOR INNOVATIVE PRODUCTS.
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.