

 **CONCEPTRONIC**

**TOBIN01B**  
**10 Inch**  
**Bluetooth**  
**Touchpad**  
**Keyboard**



## CONCEPTRONIC TOBIN01B 10 Inch Bluetooth Touchpad Keyboard Installation Guide

[Home](#) » [CONCEPTRONIC](#) » [CONCEPTRONIC TOBIN01B 10 Inch Bluetooth Touchpad Keyboard Installation Guide](#) 

### Contents

- [1 CONCEPTRONIC TOBIN01B 10 Inch Bluetooth Touchpad Keyboard](#)
- [2 Product Usage Instructions](#)
- [3 PACKAGE CONTENTS](#)
- [4 SPECIFICATION](#)
- [5 Installation and usage](#)
- [6 Troubleshooting](#)
- [7 Safety and warning instructions](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)



**CONCEPTRONIC TOBIN01B 10 Inch Bluetooth Touchpad Keyboard**



## Product Usage Instructions

### Power On:

Turn on the keyboard by switching the toggle on the side of the keyboard to the on position.

### First-Time Setup:

#### Pairing BT1:

1. Turn on the keyboard and press FN + C to start Bluetooth pairing.
2. On your device, navigate to the Bluetooth settings and select Bluetooth Keyboard from the list of available devices to pair.
3. Select the device's operating system by pressing: FN + Q for Android, FN + W for Windows, or FN + E for iOS.

#### Pairing BT2 or BT3:

1. Press FN + BT2 or FN + BT3, then press FN + C to start Bluetooth pairing.
2. On your device, navigate to the Bluetooth settings and select Bluetooth Keyboard from the list of available devices to pair.
3. Once paired, select the device's operating system.




## Frequently Asked Questions (FAQ):

### Q: What should I do if the keyboard is not responding?

A: If the keyboard is not responding, please follow these troubleshooting steps:

- 1. Verify that the keyboard is powered on.
- 2. Ensure the keyboard is within the operable distance of the device.
- 3. Check that the battery has sufficient power.
- 4. Make sure the device’s Bluetooth is turned on.
- 5. Confirm that the Bluetooth keyboard is connected to the device.


**PACKAGE CONTENTS**



**SPECIFICATION**

Model number	TOBIN01BUS – QWERTY
Bluetooth version	5.4
Working distance	10m
Frequency range	2402 – 2480MHz
Maximum output power (EIRP)	-15dBm ~ +3dBm
Battery capacity	150mAh
Recharge time	4 hours
Standby time	150 hours
Average operation time	40 hours
Compatible operating systems	Windows 10 or above iOS 12 or iPadOS 13 or above macOS 10.15 (Catalina) or above Android 8.0 (Oreo) or above

**Installation and usage**




**Bluetooth 1**

①



+




Bluetooth Keyboard

②




+



Device's operating system

**Bluetooth 2 / Bluetooth 3**


①




+




②



+



③




+



Select device



+



## Power On

Turn on the keyboard by switching the toggle on the side of the keyboard to the “on” position.

## First-Time Setup

### Pairing BT1:

1. Turn on the keyboard and press FN + C to start Bluetooth pairing. The Bluetooth indicator light will flash, and the default connection will be set to BT1.
2. On your device, navigate to the Bluetooth settings and select “Bluetooth Keyboard” from the list of available devices to pair.
3. Select the device’s operating system by pressing: FN + Q for Android, FN + W for Windows, or FN + E for iOS.

### Pairing BT2 or BT3:

1. Press FN + BT2 or FN + BT3, then press FN + C to start Bluetooth pairing. The Bluetooth indicator light will start flashing.
2. On your device, navigate to the Bluetooth settings and select “Bluetooth Keyboard” from the list of available devices to pair.
3. Once paired, select the device’s operating system.

## Switching Between Paired Devices

Once all three devices are paired, press FN + BT1, FN + BT2, or FN + BT3 to switch between devices.

## Changing the Paired Device

To pair a new device, press FN + BT1, FN + BT2, or FN + BT3, then press FN + C to start pairing. Once paired, select the device’s operating system.

## Power-Saving Sleep Mode

The keyboard will automatically enter sleep mode after 15 minutes of inactivity. To wake the keyboard, simply press any key and wait for about 3 seconds. It will automatically reconnect to the Bluetooth device and resume normal operation.















## Battery and Charging

- **Low Power:** LED flashes when the battery is low.
- **Charging:** Plug the included USB cable into the keyboard and a USB charger (not included). The LED will light up red while charging.
- **Fully Charged:** The LED will turn blue when charging is complete. Charging Tips: Charge only when the power light flashes. Ensure each charge lasts at least 2 hours for optimal battery performance.
- **When Not in Use:** Switch off the keyboard to extend battery life.

## Multimedia keys

### Note:

Multimedia keys vary depending on the operating system. Some keys may not respond on certain operating systems.

	Back to home page		Pause/Play
	Search		Next track
	Select all		Volume -
	Copy		Volume +
	Paste		Brightness -
	Screen capture		Brightness +
	Previous track		Lock screen

## Troubleshooting

1. Verify that the keyboard is powered on.
2. Ensure the keyboard is within the operable distance of the device.
3. Check that the battery has sufficient power.
4. Make sure the device's Bluetooth is turned on.
5. Confirm that the Bluetooth keyboard is connected to the device's Bluetooth.
6. Ensure the Bluetooth keyboard has paired successfully with the device.

## Safety and warning instructions

- Keep the device away from water, humidity, fire, or hot environments.
- Keep your device and all its parts and accessories out of the reach of small children.
- Do not leave the packaging material lying around carelessly. This may become dangerous playing material for children.
- Avoid dropping, throwing, or crushing the device.
- Do not open, change, or damage the device.
- Do not use a damaged USB charger or cable to charge the device. Using an improper charging method may result in fire or explosion.
- Do not recharge batteries near a fire or in extremely hot conditions.
- Observe signs and notices that prohibit or restrict the use of electronic devices.
- Turn off your device in any location where instructed to do so.
- Unplug all cables and turn your device off before cleaning.

### Disposal of waste electrical equipment and batteries:

Do not dispose of waste electrical equipment and batteries with household waste. Please hand them to your local recycling point. Batteries should be fully discharged when disposed of. Incorrect storage/disposal can harm the

environment and/or cause injury.

### CE marking:

Conceptronic declares that this product complies with the directives listed in the section 'Declaration of Conformity'.

### Radiation Exposure Statement:


This device has been evaluated and found to meet general RF exposure requirements. It can be used in portable exposure conditions without restriction. The device operates within the frequency range of 2402 – 2480 MHz, with a maximum output power (EIRP) of 3dBm.

### Need Help?


- [support@conceptronic.net](mailto:support@conceptronic.net)
- [www.conceptronic.net](http://www.conceptronic.net).

Digital Data Communications GmbH – Im Defdahl 10 F, 44141 Dortmund, Germany CONCEPTRONIC® is a registered trademark of Digital Data Communications GmbH © Copyright Digital Data Communications GmbH. All Rights Reserved.

### Documents / Resources

  <b>TOBIN01B</b> Quick Installation Guide  <small>Schnellinstallationsanleitung Guide d'installation Rapide Guia de Instalação Rápida Guida di Installazione Rapida Oydeni Tsepelezi (Ünvanlı) Rápida Instalação Instrução Guia de Instalação Rápida</small>	<a href="#">CONCEPTRONIC TOBIN01B 10 Inch Bluetooth Touchpad Keyboard</a> [pdf] Installation Guide TOBIN01B, TOBIN01B 10 Inch Bluetooth Touchpad Keyboard, 10 Inch Bluetooth Touchpad Keyboard, Bluetooth Touchpad Keyboard, Touchpad Keyboard, Keyboard
---	---

### References

-  [Home - Conceptronic](#)
- [User Manual](#)

[Manuals±](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.