

Coulomb LSPFN13WLAN WiFi BLE 4.0 Module Instruction **Manual**

Home » Coulomb » Coulomb LSPFN13WLAN WiFi BLE 4.0 Module Instruction Manual



Coulomb

LSPFN13WLAN Instruction Manual

Installation and Use of Transceiver Module

IUmin

Copyright Coulomb, Inc. (DBA Lumin) 2021 Any unauthorized copy, alteration, distribution, transmission, performance, display, or other use of this material is strictly prohibited.

www.luminsmart.com

Contents

- 1 Module Installation
- 2 Module Use
- 3 Documents /

Resources

4 Related Posts

Module Installation

- 1. Ensure pads/pins are clean on host PCB and module.
- 2. Place module onto host PCB.
- 3-5. Solder numbered regions in order.
- 6. Connect antenna of the correct type and gain as specified in "Module Use."




Figure 1 – Diagram of Module Installation

Module Use

2.1 Host Integration Requirements

This radio transmitter, FCC ID: 2AY52-LSPFN13WLAN, IC: 27016-LSPFN13WLAN, has been approved by the FCC and Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited from use with this device.

• External Omni-directional dipole antenna: 2.8 dBi peak gain

This module complies with FCC RF exposure limits for an uncontrolled environment exclusively in fixed host products providing ≥ 20 cm separation between the antenna and nearby persons. All host products must be visibly labeled "Contains FCC ID: 2AY52-LSPFN13WLAN" and "Contains IC: 27016-LSPFN13WLAN" to inform end-users.

The onboard Bluetooth transceiver must be disabled in all host products, and no means of enabling Bluetooth functionality shall be provided. Any changes or modifications not expressly approved by Coulomb, Inc. (DBA Lumin) could void the user's authority to operate the equipment.

2.2 Regulatory Statement


This device complies with Part 15 of the FCC rules and with Innovation, Science, and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources



Manuals+,