

CROSLEY CR3111A Cadence Bluetooth Speaker Instruction Manual

Home » Crosley » CROSLEY CR3111A Cadence Bluetooth Speaker Instruction Manual



Cadence Bluetooth Speaker Instruction Manual



Questions, problems, missing parts?

Before returning to the store, call Customer Service 8 a.m. – 6 p.m., EST, Monday – Friday 1-888-CROSLEY

www.crosleyradio.com

Contents

- 1 Safety Instructions
- 2 Items in this package
- 3 Specifications
- **4 Product Description**
- **5 Bluetooth Operation**
- **6 FCC Statements**
- 7 Documents /

Resources

- 7.1 References
- **8 Related Posts**

Safety Instructions

Read and understand this entire manual before using this product. Keep these instructions for future reference.

- 1. Do not use this product near water.
- 2. This product should be operated only by the type of power source indicated on the marking label or in this instruction manual.
- 3. Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades with one blade wider than the other. This plug will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet try reversing the plug. If the plug should still fail to fit, contact your electrician.
- 4. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.
- 5. Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 6. Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- 7. Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 8. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- 9. Do not use attachments not recommended by the product manufacturer as they may cause hazards.
- 10. A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.
- 11. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating. Do not block or cover these openings.
- 12. Unplug the product during a lightning storm or when unused for long periods of time.

Items in this package

Before throwing away any packaging materials, please check thoroughly and make sure you find the following items that come along with this package:

- Bluetooth Speaker
- Adapter

Please contact Crosley customer service if there is any accessory missing from the package. **Retain the original packaging materials for exchange or return purposes.**


Specifications

Power	DC 18V, 2A
Power Output	40 W
Speaker	5.25" woofer 6Ω & 1" tweeter 6Ω
Frequency Response	20Hz- 20KHz

Note:

- Design and specifications are subject to change without notice.
- To help save power consumption, some models will comply with ERP energy-saving standards. When there is no audio input for 20 minutes, their powers will automatically cut off. To turn the power back on and resume playing, you will need to turn off the power and turn it on again.

Product Description



1. ON/OFF Switch	3. Power Jack
2. Bluetooth Indicator	4. Pair Button

Bluetooth Operation

1. Turn on the unit and you will hear an activation sound from the unit.

Note: The Bluetooth indicator will be flashing blue.

- 2. Turn on the Bluetooth feature of your audio device, search for "CROSLEY CR3111A" and pair.
- 3. Once your device is successfully paired with the unit, you will hear a short confirmation sound from the unit, and the Bluetooth indicator will be blue.
- 4. Play and stream music from your device to the unit.
- 5. To disconnect, press and hold the Pair button on the unit.

Note: Bluetooth version - 5.0

FCC Statements

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - 1. This device may not cause harmful interference, and
 - 2. This device must accept any interference received, including interference that may cause undesired operation.
- 2. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body

RF warning statement:

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Documents / Resources

CROSLEY Constitute Spater Catenative Material Catenative Material Locative Material	CROSLEY CR3111A Cadence Bluetooth Speaker [pdf] Instruction Manual CR3111A, AUSCR3111A, CR3111A Cadence Bluetooth Speaker, Cadence Bluetooth Speaker
CROSLEY COILLA Calculate Historian Relater Individual Meteory Individu	CROSLEY CR3111A Cadence Bluetooth Speaker [pdf] Instruction Manual CR3111A, Cadence Bluetooth Speaker

References

• crosleyradio.com

Manuals+,