



CUBOT Simple and Trust Smartphone User Guide

[Home](#) » [CUBOT](#) » CUBOT Simple and Trust Smartphone User Guide 

Contents

- [1 CUBOT Simple and Trust Smartphone](#)
- [2 Safety Information](#)
- [3 Introduction](#)
- [4 Call Functions](#)
- [5 Contacts](#)
- [6 Messages](#)
- [7 Internet Browser](#)
- [8 Bluetooth & Wi-Fi](#)
- [9 Camera](#)
- [10 Gallery](#)
- [11 Settings](#)
- [12 Main components](#)
- [13 Customize home interface](#)
- [14 Map](#)
- [15 FCC Rules Compliance](#)
- [16 Documents / Resources](#)
 - [16.1 References](#)
- [17 Related Posts](#)

CUBOT

CUBOT Simple and Trust Smartphone



Safety Information

Please carefully read the terms bellow:

Use Safely

Do not use the phone in situations where it might cause danger.

Transportation Safety

Please observe all transportation laws and regulations. Please drive with both hands on the wheel.

DO NOT TEXT AND DRIVE

Hospitals

Please follow the limitations. Please turn off your mobile phone when near medical instruments.

Airports

Remember to follow all airport and flight safety regulations. Please do not use your phone during the flight.

Toxic Chemicals

Do not use your mobile phone around fuels or chemicals.

Hazard

Do not use in hazardous areas where explosions may occur.

Accessories and Batteries

Use only Blu-authorized batteries and accessories.

Backup

Remember to keep a written record of all important information.

Water

Your phone is not waterproof. Keep it away from water and liquids.

SOS Emergency Calls

Make sure your mobile phone is switched on and in a service area. In-home screen, tap the phone key and dial 911, and send.

Introduction

Power On and Off

- **On** – Please ensure the SIM card has been properly inserted into the phone. Long press the Power key to switch on the phone.
- **Off** – In standby mode, long press on the Power key until an options menu appears. Select Power Off in the menu and confirm.


Security


You may set a security lock feature as a security measure for the phone. For further information regarding password locks, password revision and other functions please enter the security option in system settings.

Call Functions

At the dial keyboard, enter the phone number and then click the dial key. If dialing an extension, you may click the dial pad icon in the bottom of the screen to open the interface and enter the number of the extension. You may also press and hold the 0 key to add a (+) sign when adding an international dialing prefix.

history






Every telephone number called and received will be saved in history. All numbers in the history can be dialed directly by clicking the CALL BACK on the screen. When the number appears on the list, click it to view details.

Call Options

There are different options that can be used in the history and dialing interface. You may press the MORE while in the dial interface and adjust the speed dial and call settings. In the dialing interface, you may press the search button to browse through the contacts list or set default contact resources.

Contacts

**Enter:**

Click on the applications menu and select contacts.

- The default display is the phone contacts and SIM card contacts.
- The contacts are organized alphabetically by default.
Click the Search icon to enter the contact search interface.
- Any numbers or letters associated with any of the contacts saved in the list will be shown in the search results.

Add New Contact

1. Click the add contact icon (+) to add a contact.
2. Select to save your contacts to the Google™ account, the phone or the SIM card.
3. You may enter different contact details which include adding a picture, name, telephone number, group, address, and email among other options.
4. Click to finish and save the contact.

4:03

× Create contact ✓ ⋮

Device

First name

Last name

Company

Phone


Mobile

Email

Home

Messages

You may use this function to exchange text messages and multimedia messages with your family and friends. The messages to and from the same contact or phone number will be saved into a single conversation so you may see the entire message history conveniently.



Send an SMS

Application Menu >> Messaging >> New message (or shortcut icon)

1. Click to enter the recipient (You may enter contacts from the contact book or enter a new number)
2. Compose Message
3. Send

Send an MMS

When creating a message, the default message style is SMS. The message will automatically convert to MMS when adding an attachment.

1. Click the attachment icon in the messaging interface.
2. Click to add attachments and create an MMS message.

Internet Browser

Menu Functions

- Recent tab
- After browsing through multiple pages, this option will return the user to the previous page.

Windows

- You may view all windows open by clicking the windows icon in the upper right part of the browser. Bookmarks
- Click the save to Bookmarks option to make the current URL as a saved Bookmark.
- Click Bookmarks/History to opened saved bookmarks.

Find on page:


Search current page.

Share page:

Select to share the current page. Bookmarks/History: Show your browsing history and view the most visited pages.

Settings:


Contains a variety of browser settings.



Bluetooth & Wi-Fi

Bluetooth is a short-range wireless communications technology that devices can use to exchange information and connect to different types of devices which include headsets and other devices.

Power on Bluetooth




1. Settings >> Bluetooth and select power on Bluetooth.
2. The Bluetooth icon will appear in the notification bar. Click “scan for devices” and the phone will start to scan for all devices within range.
3. In Bluetooth settings, all the devices found will be displayed in the list under the icon.

Note: The maximum detecting time of the phone is 2 minutes.

Power on Wi-Fi

1. Settings >> Wi-Fi and select ON to power on Wi-Fi
2. Click on the desired Wi-Fi network to be connected. Unsecured networks can be connected to directly – secured networks require a password or credentials prior to connection.



Camera

Camera

Prior to use:

Insert SD card before using the camera or video camera. All photos or videos taken by the phone are typically stored in the memory card for large storage capacity of images.

Open Camera


1. Applications Menu Camera
2. Switch to video mode if you want to record videos.

Note: You may place a camera shortcut icon on any of the screens

Take Pictures

1. Aim the object that the picture will be taken.
2. Press the "Shutter" button on the screen.
3. After taking the picture, the file will be saved in the camera's gallery folder.
4. You can view the photos by clicking the preview box button. You may adjust various settings for the camera by

pressing Menu while in the camera interface. When in the camera viewfinder mode, you can switch to a video or photo gallery.



Gallery

Open Images

Applications Menu >> Gallery

Share Pictures

You may share pictures by sending them through different types of installed applications. You may also send pictures through the MMS message function by composing a message and attaching the picture. Any image can also be sent via the Bluetooth function by selecting the Bluetooth equipment that has been paired.

Adjust Image

Press Menu and Edit to adjust images

You may select from different effects that may include:


Vintage, Black and White, Instant, Latte, Litho, X-Process, Crop, Rotate, Mirror, Straighten, Vignette, Contrast, Exposure, Auto color, Shadows, and Vibrancy, among other settings that can be used to adjust picture images.

View Images

In the picture interface, click on an album to view images In the photo album, scroll the picture toward the left to view the next picture or toward the right to view the previous one.

Crop Pictures

If you want to adjust the size of the picture, use the crop tools. Once the arrow appears, pinch your fingers in or out to adjust the size. If you want to adjust the image and keep its proportion, please hold down any of the four corners of the image and adjust accordingly.



Music

Open Music

Application Menu >> Music

Search Music

You may choose to search for music from the media folder through artist name, song name, and album name. The following formats are available: AMR, MIDI, MP3, WAV, and OGG.

Sound Recorder

The Sound Recorder can record voice or any audio. You may send any recorded audio via Bluetooth or MMS and also have the option to make any recorded audio the phones default ring tone.


The recorder uses 3GPP and OGG formats.

Record

- Keep the phone's microphone near the voice source.
- Click the record button to record the audio.
- Click the stop button to stop recording the audio.


All recordings will be saved in the recording folder in the default music program and can be accessed from the

sound recorder application.




Alarm Clock

1. Click on the Clock icon in the application menu
2. Click the set alarm button and enter the alarm clock set interface where you may delete and edit alarms



Google Play

Google Play allows you to download music, movies, and even games. Click the Play icon to sign in with your Google account.



Settings

Wi-Fi

Settings >> network & Internet >> Wi-Fi to power on. When on, the Wi-Fi will automatically search for available networks. Any unsecured network can be used directly and any secured network requires a password or credentials prior to connection.

Connected devices

Press the switch to power on Bluetooth. Once on, the Bluetooth will automatically scan for any nearby open equipment. You can also use Cast, Printing, and check Received files.

Apps & notifications

Press the check recently opened apps and manage notifications options.

Battery

General power usage

Display

Brightness, Auto rotating screen, Wallpaper, Screen Timeout

Sound

This option sets the phone tone settings for receiving calls and notifications. Some of the settings include:

- Vibrate, volume, ring tones, ring tones notification, dial touchpad, and haptic feedback and tones

Storage

View the phone memory usage.

Security & location

Set up screen locks: Use slide, face/voice unlock, pattern, PIN or password to lock the screen.

- **Pattern:** The first time there will be simple unlock instructions and examples. Click “next step” to continue the security pattern step.
- **PIN:** Enter the PIN number to unlock the screen.
- **Password:** Use the password to unlock the screen

You may stop the security feature at any time.

Set up SIM card PIN lock

SIM card PIN (Personal Identification Number) is used to prevent the unauthorized use of SIM cards.

To change a blocked PIN code, you will need to unlock the SIM lock then go to the Change Password screen. The phone will automatically prompt you enter the old PIN code and ask to enter a new PIN code twice. The phone will then prompt you that the change was successful. If you enter the PIN incorrectly three times, the SIM and PIN codes will be automatically locked. You will need the PUK code to unlock the phone which is available through your service provider. If you enter the PUK code incorrectly 10 times, the SIM card will be permanently locked. Please see your service provider for a new SIM card.

- Password visible – Make the password visible when it’s typed.
- Use security credentials – Allow applications to visit security credentials or other credentials.
- Mobile Network Location – Use wireless services to find locations in applications.
- When using the GPS, power on to set satellite positioning for accuracy.

Accounts

Add accounts,include Duo Exchange Google Personal(IMAP) Personal(POP3)

Accessibility

- The power button ends the call and auto-rotates the screen
- Speak Passwords and large text

Google

- Google account and google services

DuraSpeed

DuraSpeed helps boost the foreground APP by restricting background APPs; some notifications may be postponed or not received.

System

Language and Input

- Language – Change the language of the phone.
- Custom Dictionary – Add or delete words to the custom dictionary.
- Keyboard Settings – Haptic vibration, Haptic tones, Capitalizing, Speech Input, Inputting words, Predictive text function, Auto-Text, Input keyboard method

Gestures

- Jump to camera
- Prevent ringing

Date & Time

- Date and Time adjustment.
- Time Zone – Select Time Zone according to where your location.
- Select Date Format – There are 3 kinds of formats you can choose from Month-Day-Year, Day-Month-Year and Year-Month-Day, and Year-Month-Day which is the default setting

Backup

- Backup Data – Will back up all application data, WLAN passwords, and other settings to Google's servers
- Restore to Factory Settings – Clear all data stored on the phone.

Reset options


- DRM reset; reset Wi-Fi, mobile & Bluetooth; reset app preferences; Erase all data

About phone

- Phone information status and build number


Storage

Connect the phone with the USB cable provided. Once connected, a connection interface will appear. In the connection mode interface, select MTP and turn on the connection screen to be able to transfer files. Other storage options are also available.




Some system settings, hardware, and UI options may vary depending on final version.

Main components



SIM/Micro SD

Nano SIM card+ Nano SIM card Micro sox1



Battery
2800mAh
Detachable battery



Screen lock

It can be increased the security of the phone by using screen lock Screen lock settings can be found under “Settings”>”Security”> “Set up screen lock”.




Customize home interface

In standby mode, press at any blank area for a few seconds to add shortcuts, widgets, folders, or set wallpapers. You can also remove or move,add other items from the home interface. It's customized.




Camera

CUBOT is equipped with front and rear cameras, which are designed for you to share wonderful moments with friends and family. Adjust focus, exposure, zoom in or zoom out, switch between front and rear cameras, and among different functions of the camera video recorder by flipping the icon on the screen.




Make a call

You can make a call under the interface of the Call log, contacts, favorites, and message (which contains the phone number). In standby mode, press the call key to make a call.




Messaging

Touch and open the text box to select an input method. You can insert smiley, picture, audio or video files and send to multiple recipients.




Email

The email app enables you to read, compose and send emails, and is configured to work with all the major email providers. CUBOT supports multiple account modes, and you won't miss any emails.




Music

CUBOT supports various music formats, different sound effects, such as Bass Boost, Virtualizer and equalizer features etc. and 4 categories, i.e. Artists, Albums, Songs and Playlists.



Gallery

You will find it very easy to view all the photos. Flick right or left to move images. Double-click or pinch the photo to zoom in. You can edit, share, print, and more.



Intelligent keyboard

CUBOT automatically corrects and suggests words when you are typing and it also supports voice input.



Cut, copy, and paste

Press for a little longer of the text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then tap to Cut, copy, or paste. It is very easy to copy text from web pages, emails, or text messages.



Map

You can view satellite images or street maps with detailed route instructions just like you are walking in the street. The Map app can be used to locate yourself, and view real-time traffic conditions, pedestrian, bus routes, or car driving route instructions.



FCC Rules Compliance

(United States Federal Communications Commission)

This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user, is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Information (SAR)

This mobile phone meets the government's requirements for exposure to radio waves. This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit set by the FCC is 1.6W/kg – Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The highest SAR value for the model phone as reported to the FCC when tested for use at the ear is 0.39 W/kg and when worn on the body, as described in this user guide, is 0.73W/kg (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements.) While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement. The FCC has granted Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines.

SAR information on this model phone is on file with the FCC and can be found under the Display Grant section at www.fcc.gov/oet/ea/fccid after searching – FCC ID: YHLBLUST60HD.

For body-worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the handset a minimum of 1.5cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 10mm from your body when the phone is switched on.

Additional Information

The information provided in this user manual is subject to change without notice and BLU Products reserves the right to modify the manual at any given time. BLU Products has made every effort to ensure that this user manual is accurate and disclaims responsibility and liability for any inaccuracies or omissions. BLU Products makes no commitment to keep current the user manuals, however, does reserve the right to make improvements to the user manual at any given time without notice.

IC Notice

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

IC: 11492A-STUDIO6.0HD

IC Radiation Exposure Statement

This EUT is in compliance with SAR for general

population/uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528 and IEC 62209. This equipment should be installed and operated with a minimum distance of 1.0 cm between the radiator and your body. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.


Google, Google Play, and other marks are trademarks of Google LLC.

CUBOT SIMPLE & TRUST

Thank you for your purchase of the CUBOTAndroid” product Android is a trademark of Google LLC

Please click www.cubot.net and download the latest firmware, getting acknowledgment of late product information.

Documents / Resources

	CUBOT Simple and Trust Smartphone [pdf] User Guide Simple and Trust Phone, Simple Phone, Trust Phone, Phone, Simple and Trust Smartphone, Smartphone
---	---

References

- [FCC ID Search | Federal Communications Commission](#)