



cudy AX3000 Wi-Fi 6 Mesh Router Installation Guide

[Home](#) » [cudy](#) » cudy AX3000 Wi-Fi 6 Mesh Router Installation Guide 




Quick Installation Guide

Contents

- [1 AX3000 Wi-Fi 6 Mesh Router](#)
- [2 LED and Button](#)
- [3 EU Declaration of Conformity](#)
- [4 WEEE](#)
- [5 FCC Statements:](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

AX3000 Wi-Fi 6 Mesh Router

If your internet source is an Ethernet cable coming from the wall directly instead of a DSL/Cable/Satellite modem, connect the Ethernet cable to the router's WAN port and skip steps 1, 2 ,3.




1. Turn off the modem and remove the battery if it has one.
2. Connect router's WAN Port to DSL/Cable/Satellite Modem.
3. Turn on the modem and then wait about 2 minutes for it to restart.
4. Connect the power adapter to the router and wait 1 minute until the system LED changes from flashing to solid on (red or blue) , which means the system startup is completed.
5. Connect your computer to the router (Wired or Wireless).

Wired

Turn off the Wi-Fi on your computer and connect it to router's LAN port via an Ethernet cable.


Wireless



Connect your device to the router's Wi-Fi using the SSID (network name) and Password printed on the bottom of the router.





6. Launch a web browser, and enter <http://cudy.net/> or <http://192.168.10.1/> in the address bar. Use admin for password to log in.

Navigation icons: back, forward, search, and refresh. Address bar: <http://cudy.net/>



Language:  English 

Username:  admin 

[Log In](#)

7. The window below will pop up, please follow the step-by-step instructions to set up the internet connection.

Quick Setup

1 [Mode](#) 2 Timezone 3 WAN 4 Wireless 5 Summary







Operation Mode

- ☒ Wireless Router
- ☐ Wireless Access Point
- ☐ Wireless Extender
- ☐ WISP

[Exit](#) [Next](#)

 **Enjoy the internet!**

LED and Button

Name	Status	Indication
	OFF	Not powered on
	Flashing	System start-up process
	ON	System startup complete
	OFF	Not connected to the Internet
	ON	Connected to the Internet
	OFF	No connection at WAN port
	ON	WAN port has connection
	OFF	LAN port is not connected
	ON	LAN port is connected
	Off	2.4GHz Wi-Fi off
	Flashing	WPS in process
	ON	2.4GHz Wi-Fi On
	Off	5GHz Wi-Fi off
	Flashing	WPS in progress
	ON	5GHz Wi-Fi On
Button	WPS	Press and hold 1 second to enable the WPS function.
	Reset	Press and hold 2 seconds to reset the router to its factory default settings.

EU Declaration of Conformity

Cudy hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU, directive 2011/65/EU, directive (EU) 2015/863. The original EU declaration of conformity can be found at <http://www.cudy.com/ce>.

WEEE

According to the EU Directive on Waste Electrical and Electronic Equipment (WEEE – 2012/19 / EU), this product must not be disposed of as normal household waste.

Instead, they should be returned to the place of purchase or taken to a public collection point for recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more information, please contact your local authority or the nearest collection point. Improper disposal of this type of waste may result in penalties according to national regulations.

FCC Statements:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

GNU General Public License Notice

The software code in this product was created by third parties and is licensed under the GNU General Public License ("GPL"). If applicable, Cudy ("Cudy" in this context refers to the Cudy entity offering respective software for download or being in charge of the distribution of products that contain respective code) makes the corresponding GPL source code available upon request via the official website, either independently or with the assistance of third parties (such as Shenzhen Cudy Technology Co., Ltd.).

For GPL-related questions, email support@cudy.com. In addition, Cudy offers a GPL-Code-Centre under <https://www.cudy.com/gplcodecenterdownload> where users can get the GPL source codes used in Cudy products for free. Please note, that the GPL-Code-Centre is only provided as a courtesy to Cudy's customers but may neither offer a full set of source codes used in all products nor always provide the latest or actual version of such source codes.

The GPL code used in this product is subject to the copyrights of one or more authors and is supplied WITHOUT ANY WARRANTY.



NEED TECH HELP?



Website:

www.cudy.com



Email:

support@cudy.com



Driver & Manual:

www.cudy.com/download

Support

For technical support, the user guide and more information, please visit: <https://www.cudy.com/support>

Documents / Resources

	<p>cudy AX3000 Wi-Fi 6 Mesh Router [pdf] Installation Guide</p> <p>AX3000, REV1.0, AX3000 Wi-Fi 6 Mesh Router, Wi-Fi 6 Mesh Router, 6 Mesh Router, Router</p>
--	---

References

- [Cudy CE](#)
- [Download Center](#)
- [cudy.com/gplcodecenterdownload](https://www.cudy.com/gplcodecenterdownload)
- [Cudy Support Center](#)

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)