



CURT Multi Function Socket with Back Up Alarm Instruction Manual

[Home](#) » [Curt](#) » CURT Multi Function Socket with Back Up Alarm Instruction Manual 

Contents

- [1 CURT Multi Function Socket with Back Up Alarm](#)
- [2 USCAR application](#)
- [3 INSTALLATION/SAFETY INSTRUCTIONS](#)
- [4 WIRING LOCATION](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



CURT Multi Function Socket with Back Up Alarm



WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

USCAR application



INSTALLATION/SAFETY INSTRUCTIONS

- **Step 1**

Locate the factory 7-way attached to the hitch, behind the center of the rear bumper in position T3 as shown in the 'Wiring Location Guide'.

- **Step 2**

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

- **Step 3**

Separate the factory socket and the 7-way.

- **Step 4**

Insert the 57101 into the factory housing.

- **Step 5**

Mount the bracket to the vehicle and secure the socket.

- **Step 6**

Reinstall all items removed during install and reconnect negative battery terminal.

WIRING LOCATION

PICKUP TRUCKS (T)

Representative vehicle shown below

T3 – Behind driver side rear bumper



NOTICE

All steps must be followed to ensure the CURT socket will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer

57101-INS-RA

1.877.287.8634

NEED ASSISTANCE?

CURTMFG.COM

Scan for helpful installation tips



Documents / Resources



[CURT Multi Function Socket with Back Up Alarm](#) [pdf] Instruction Manual
Multi Function Socket with Back Up Alarm, Multi Function Socket, Multi Function Alarm, Back Up Alarm

References

- [CURT: Trailer Hitches - Trailer Wiring - 5th Wheel - Gooseneck](#)

