

Dasqua SB-003 Digital Zero Setting Devices



Dasqua SB-003 Digital Zero Setting Devices Instruction Manual

[Home](#) » [Dasqua](#) » Dasqua SB-003 Digital Zero Setting Devices Instruction Manual 

Contents

- [1 Dasqua SB-003 Digital Zero Setting Devices](#)
- [2 Product information](#)
- [3 Safety Instructions](#)
- [4 Product Usage Instructions](#)
- [5 Safety Instructions](#)
- [6 Safety instructions](#)
- [7 Replacing batteries](#)
- [8 Disposal](#)
- [9 Technical data](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)

The Dasqua logo consists of a large, stylized red 'D' followed by the word 'asqua' in a black, italicized sans-serif font. A registered trademark symbol (®) is located at the top right of the 'a'.

Dasqua SB-003 Digital Zero Setting Devices



Product information

Specifications

- Product: IP65 Digital Zero Setting Device
- Item No: 2986825, 2986826
- Battery: CR2032; 210mAh
- Protection class: IP65

Safety Instructions

Description of symbols

The following symbols are on the product/appliance or are used in the text:

- The symbol warns of hazards that can lead to personal injury.

General Safety Instructions

The product is not a toy. Keep it out of the reach of children and pets. Do not leave packaging material lying around carelessly as it may become dangerous playing material for children. If you have questions that remain unanswered by this information product, contact our technical support service or other technical personnel. Maintenance, modifications, and repairs must only be completed by a technician or an authorized repair center.

Handling

Handle the product carefully. Jolts, impacts, or a fall even from a low height can damage the product.

Operating environment

Do not place the product under any mechanical stress. Protect the appliance from extreme temperatures, strong jolts, flammable gases, steam, and solvents. Protect the product from direct sunlight.

surgery

Consult an expert when in doubt about the operation, safety, or connection of the product. If it is no longer possible to operate the product safely, take it out of operation.

Battery safety

Correct polarity must be observed while inserting the battery. The battery should be removed from the device if it is not used for a long period of time to avoid damage through leaking. Leaking or damaged batteries might cause acid burns when in contact with the skin; Therefore, use suitable protective gloves to handle corrupted batteries.

Batteries must be kept out of reach of children. Do not leave batteries lying around, as there is a risk that children or pets swallow them. Batteries must not be dismantled, short-circuited, or thrown into fire. Never recharge non-rechargeable batteries as there is a risk of explosion.

Product Usage Instructions

Replacing Batteries

To replace the batteries, follow these steps:

1. Make sure the product is turned off.
2. Locate the battery compartment on the device.
3. Open the battery compartment by following the instructions in the user manual.
4. Remove the old batteries from the compartment.
5. Insert new CR2032 batteries with the correct polarity.
6. Close the battery compartment securely.

Disposal

Dispose of WEEE (Waste from Electrical and Electronic Equipment), used batteries/rechargeable batteries, and packaging in accordance with the laws and regulations in force in your country.

WEEE and used batteries/rechargeable batteries not only contain valuable raw materials but sometimes also hazardous substances which, if released, can adversely affect the environment. Check the dealer's website, the website of your local service provider, or your municipal waste management authority to learn how to dispose of WEEE, used batteries/rechargeable batteries, and packaging correctly.

FAQ

Q: Can I use rechargeable batteries in this device?

A: No, you should not use rechargeable batteries in this device. Only use non-rechargeable CR2032 batteries.

Q: What should I do if the product gets damaged?

A: If the product gets damaged, stop using it and contact our technical support service or an authorized repair center for assistance.

Q: How long do the batteries last?

A: The CR2032 batteries included with the device have a capacity of 210 mAh and should last for a reasonable period of usage. However, battery life can vary depending on the frequency and duration of use.

Safety Instructions

[SB-003] IP65 Digital Zero Setting Device

Item no: 2986825

Item no: 2986826

Description of symbols

The following symbols are on the product/appliance or are used in the text:



The symbol warns of hazards that can lead to personal injury.

Safety instructions

Read this document and the accompanying operating instructions carefully and especially observe the safety information. If you do not follow the safety instructions and information on proper handling, we assume no liability for any resulting personal injury or damage to property. Such cases will invalidate the warranty/guarantee.

General

- The product is not a toy. Keep it out of the reach of children and pets.
- Do not leave packaging material lying around carelessly. This may become dangerous playing material for children.
- If you have questions which remain unanswered by this information product, contact our technical support service or other technical personnel.
- Maintenance, modifications and repairs must only be completed by a technician or an authorised repair centre.

Handling

- Handle the product carefully. Jolts, impacts or a fall even from a low height can damage the product.

Operating environment

- Do not place the product under any mechanical stress.
- Protect the appliance from extreme temperatures, strong jolts, flammable gases, steam and solvents.
- Protect the product from direct sunlight.

Operation

- Consult an expert when in doubt about the operation, safety or connection of the product.
- If it is no longer possible to operate the product safely, take it out of operation and protect it from any accidental use. DO NOT attempt to repair the product yourself. Safe operation can no longer be guaranteed if the product:
 - is visibly damaged,
 - is no longer working properly,
 - has been stored for extended periods in poor ambient conditions or
 - has been subjected to any serious transport-related stresses.

Battery

- Correct polarity must be observed while inserting the battery.
- The battery should be removed from the device if it is not used for a long period of time to avoid damage through leaking. Leaking or damaged batteries might cause acid burns when in contact with skin, therefore use suitable protective gloves to handle corrupted batteries.
- Batteries must be kept out of reach of children. Do not leave batteries lying around, as there is risk, that children or pets swallow them.
- Batteries must not be dismantled, short-circuited or thrown into fire. Never recharge nonrechargeable batteries. There is a risk of explosion!

Replacing batteries



Disposal

Important:

Dispose of WEEE (Waste from Electrical and Electronic Equipment), used batteries/rechargeable batteries and packaging in accordance with the laws and regulations in force in your country. WEEE and used batteries/rechargeable batteries not only contain valuable raw materials but sometimes also hazardous substances which, if released, can adversely affect the environment.

Check the dealer's website, the website of your local service provider or your municipal waste management authority to learn how to dispose of WEEE, used batteries/rechargeable batteries and packaging correctly. Proper disposal ensures compliance with legal regulations and contributes to a cleaner environment.

Product

Any electrical and electronic equipment placed on the European market shall bear this symbol, indicating that the

equipment must be disposed of separately from unsorted municipal waste at the end of its useful life.



Owners of WEEE (Waste from Electrical and Electronic Equipment) shall dispose of it separately from unsorted municipal waste.

Spent batteries and accumulators, which are not enclosed by the WEEE, as well as lamps that can be removed from the WEEE in a non-destructive manner, must be removed by end users from the WEEE in a non-destructive manner before it is handed over to a collection point.

Distributors of electrical and electronic equipment are legally obliged to provide free takeback of waste. You can also hand in old devices to the collection points of the public waste management authorities or to the take-back points set up by manufacturers or distributors as defined by the Electrical and Electronic Equipment Act (ElektroG).

End users are responsible for deleting personal data from the WEEE to be disposed of.

(Rechargeable) batteries

Batteries or rechargeable batteries that are not permanently installed in the old device (e.g. with a battery compartment or similar) must be removed beforehand and disposed of separately.

According to the Battery Directive, end users are legally obliged to return all spent batteries/rechargeable batteries; they must not be disposed of in the normal household waste.

Batteries/rechargeable batteries containing hazardous substances are labelled with this symbol to indicate that disposal in household waste is forbidden. The following abbreviations are used for heavy metals found in batteries: Cd = Cadmium, Hg = Mercury, Pb = Lead (name on (rechargeable) batteries, e.g. below the trash icon

on the left).




You can return used batteries to a local recycling point or battery retailer.

Batteries/rechargeable batteries that are disposed of should be protected against short circuit and their exposed terminals should be covered completely with insulating tape before disposal. Even empty batteries/rechargeable batteries can contain residual energy that may cause them to swell, burst, catch fire or explode in the event of a short circuit.

Technical data

- Battery CR2032; 210 mAh
- Operating environment..... Indoors and outdoors
- Ingress protection..... IP65

Documents / Resources

	<p>Dasqua SB-003 Digital Zero Setting Devices [pdf] Instruction Manual 1801-1010, SB-003 Digital Zero Setting Devices, SB-003, Digital Zero Setting Devices, Zero Setting Devices, Setting Devices, Devices</p>
--	---

References

- [User Manual](#)