

Davek 2BDQP Loss Alert Sensor User Manual

Home » Davek » Davek 2BDQP Loss Alert Sensor User Manual



Contents

- 1 Davek 2BDQP Loss Alert
- Sensor
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 Features**
- **5 INSTRUCTION**
- **6 SAFETY WARNING**
- 7 FCC
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts

davek

Davek 2BDQP Loss Alert Sensor



Product Information

Specifications:

- · Digital tether for pairing phone to umbrella
- Alert sent to phone if umbrella is more than ~30 ft away
- · Digital Loss Alert notifications
- · Last known location memory
- Replaceable CR 2032 battery
- · Battery check LED
- Attachable magnet

Product Usage Instructions

Step 1: Remove Top Black Magnet

Using your thumb, slide the top black magnet off the sensor. Do not try to lift the magnet off. Instead, slide it off as shown:

Step 2: Attach the Sensor to Your Umbrella

- A. Hold the sensor underneath the canopy in the position shown below, depending on your umbrella type.
- B. Place the black magnet on top of the canopy over the sensor. The two parts should automatically join.

For folded umbrella: Position black magnet 3 inches from the top.

For long-shaft umbrella: Position halfway down the full length of the panel.

IMPORTANT: Once removed, keep the magnet and sensor separated (> 2+ ft) so they are not attracted to each other. Be careful! The magnet is strong and will forcefully attach back to the sensor.

Hold Sensor under canopy

Step 3: Pair Sensor to Your Phone

- 1. Download the free Davek Loss Alert app on your phone from the Apple App Store or Google Play.
- Start the app and make sure you ALLOW all permission requests (location, notifications, etc.) during the first launch. For Location Permission, be sure to choose Always Allow. For more information, visit www.davekny.com/instructions.
- 3. Place the phone near the umbrella (less than 1 ft).
- 4. To pair the umbrella to the app, slide the ON/OFF button to ON. You should receive an activation message within 10 seconds: "Umbrella is connected". Now, if you walk away from the umbrella(~30 ft), you will receive a "Connection is lost" notification within 60 seconds. Walk back to the umbrella to automatically re-connect.

Safety Warning

This product features a strong magnet. Please note these precautions:

- KEEP OUT OF REACH OF CHILDREN: Small magnets are a choking hazard. If swallowed, this can cause a severe health risk.
- MEDICAL DEVICE INTERFERENCE: Magnetic fields can affect pacemakers, ICDs, and other implanted medical devices. Avoid use if you are using these medical devices.
- USE AS INTENDED: This device is intended to be attached to your umbrella canopy. Using it otherwise may result in a lost device and/or magnet.

FAQ (Frequently Asked Questions)

Q: Where can I find full instructions and FAQs?

A: For full instructions & FAQ, visit www.davekny.com/instructions.

Q: How can I contact customer support?

A: You can reach customer support via email at support@davekny.com or by phone at 212-749-8746.

Q: Does the product comply with regulatory standards?

A: Yes, the product complies with Industry Canada's licence-exempt RSSs and part 15 of the FCC rules. Please refer to the user manual for more details.

The Davek Loss Alert Sensor is a digital tether that allows you to pair your phone to your umbrella. If the distance between your umbrella and your phone exceeds ~30 ft, the sensor will send an alert to yourphone. Never accidentally leave your umbrella behind again!


Features

- · Digital Loss Alert notifications
- Last known location memory
- Replaceable CR 2032 battery
- · Battery check LED
- · Attachable magnet

INSTRUCTION

STEP 1: REMOVE TOP BLACK MAGNET

Using your thumb, slide the top black magnet off the sensor. Do not try to lift the magnet off. Instead, slide it off as shown:



IMPORTANT: Once removed, keep the magnet and sensor separated (> 2+ ft) so they are not attracted to each other.

Careful! The magnet is strong and will forcefully attach back to sensor.

STEP 2: ATTACH THE SENSOR TO YOUR UMBRELLA


- Hold sensor underneath canopy in position shown below, depending on your umbrella type.
- Place black magnet on top of canopy over sensor. The two parts should automatically join.

FOR FOLDED UMBRELLA

Position black magnet 3" from top

FOR LONG-SHAFT UMBRELLA

Position halfway down full length of panel



SAFETY WARNING

This product features a strong magnet. Please note these precautions:

- **KEEP OUT OF REACH OF CHILDREN:** Small magnets are a choking hazard. If swallowed, this can cause a severe health risk.
- MEDICAL DEVICE INTERFERENCE: Magnetic fields can affect pacemakers, ICDs and other implanted medical devices. Avoid use if you are using these medical devices.
- **USE AS INTENDED:** This device is intended to be attached to your umbrella canopy. Using it otherwise may result in lost device and/or magnet.

NEED HELP?

For full instructions & FAQ:

www.davekny.com/instructions support@davekny.com 212-749-8746

Go to www.davekny.com/instructions for full set up instructions & FAQ.

Canada IC Notice

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- 1. this device may not cause interference, and
- 2. this device must accept any interference, including interference that may cause undesired operation of the device

FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources



References

- ✓ Davek Sensor Set Up Instructions
- <u>User Manual</u>

Manuals+, Privacy Policy