

DELOCK 11501 Multi Socket Cube 3 Way with Childproof Lock and USB Charger User Manual

Home » DeLOCK » DELOCK 11501 Multi Socket Cube 3 Way with Childproof Lock and USB Charger User Manual



Multi Socket Cube 3-way with childproof lock and USB charger





Product-No: 11501 User manual no: 11501-a www.delock.com



http://www.delock.com /qr/11501.html

Contents

- 1 Description
- 2 USB charger included
- 3 Specification
- 4 Package content
- **5 Safety instructions**
- 6 Installation and

Operation

- 7 Declaration of conformity
- 8 Documents / Resources
 - 8.1 References

Description

The extension socket by Delock with USB charging function is suitable for extending sockets on an existing socket outlet.

Make 3 out of 1

Whether in the kitchen, living area or office. There is a lack of free sockets. This multiple socket makes three out of one free grounded socket. The cube shape also provides a space-saving solution.

USB charger included

In addition to the sockets, one USB Type-C[™] and one USB Type-A charging ports are provided. Common fast charging technologies, such as Power Delivery (PD) 3.0, are supported. This makes the charging process as safe and fast as possible.

Specification

· Connectors:

Input:

1 x plug CEE 7/7

Output:

3 x power socket CEE 7/3 with childproof lock

1 x USB Type-A female

1 x USB Type-C™ female

Rated current: 16.0 A / 250 V~

• Rated power: 3680.0 W

· LEDs for status monitoring

· USB Charger:

Input: AC 250 V / 50 Hz / 0.5 A
Output power: max. 20.0 W total

USB-A: 5.0 V / 3.0 A, 9.0 V / 2.22 A, 12.0 V / 1.67 A USB-CTM: 5.0 V / 3.0 A, 9.0 V / 2.22 A, 12.0 V / 1.67 A

Over current protection, over heating protection, short circuit protection

- Average active efficiency 82.06 %
- Efficiency at low load (10 %) 78.21 %
- No-load power consumption 0.138 W

- · Colour: white
- Dimensions (LxWxH): ca. 66 x 66 x 87 mm

Package content

- Extension socket
- User manual

Safety instructions

- This product is only intended for the connection of 220 V ~ 250 V devices to the power line.
- The total power of the connected electrical equipment must not exceed the rated power 3680 W of this product.
- To reduce the risk of electric shock-use only indoors and in dry locations.
- Keep it away from liquids and extreme heat.
- The socket cube must only be plugged into a grounded outlet.
- Do not connect several power strips in a row.
- · Do not cover when in use.
- Disconnected from Voltage only when the plug is pulled out.
- Unplug the product during the thunderstorms.
- It is recommended to replace the socket cube after a serious power surge or several years of using.

Installation and Operation

- 1. Insert the plug of the socket cube into a wall socket.
- 2. Connect your electric appliance and electronic devices to the AC outlets and USB ports.
- 3. Unplug your USB devices from the socket cube when fully charged or not in use.

Support Delock

If you have further questions, please contact our customer support support@delock.de

Final clause

Information and data contained in this manual are subject to change without notice in advance. Errors and misprints excepted.

Copyright

No part of this user manual may be reproduced, or transmitted for any purpose, regardless in which way or by any means, electronically or mechanically, without explicit written approval of Delock.

Declaration of conformity

Products with a CE symbol fulfill the EMC directive (2014/30/EU), the ErP directive (2009/125/EC), LVD directive (2014/35/EU) and RoHS directive (2011/65/EU+2015/863+2017/2102), which were released by the EUcomission.

The declaration of conformity can be downloaded here:

https://www.delock.de/produkte/G 11501/merkmale.html

WEEE-notice

The WEEE (Waste Electrical and Electronic Equipment)-directive, which became effective as European law on

February 13th 2003, resulted in an all out change in the disposal of disused electro devices. The primarily purpose of this directive is the avoidance of electrical waste (WEEE) and at the same time the support of recycling and other forms of recycling in order to reduce waste. The WEEE-logo on the device and the package indicates that the device should not be disposed in the normal household garbage. You are responsible for taking the disused electrical and electronical devices to a respective collecting point. A separated collection and reasonable recycling of your electrical waste helps handling the natural resources more economical. Furthermore recycling of electrical waste is a contribution to keep the environment and thus also the health of men. Further information about disposal of electrical and electronical waste, recycling and the collection points are available in local organizations, waste management enterprises, in specialized trade and the producer of the device.



EU Import: Tragant Handels- und Beteiligungs GmbH, Beeskowdamm 13/15, 14167 Berlin, Germany

Documents / Resources



<u>DELOCK 11501 Multi Socket Cube 3 Way with Childproof Lock and USB Charger</u> [pdf] Use r Manual

11501 Multi Socket Cube 3 Way with Childproof Lock and USB Charger, 11501, Multi Socket Cube 3 Way with Childproof Lock and USB Charger, Childproof Lock and USB Charger, USB Charger

References

- O Delock DomÅ
- Pelock Home
- O Delock Inicio
- O Delock Accueil
- **Delock Strona GÅ**,ówna
- <u>Que Faire de mes Déchets ? Découvrez les solutions pour tous vos déchets et nos conseils pour en produire moins.</u>
- ■ Delock Produkte 11501 Delock Steckdosenwürfel 3-fach mit Kindersicherung und USB PD 3.0 Ladegerät 20 W weiß
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.