



**INT-KLFR-W
Keypad For Alarm
Control Panel**



DELTA INT-KLFR-W Keypad For Alarm Control Panel User Manual

[Home](#) » [Delta](#) » DELTA INT-KLFR-W Keypad For Alarm Control Panel User Manual

Contents

- [1 DELTA INT-KLFR-W Keypad For Alarm Control Panel](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Introduction](#)
- [5 Safety Warning](#)
- [6 Specification](#)
- [7 Overview](#)
- [8 What's In The Box](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



DELTA INT-KLFR-W Keypad For Alarm Control Panel



Product Information

- **Product Name:** INT-KLFR-W Keypad
- **Code:** INT-KLFR-W
- **Manufacturer/Brand:** SATEL
- **Power Supply:** 12 V DC
- **Current Consumption:** max. 110 mA
- **Color:** White
- **Weight:** 0.34 kg
- **Dimensions:** 145 x 143 x 25 mm
- **Warranty:** 2 years

Product Usage Instructions

1. Installation:

1. Ensure the power supply is disconnected before installation.
2. Mount the keypad in a suitable location near the alarm control panel.
3. Connect the keypad to the control panel following the provided instructions.

2. Operation:

1. Use the built-in proximity card reader to operate the system without passwords.
2. The LCD display shows text messages for easy navigation and programming.

3. Maintenance:

1. Regularly clean the keypad with a soft, dry cloth to prevent dust buildup.
2. Avoid contact with caustic, staining, and viscous fluids as they may damage the device.

Frequently Asked Questions (FAQ):

- **Q: Can I use the keypad with other alarm control panels?**

A: The INT-KLFR-W keypad is specifically designed for use with the Integra series alarm control system and may not be compatible with other panels.

- **Q: How do I reset the keypad if I forget the proximity card?**

A: Please refer to the user manual for detailed instructions on resetting the keypad in case of forgotten credentials.

Introduction

- The INT-KLFR-W keypad is intended for daily operations and programming of the Integra series alarm control system.
- The built-in proximity card reader allows to operate the system without the necessity to remember passwords. With the LCD showing text messages, even advanced functionalities of the alarm control unit are simple and convenient.



Safety Warning

Warning!

Please read the user manual included in this work as it contains important information related to the safety of installation and use of the device.

- Only persons who read the user manual may use the device.

- The user manual must be kept because it may be required in the future. The device is to be used exclusively for purposes specified in this user manual.
- The device must be unpacked before starting up. After removing the packaging make sure the device is in working order.
- If the product has defects, it should not be used until it is repaired.
- The product is intended for use at home and commercial use and may not be used for other than intended use.
- The manufacturer is not liable for damages resulting from not adhering to the rules contained in the user manual, therefore, we recommend following the aforementioned safety rules for the operation and maintenance of the device. In this way, you will ensure your safety and avoid causing damage to the device.
- The manufacturer and the supplier are not liable for losses or damages arising out of the product, including financial or intangible losses, loss of profits, income, data, pleasure from use of the product, or other products related to it – indirect, incidental, or consequential loss or damage. The above provisions apply whether the loss or damage concerns:
 1. Deterioration of quality or the lack of operation of the products or products related with it due to damage as well as the lack of access to the product when it is undergoing repair, which results in stoppage the loss of user's time or a break in business activity;
 2. Improper results of operation of the product or products related to it;
 3. It applies to losses and damages according to any legal category, including negligence and other losses, termination of a contract, expressed or implied guarantee, and strict liability (even if the manufacturer or the supplier was notified about the possibility of occurrence of such damages).

Safety measures:

- Particular attention to designing was directed to the quality standards of the device where ensuring the safety of operation is the most important factor.
- The device must be secured against contact with caustic, staining, and viscous fluids.
- The device was designed in such a way that it restarts operation when the power supply is restored after a break.
- **Attention!** We recommend using protections to further protect the device from possible overvoltages in installations. Surge protectors are effective protection against accidental pass to the device voltages higher than the rated.
- Damages caused by passing the voltages higher than specified in the manual are not under warranty.
- Turn off the device before transporting it.
- Prior to connecting the device to a power source check whether the supplied voltage is consistent with the rated voltage specified in the user manual.

Proper product disposal:

- A marking of a crossed-out waste bin indicates that the product may not be disposed of together with other household waste in the entire EU. To avoid possible damage to the natural environment of health due to uncontrolled waste disposal, therefore, it should be handed over for recycling, propagating in this way sustainable use of natural resources.
- To return a worn-out product, use a collection and disposal system for this type of equipment or contact the seller from whom it was purchased. He will then be recycled in an environmentally friendly way.

Specification

Support:	INTEGRA
Main features:	<ul style="list-style-type: none">• Large, easily readable LCD with backlight displaying detailed information on system state• 3EOL configurations support – 2 Inputs• Operation status LED indicator• Alarms: keypad hold-down PANIC, FIRE and AUX• Buzzer for acoustic signaling of some system events• RS-232 port allows programming using the PC with GUARDX software installed• proximity reader built-in – Unique EM 125kHz• Microswitch as tamper contact
Power supply:	12 V DC
Current consumption:	max. 110 mA
Color:	White
Operation temp:	-10 °C ... 55 °C
Weight:	0.34 kg
Dimensions:	145 x 143 x 25 mm
Manufacturer / Brand:	SATEL
Guarantee:	2 years

Overview

View after open the cover



View after remove the cover




Mounting side view



What's In The Box

In the kit



PACKAGE

- **Dimensions (L x W x H):** 0x0x0 mm
- **Gross Weight:** 0 kg

Contact Information

- DELTA-OPTI Monika Matysiak; <https://www.delta.poznan.pl> POL; 60-713 Poznań; Graniczna 10
- e-mail: delta-opti@delta.poznan.pl
- tel: +(48) 61 864 69 60

Documents / Resources

	<p>DELTA INT-KLFR-W Keypad For Alarm Control Panel [pdf] User Manual INT-KLFR-W Keypad For Alarm Control Panel, INT-KLFR-W, Keypad For Alarm Control Panel, Alarm Control Panel, Control Panel</p>
---	---

References

-  [Monitoring, Kamery, Alarmy - sklep.delta.poznan.pl](https://sklep.delta.poznan.pl)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.