



## **DELUX M912DB Ergonomics LED Screen Display Wireless Gaming Mouse User Manual**

[Home](#) » [DELUX](#) » **DELUX M912DB Ergonomics LED Screen Display Wireless Gaming Mouse User Manual** 

# DELUX

**M912DB Ergonomics LED Screen Display Wireless Gaming Mouse  
User Manual**



## M912DB

### Contents

- [1 M912DB Ergonomics LED Screen Display Wireless Gaming Mouse](#)
- [2 Instructions](#)
- [3 Warranty Conditions](#)
- [4 EU Declaration of Conformity](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)

## M912DB Ergonomics LED Screen Display Wireless Gaming Mouse

Dear customer,



Thank you for purchasing our product. Please read the following instructions carefully before first use and keep this user manual for future reference. Pay particular attention to the safety instructions. If you have any questions or comments about the device, please contact the customer line.



[www.alza.co.uk/kontakt](mailto:www.alza.co.uk/kontakt)

© +44 (0)203 514 4411

Importer [Alza.cz](http://www.alza.cz) as., Jankovcova 1522/53, Holešovice, 170 00 Praha 7, [www.alza.cz](http://www.alza.cz)



## Instructions

### Screen Display

The mouse is equipped with a screen which can display mode name, DPI gear and battery capacity.

### Mode Switching

The mouse can be used as wired, wireless using 2.4G or wireless using Bluetooth 5.0 (dual channel). Short press the mode button at the bottom to cyclically switch between USB/2.4G/BT1/BT2 modes.

The wireless mode can be shown by the corresponding indicator (indicators will be all of in the wired mode), and the screen displays the current mode name.

### Screen Display

The mouse is equipped with a screen which can display mode name, DPI gear and battery capacity.

### Mode Switching

The mouse can be used as wired, wireless using 2.4G or wireless using Bluetooth 5.0 (dual channel). Short press the mode button at the bottom to cyclically switch between USB/2.4G/BT1/BT2 modes.

The wireless mode can be shown by the corresponding indicator (indicators will be all of in the wired mode), and the screen displays the current mode name.

### DPI Switch


There are five gears of DPI sensitivity. You can check the current gear of DPI on the screen. The DPI modes are: 800 – 1200 – 1600 – 2400 – 4000. The driver can adjust this sensitivity in range from 200 DPI to 4800 DPI.

### Battery Detection

The screen displays the battery capacity grid and battery percentage. When the battery voltage is lower than 3.3V ( $\pm 0.1V$ ), the battery capacity is about 20%.

### Mouse Customization

In order to customize your mouse, you need to download the driver. The driver can be found on Deluxe official website: [www.deluxworld.com/en/service/download/](http://www.deluxworld.com/en/service/download/). The driver let's you customize some aspects of the mouse, such as functions of the buttons, lighting, DPI, macros and so on.



Open the driver settings interface (note that the mouse has to be connected prior to the opening of the software).

- Click the configuration button to configure some aspects of the mouse (see below).
- The power can be displayed in a wireless mode, and the charging status can be displayed in the wired mode.
- The mouse can be restored to the default state after clicking the reset button.

### Key Setting

On the right side of the interface, you can set specific functions of the mouse buttons. The setting will be saved automatically.

### Power Management

The time when mouse can enter stand-by mode can be set in a range between 3 to 10 minutes. In order to wake the mouse up, just move it slightly.

### DPI Setting

You can click “DPI” to modify the DPI gear, DPI value and light corresponding to the DPI gear. The setting will be saved automatically.

### Lighting Setting

Click “Lighting” to set the overall lighting effect of the mouse. Select different lighting modes and the mouse can display different lighting effects. Users can adjust the brightness, speed, or color. The setting will be saved automatically.

### Mouse parameter setting

Click to enter the system mouse setting interface.

## Warranty Conditions

A new product purchased in the Alza.cz sales network is guaranteed for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide the original proof of purchase with the date of purchase.

**The following are considered to be a conflict with the warranty conditions, for which the claimed claim may not be recognized:**

- Using the product for any purpose other than that for which the product is intended or failing to follow the instructions for maintenance, operation, and service of the product.
- Damage to the product by a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (e.g., during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, such as sunlight and other radiation or electromagnetic fields, fluid intrusion, object intrusion, mains overvoltage, electrostatic discharge voltage (including lightning), faulty supply or input voltage and inappropriate polarity of this voltage, chemical processes such as used power supplies, etc.
- If anyone has made modifications, modifications, alterations to the design or adaptation to change or extend the functions of the product compared to the purchased design or use of non-original components.

## EU Declaration of Conformity

### Identification data of the manufacturer's / importer's authorized representative:

Importer: [Alza.cz](https://www.alza.cz) a.s.

Registered office: Jankovcova 1522/53, Holešovice, 170 00 Prague 7

CIN: 27082440

### Subject of the declaration:

Title: Mouse

Model / Type: Deluxe M912DB

### The above product has been tested in accordance with the standard(s) used to demonstrate compliance with the essential requirements laid down in the Directive(s):

Directive No. 2014/53/EU

Directive No. 2011/65/EU as amended 2015/863/EU



Prague, 30.9.2022

## WEEE



■ This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE – 2012/19 / EU). Instead, it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.







# DeLUX



M912DB  
User Manual - (English) manual -  
M912DB manual - (English) manual -  
M912DB manual

**[DELUX M912DB Ergonomics LED Screen Display Wireless Gaming Mouse](#)** [pdf] User Manual  
M912DB, Ergonomics LED Screen Display Wireless Gaming Mouse, Display Wireless Gaming Mouse, Ergonomics LED Screen, Wireless Gaming Mouse, Gaming Mouse, Mouse

## References

-  [Alza.sk – rýchly a pohodlný nákup odkiaľkoľvek | alza.sk](#)
-  [alza.at](#)
-  [alza.co.uk](#)
-  [alza.de](#)
-  [alza.hu](#)
-  [alza.sk](#)
- ✂ [DELUX | GAMING DEVICE | ERGONOMIC MOUSE AND KEYBOARD | OFFICE DEVICE](#)