


# **Dewenwils V40705 Indoor Countdown Timer Instruction** Manual

Home » dewenwils » Dewenwils V40705 Indoor Countdown Timer Instruction Manual



# c ewenwils



**Indoor Countdown Timer** SKU:HIDT01E [Instruction Manual]

#### **Contents**

- 1 V40705 Indoor Countdown
- **Timer**
- 2 Product Layout
- 3 Specifications
- **4 One Year Limited Warranty**
- 5 Documents / Resources
  - 5.1 References


#### **V40705 Indoor Countdown Timer**

Please pay attention to the warning signs
Read the instructions with caution before operating and keep it properly
WARNING:

- 1. Do not connect any devices which may exceed the maximum ratings of this timer.
- 2. Children are not allowed to use the timer without supervision.
- 3. Do not disassemble or repair the product, but only by authorized service personnel.
- 4. Do not immerse in water.
- 5. Always unplug and store indoors when not in use.

### **Product Layout**

Press the button to set timer, the timer mode will be switched in the following order



1hour-2hours-4hours-8hours-HOLD-OFF 1hour On for 1 hour then Off 2hours On for 2 hours then Off 4hours On for 4 hours then Off 8hours On for 8 hours then Off HOLD Always ON

#### **Federal Communications Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

## **Specifications**

- Rated Voltage: 125VAC, 60 Hz
- Electrical Rating:
- 15A General Use
- 15A Resistive, 1000W Tungsten
- 500VA Electronic Ballast 1/3HP
- 120VAC 8.3A Ballast

#### **One Year Limited Warranty**

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date.

Please note that the warranty does not cover damage caused by personal misuse or improper installation. Please attach your Order ID and Name so that our dedicated customer service team can help you better.



#### **Documents / Resources**



<u>Dewenwils V40705 Indoor Countdown Timer</u> [pdf] Instruction Manual HIDT01E, V40704, V40705, V40705 Indoor Countdown Timer, V40705, Indoor Countdown Timer, Countdown Timer, Timer

#### References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.