



DIGITECH HDMI VGA Converter User Manual

[Home](#) » [Digitech](#) » DIGITECH HDMI VGA Converter User Manual

DIGITECH HDMI VGA Converter User Manual



Contents [[hide](#)]

- [1 Operation:](#)
- [2 Troubleshooting:](#)
- [3 Specifications:](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Operation:

Before Installation, please make sure all devices you want connected have been turned off. Ensure that your output devices support the same frequency and resolution settings as the source device.

1. Connect the HDMI plug of the converter to the HDMI input of your device such as a laptop or PC.
2. Connect a VGA cable (not included) to the output of the converter and the input on your VGA display.
3. Connect the 3.5mm audio cable to the output jack on the converter and the audio input jack of your laptop or PC if audio is required.
4. Power on all the connected devices such as the display and laptop or PC and switch the source input of the display to VGA.

Note:The image does not need to be adjusted; the converter will position it automatically.

Troubleshooting:

Not Turning On/Intermittent Signal:

1. Check the refresh of the VGA monitor is set to 50 or 60HZ otherwise the device will not match with your HDMI source.
2. Ensure the VGA display and HDMI input supports the required resolution. If they don't match, then you will need to switch the VGA display or HDMI input resolution so that it supports either 1080p, 1080i, 720p, 576p or 480p.
3. Connect a micro B USB cable (not included) to the input of the converter and the plug to a USB port on a computer or USB power supply. This should make the signal stable as some devices require additional power.
4. The VGA cable connected between the display and converter maybe faulty, connect a different cable and try again.

No Audio Output:

1. Switch the audio output as HDMI otherwise it will still be coming out of the laptop or PC.


Specifications:

Input	1 x HDMI
Output	1 x VGA, 1 x 3.5 mm Audio Jack
HDMI Resolution	1080p (1920 x 1080) x 1080i (1920 x 1980), 720p (1280 x 720), 576p (720 x 576), 480p (720 x 480)
VGA Resonation	1080p (1920 x 1080), 1080i (1920 x 1080), 720p (1280 x 720), 576p (720 x 576), 480p (720 x 480)
Frequency	50/60Hz
Power	5VDC, 500mA (Micro B USB)
Cable Length	160 mm
Dimension	45 (L) x 45 (W) x 15 (H) mm

Contact:

Tech Brands by Electus Distribution PTy. LTD,
320 Victoria Rd, Rydalmere NSW 2116 Australia
PH: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com

Documents / Resources

 <p>DIGITECH Audio Visual</p> <p>HDMI to VGA Converter AC1724</p> <p>Operation</p> <p>Before using this device, please read the following instructions carefully. Failure to follow these instructions may result in damage to the device or personal injury.</p> <p>1. Connect the HDMI input to the source device (e.g., DVD player, Blu-ray player, PC, etc.).</p> <p>2. Connect the VGA output to the display device (e.g., monitor, projector, etc.).</p> <p>3. Connect the 3.5mm audio output to the audio system (e.g., speakers, etc.).</p> <p>4. Turn on the power switch on the back of the device.</p> <p>5. The device will automatically detect the input signal and output the corresponding video and audio signals.</p> <p>6. The device is designed for indoor use only. Do not use it in wet or dusty environments.</p> <p>7. Do not touch the device when it is powered on. It may become hot.</p> <p>8. The device is not a power supply. Do not connect it to a power supply.</p> <p>9. The device is not a power supply. Do not connect it to a power supply.</p> <p>10. The device is not a power supply. Do not connect it to a power supply.</p> <p>Specifications</p> <p>Input: HDMI (Type A)</p> <p>Output: VGA (Type D), 3.5mm Audio Jack (Type C)</p> <p>Power: 5VDC, 500mA (Micro B USB)</p> <p>Dimensions: 45 (L) x 45 (W) x 15 (H) mm</p>	<p>DIGITECH HDMI VGA Converter [pdf] User Manual</p> <p>HDMI VGA Converter, AC1724</p>
--	--