

dji Mic 2 Firmware



dji Mic 2 Firmware Upgrade User Guide

[Home](#) » [DJI](#) » dji Mic 2 Firmware Upgrade User Guide 

Contents

- [1 dji Mic 2 Firmware Upgrade](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 How to update firmware](#)
- [5 FAQ](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



dji Mic 2 Firmware Upgrade



Specifications

- **Product Name:** DJI Mic 2
- **Manufacturer:** DJI
- **Website:** <http://www.dji.com/mic-2>

Product Usage Instructions

Firmware Upgrade Guide

1. Visit the official DJI website at the provided link for firmware upgrade instructions.
2. Follow the steps outlined on the website to upgrade the firmware of your DJI Mic 2.
3. After the firmware update is complete, check the firmware version on the receiver to confirm a successful update.

Transmitter and Receiver Connection

To connect the transmitter to the receiver:

1. Utilize the receiver touchscreen for a user-friendly connection process.
2. Alternatively, manually stop the transmitter's internal recording after connecting it to the receiver.

When there is new firmware available, update the firmware by connecting the transmitters and the receiver to the computer one at a time.

How to update firmware

- **a)** Download the firmware on the product page at www.dji.com/mic-2/downloads.
- **b)** Connect a transmitter or the receiver to the computer using the USB-C cable provided. When connecting to a computer, the receiver needs to be in the off state, and the transmitter can be either in the on or off state.
- **c)** Place the downloaded firmware update package .bin file under the root directories of the transmitter or receiver.
- **d)** After disconnecting from the computer, the receiver will start upgrading automatically, and the screen will display "updating" during the upgrading process. The transmitter needs to be powered on to start upgrading automatically. The System Status LED will blink red and green alternately during the upgrading process.
- **e)** Once the upgrade is complete, the firmware version can be viewed on the receiver to confirm that it has been successfully upgraded to the latest firmware.
 - If the firmware update fails, download the firmware again, restart the receiver or transmitter, and repeat the steps above. After the firmware update is complete, check the firmware version on the receiver to ensure the firmware has been updated successfully.
 - If the firmware of the transmitter does not automatically update after powering on, disable Auto Record on the receiver touchscreen or manually stop the transmitter's internal recording after connecting the transmitter to the receiver.

FAQ

- **Q: How can I check if the firmware update was successful?**
 - A: To verify a successful firmware update, check the firmware version on the receiver after completing the upgrade process.
- **Q: What should I do if I encounter connection issues between the transmitter and receiver?**
 - A: If you experience connection problems, ensure that both devices are properly powered on and within range. You may also refer to the product manual for troubleshooting tips or contact DJI support for assistance.

<http://www.dji.com/mic-2>

Documents / Resources

	dji Mic 2 Firmware Upgrade [pdf] User Guide Mic 2, Mic 2 Firmware Upgrade, Firmware Upgrade, Upgrade
--	---

References

- [DJI Mic 2 - Pocket-Sized Pro Audio - DJI](#)
- [DJI Mic 2 - Downloads - DJI](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.