DONGGUAN K1B Wireless Keyboard and Mouse



# **DONGGUAN K1B Wireless Keyboard and Mouse User Manual**


Home » Dongguan » DONGGUAN K1B Wireless Keyboard and Mouse User Manual 🖫

## **Contents**


- 1 DONGGUAN K1B Wireless Keyboard and Mouse
- 2 Packing List
- - uoiming -io
- 3 Overview
- **4 Operation Guides**
- **5 FN Key Combination Instructions**
- **6 Mouse Instructions**
- **7 Correct Disposal Of This Product**
- **8 FCC STATEMENT**
- 9 Documents / Resources
  - 9.1 References
- **10 Related Posts**

# **DONGGUAN**

# **DONGGUAN K1B Wireless Keyboard and Mouse**










- 1. Keyboard x1
- 2. Mouse x1
- 3. USB receiver x1
- 4. USB C to USB adapter x1
- 5. User manual x1


# **Overview**






**Operation Guides** 







- 1. Fetch the wireless keyboard and mouse, and USB receiver.
- 2. Insert two AAA batteries into the keyboard according to the positive and negative signs. Turn on the power switch of the keyboard.
- 3. Insert one AA battery into the mouse according to the positive and negative signs. And turn on the power switch of the mouse.
- 4. Plug the receiver into the USB port of your computer. If your device contains a USB C port, you can also use a USB C to USB adapter. After inserting the receiver, please wait 3 seconds for the system to automatically install the driver.
- 5. When the computer installs the driver automatically, they start serving.

# **FN** Key Combination Instructions

KEY	Win	Мас
FN+A	Switch to Win system	/
FN+S	/	Switch to Mac system
FN+F1	Screen brightness -	Screen brightness -
FN+F2	Screen brightness +	Screen brightness +
FN+F3	Conversion Window	Array Runner
FN+F4	Search	Focused search
FN+F5	microphone	Call Siri
FN+F6	Music	full screen screenshot
FN+F7	Previous song	Previous song
FN+F8	Play / Pause	Play / Pause
FN+F9	next song	next song
FN+F10	mute	mute
FN+F11	Vo <b>l</b> ume down	Volume down
FN+F12	Vo <b>l</b> ume up	Volume up

# **Mouse Instructions**

Key	Function
Left Button L	Standard left mouse button function
Middle Button M	Standard middle mouse button function
Right button R	Standard mouse right button function
Forward FB	Standard mouse forward function
Back BB	Standard mouse back function
DPI+	800/1200/1600/2000
DPI-	2000/2600/1200/800

# **Correct Disposal Of This Product**

(Waste Electrical & Electronic Equipment) This Marking shown on the product or its literature indicates that it should not be disposed of with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

## **FCC STATEMENT**

This device complies with part 15 of the FCC Rules.

## Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

### Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user

is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Note:

The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

## The device has been evaluated to meet general RF exposure requirements.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or in conjunction with any other antenna or transmitter.

#### **Contact Us**

Whatever you need, we're here to help. Just get in touch, and we'll try our best to respond within 24 hours.

### After-sales email:

csforcustomer@gmail.com.

### **Documents / Resources**



**DONGGUAN K1B Wireless Keyboard and Mouse** [pdf] User Manual

2A2B5-K1B, 2A2B5K1B, K1B Wireless Keyboard and Mouse, K1B, K1B Keyboard and Mouse, Wireless Keyboard and Mouse, Wireless Keyboard, Wireless Mouse, Keyboard and Mouse, Keyboard, Mouse

#### References

User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.