



DOSS SoundBox Pro Plus Wireless Bluetooth Speaker User Manual

[Home](#) » [Doss](#) » DOSS SoundBox Pro Plus Wireless Bluetooth Speaker User Manual 

Contents

- 1 DOSS SoundBox Pro Plus Wireless Bluetooth Speaker
- 2 1. Packing content
- 3 2. Specifications
- 4 3. Product overview
- 5 4. Buttons and controls
- 6 5. Indicators
- 7 6. Pairing your device via Bluetooth
- 8 7. Pairing your device via Auxiliary cable
- 9 8. Play music from a Micro SD card
- 10 9. How to set up true wireless stereo pairing
- 11 Warning
- 12 FCC Statement
- 13 RF Exposure Information
- 14 ISED Statement
- 15 Specifications
- 16 Frequently Asked Questions (FAQ)
 - 16.1 Q: What is the warranty period for the DOSS SoundBox Pro+?
- 17 Documents / Resources
 - 17.1 References
- 18 Related Posts

DOSS SoundBox Pro Plus Wireless Bluetooth Speaker



USER MANUAL


1. Packing content

- DOSS SoundBox Pro+ x 1
- Micro USB charging cable x 1
- User manual x 1











2. Specifications

- Bluetooth version: V5.0
- Range: 20 m/66'
- Output: 12W x 2
- Input: 5V=2A
- Battery: Li-ion 3.7V=4400mAh
- Weight: 758g
- Unit dimension: 8.9 x 3.3 x 3.5 inches
- Play time: 15 hours (at 50% volume)
- Warranty: One-year





3. Product overview



4. Buttons and controls

No.	Buttons	You want to	How to
1		Turn on/off	Press
2		Add/cancel extra bass	Press
		Change/turn on/off the light mode	Press and hold
3		Increase the volume	Press
		Skip to the next track	Press and hold
4		Decrease the volume	Press
		Skip to the previous track	Press and hold
5	ADD	Enter/quit TWS mode	Press and hold
6		Play/Pause	Press
		Answer/end a call	
		Disconnect the device	Press and hold
		Reject a call	
7	MODE	Switch modes	Press
		Change the light colors	Press and hold
8		Use handfree function	Speak to the Mic
9		Play via audio-in	Plug in AUX cable
10		Play via Micro SD card	Insert the Micro SD card
11		Charge the speaker	Insert the charging cable
12		Reset the speaker	Poke it with a needle

5. Indicators

Indicator view	Indicator state	System state
	Rapidly flashing blue	Bluetooth disconnects
	Solid blue	Bluetooth connected
	Solid red	Audio in mode
	Solid green	Micro SD card mode
	OFF	Power off
	Solid white	Extra bass mode
	Light off	Cancel extra bass
	L(left) and R(right) rapidly flashing white alternately	TWS Pairing
	L(left)/R(right) solid white	TWS Paired
	Solid red	Charging
	OFF	Fully charged

6. Pairing your device via Bluetooth

1. Enable Bluetooth on your device and search for the speaker.
2. Select SoundBox Pro+ on the Bluetooth list.
3. Once paired, you can see the connected status on your device.

- The speaker will auto power off after 15 minutes without any media input. To remove the function, please contact <support@dossav.com> for support.
- The music volume will drop down 15% automatically when the speaker is on low battery.

Having problems connecting?

- Make sure that your device is within 1 meter from the speaker.
- Press and hold the Play/Pause button for 5 seconds.

Still have problems? Contact DOSS customer service at support @dossav.com for assistance.

7. Pairing your device via Auxiliary cable

Play via 3.5mm Auxiliary cable(not supplied)

8. Play music from a Micro SD card


Play in download order

Support capacity: 32G or less


Support format: MP3, WAV, WMV

9. How to set up true wireless stereo pairing

- Make sure both speakers didn't connect to any device via Bluetooth, if they did, please press and hold play/pause button for 5 seconds.
- Turn on both speakers.
- Press and hold the ADD button on one of the speakers for 3s.



Waiting for pairing.



- Once paired successfully, the speaker with the left LED on is the Primary, the speaker with the right LED on is the Secondary.
- Turn on Bluetooth on your device and select DOSS Soundbox Pro+ on your Bluetooth list.

Warning

- DO NOT drop, hit or shake the speaker.
- DO NOT disassemble, repair or modify the speaker by yourself.

- DO NOT use cleaning products that contain benzene, solvents or alcohol.
- DO NOT expose the speaker to excessive heat or direct sunlight for a long time. DO NOT store the speaker in a place with humidity or dust.
- DO NOT place heavy objects on top of the speaker.
- DO NOT use the speaker near a microwave oven or wireless LAN products.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

ISED Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Specifications

- Bluetooth version: V5.0


- Range: 20 m/66 ft
 - Output: 12W x 2
 - Input: 5V=2A
 - Battery: Li-ion 3.7V=4400mAh
 - Weight: 758g
 - Unit dimensions: 8.9 x 3.3 x 3.5 inches
 - Play time: 15 hours (at 50% volume)
 - Warranty: One-year
-

Frequently Asked Questions (FAQ)

Q: What is the warranty period for the DOSS SoundBox Pro+?

A: The warranty for the DOSS SoundBox Pro+ is one year.

Documents / Resources

	DOSS SoundBox Pro Plus Wireless Bluetooth Speaker [pdf] User Manual SoundBox Pro Plus, SoundBox Pro Plus Wireless Bluetooth Speaker, Wireless Bluetooth Speaker, Bluetooth Speaker, Speaker
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.