DrunkDeer M75 Series Rapid Trigger Mechanical Keyboard User Manual

Contents

DrunkDeer M75 Series Rapid Trigger Mechanical Keyboard

Package Content

- A75 MS Keyboard *1
- USB C to A Adapter *1
- USB Type-C Cable *1
- Dustproof Cover *1
- Keycap Puller *1
- Quick Guide *1

A75 MS Keyboard

Quick Guide

Keycap Puller

Dustproof Cover

USB Type-C Cable

CtoA Adapter

Wired Connection

- For the devices with Type-C ports(Laptop, for example), you can connect the keyboard to the device with the Type-C cable directly.

- For the devices that only have Type-A ports, you can connect the keyboard to the device with the Type-C cable and the C to adapter.

How to restore the keyboard to default settings

- You can restore the keyboard by key combination 'Fn2 + Esc' for 3 seconds.
- The backlight will blink red for 3 seconds and the keyboard will return to its default state.

How To Adjust The Actuation Sensitivity

|	Fast			to				Accurate	
Actuation Distance(mm)*	0.4	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6
Combine Key	Fn2 +1							Fn2 +9	

- The actuation sensitivity (actuation distance) can be adjusted from high to low by the key combination 'Fn2 +1' ~ 'Fn2 +9!

About The Magnetic Switch

- Magnetic Switches utilize Hall Sensors to determine the distance a key is pressed by measuring the strength of the magnetic field.
- It makes it possible to customize the trigger point (actuation point) to your preferred level of pressure and distance, accommodating all typing styles.
- Whether you bottom out or barely touch the keys, we've incorporated adaptive typing to provide noticeable comfort improvement for everyone.
- MS doesn't rely on physical contact, which can wear down the key over time.
- These switches can be pressed hundreds of millions of times.
- This is vastly superior to the metal contacts of conventional switches.

How To Control The Backlight Effect

The backlight effect can be changed by key combination as follows:

- **Fn2 + Tab:** Change the backlight colour (Only for certain effects)
- Fn2 +: ← Previous backlight effect
- **Fn2 +** →: Next backlight effect
- **Fn2 +** ↑ : Increase the backlight brightness
- **Fn2 +** ↓: Decrease the backlight brightness

How To Switch The Operating Layout

- The operating layout of the A75 can be changed by key combinations as follows:
- Fn2 + M: Switch to the Mac OS
- Under the MacOS layout, the function keys on F1 to F12 are available without other driver programs.
- Fn2 + W: Switch to the Windows
- Under the Windows layout, the function keys would retain the original key value.

Control The Volume With The Knob

- Whether it's MacOS or Windows layout, the volume of the computer can be controlled directly by turning the

knob.

- You can also play or pause music/video by pressing the knob.

Specification

- **Keyboard Model:** A75
- **Keyboard Size:** 355mm*140mm*45mm
- **Keyboard Weight:** 715 ‡ 20 g
- **Layout:** ANSI 75%
- **Main Material:** ABS(Keycaps, Case); Aluminum (Knob)
- **Switch Type:** DrunkDeer Magneite Switch
- **System Available:** Windows & Mac OS

Caution

- Please DO NOT place the keyboard in a high-temp or strong magnetic environment.
- We DO NOT recommend disassembling or modifying this keyboard.
- Due to the characteristics of magnetic switches, abnormal environments such as severe impact, high temperature, and strong magnetic fields may cause the keyboard to malfunction.
- If you have other questions, please feel free to contact us at **hello@drunkdeer.com** or go to our official website **www.drunkdeer.com** for further information and help.

Documents / Resources

M75 Series DrunkDeer® A75 User Manual Magnetic Switch Keyboard	**DrunkDeer M75 Series Rapid Trigger Mechanical Keyboard** [pdf] User Manual M75 Series Rapid Trigger Mechanical Keyboard, M75 Series, Trigger Mechanical Keyboard, Mechanical Keyboard, Keyboard

References

- **User Manual**