

DSI HD39202A Floor Lamp User Guide

[Home](#) » [DSI](#) » DSI HD39202A Floor Lamp User Guide 



Item # 1012181577

Model # HD39202A

USE AND CARE GUIDE

FLOOR LAMP



Contents

- 1 Safety Information
- 2 Warranty
- 3 Pre-Installation
- 4 Installation
- 5 Care and Cleaning
- 6 Troubleshooting
- 7 Service Parts
- 8 Documents / Resources
 - 8.1 References

Safety Information

READ AND SAVE THESE INSTRUCTIONS.

- This product has been manufactured with the highest standards of safety and quality.
- For energy savings, this portable light has been engineered to safely use a self-ballasted LED bulb in place of an incandescent bulb.
- Before assembling your portable light, spread all parts out on a clean surface. Inspect each part for defects that may have occurred during shipping.

⚠ IMPORTANT: Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have occurred during shipping. If there is a defect in the wire, do not continue the assembly process.

⚠ CAUTION: CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS. If you have any non-electrical questions about this fixture, please call our Customer Service Team at 1-[800-388-6141](tel:800-388-6141) ext 216. Please reference the model and item numbers.

Warranty

THREE (3) YEAR WARRANTY

WHAT IS COVERED

WHAT IS NOT COVERED

The manufacturer warrants this fixture to be free from defects in materials and workmanship for a period of three (3) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alteration, neglect, or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear.

The manufacturer does not warrant and specifically disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of said product.

Contact the Customer Service Team at 1-[800-388-6141](tel:800-388-6141) ext 216 Eastern Time, Mon-Fri 9:30 am to 3:00 pm EST. For customer service support and the fastest response, please email us at CustomerSupport@DSILighting.com.


Pre-Installation

PLANNING INSTALLATION

- Read all instructions before installing.
- To avoid damaging this product, place it on a soft, non-abrasive surface, such as carpet or cardboard.

⚠ IMPORTANT: Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have occurred during shipping. If there is a defect in the wire, do not attempt installation. Please call Customer Service Team at 1-[800-388-6141](tel:800-388-6141) ext 216. For customer service support and the fastest response, please email us at CustomerSupport@DSILighting.com.

PACKAGE CONTENTS




NOTE: This product requires one 100W maximum medium base (E26) type “A” or 16W maximum medium base (E26) self-ballasted LED bulb (sold separately).

Part	Description	Quantity
A	Socket assembly	1
B	Socket ring (Pre-assembled on the socket of socket assembly)	1
C	Column 1	1
D	Column 2	2
E	Column 3	1
F	Base	1
G	Power cord	1
H	Top ring	1
I	Shade	1
J	Bottom ring	1

Installation

Attaching the column and the socket assembly


- Thread the socket assembly (A), the columns (C/D/E) and the base (F) together as shown. Hand-tighten until snug.
- As you thread the socket assembly (A), the columns (C/D/E) and the base (F) together, continuously pull the power cord (G) from the bottom of the base (F).



Assembling the shade

- Remove all plastic covering from the shade (I).

- Insert the top ring (H) into the three metal buckles (1) at the top of shade until secured.
- Insert the bottom ring (J) into the three metal buckles (1) at the bottom of shade until secured.
- Shade assembly is complete.




Attaching the shade and the light bulb

- Unscrew the socket ring (B) from the socket of the socket assembly (A).
- Place the shade assembly (2) over the socket and secure with the socket ring (B).
- Install the correct bulb (not included) referring to fixture markings and/or labels for maximum wattage.
- Adjust the shade assembly (2) to your desired location.
- Plug the power cord (G) into the outlet, turn on the switch and enjoy.



NOTE: Uses one 100W maximum medium base (E26) type

- “A” or 16W maximum medium base (E26) self-ballasted LED bulb (sold separately).



Care and Cleaning


- Use a dry, soft cloth to dust or wipe carefully.
- Do not clean with abrasive materials, bleach, or solvents.

Troubleshooting

Problem	Possible Cause	Solution
The light will not turn on.	The bulb is burned out.	Replace the light bulb.
	The power is off.	Ensure the power supply is turned on.
	The cord is not plugged in.	Ensure the cord is plugged into an outlet.
	The circuit breaker is off.	Ensure the circuit breaker is set in the “ON” position.
The fuse blows or the circuit breaker trips when the light is turned on.	There is an exposed wire.	Discontinue use of the lamp. Unplug the unit from the wall. Contact a qualified electrician or call Customer Care Service Team at 1- 800-388-6141 ext 216. For customer service support and the fastest response, please email us at CustomerSupport@DSILighting.com .

Service Parts

MODEL: HD39202A



Part	Description
A	Socket assembly
B	Socket ring (Pre-assembled on the socket of socket assembly (C))
C	Column 1
D	Column 2
E	Column 3
F	Base
G	Power cord
H	Top ring
I	Shade
J	Bottom ring

Questions, problems, missing parts? Before returning to the store,
call Design Solutions International Customer Service
Mon-Fri 9:30 am to 3:00 pm EST


1-[800-388-6141](tel:800-388-6141) ext. 216

For customer service support and the fastest response, please email us at

CustomerSupport@DSLighting.com

Retain this manual for future use.

Documents / Resources

	<p>DSI HD39202A Floor Lamp [pdf] User Guide HD39202A, HD39202A Floor Lamp, Floor Lamp, Lamp</p>
---	---

References

- [User Manual](#)

Manuals+. [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.