

[Home](#) » [Ducky](#) » **Ducky DKON2161ST One X Mini Wireless Redefining Analog Keyboard User Manual** 

## Contents [ [hide](#) ]

- [1 Ducky DKON2161ST One X Mini Wireless Redefining Analog Keyboard](#)
- [2 Product Information: Ducky One X Mini](#)
- [3 Fn Layout](#)
- [4 Fn Function](#)
- [5 Connection Function](#)
- [6 Ducky Software](#)
- [7 FAQ](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)



## Ducky DKON2161ST One X Mini Wireless Redefining Analog Keyboard



## Product Information: Ducky One X Mini

## **Specifications**

- Connection: Wireless 2.4 GHz dongle, Bluetooth
- Layout: Compact
- Fn Functions: Customizable
- Software: Ducky Software for customization



## **Ducky One X Mini**

### **Model Ducky One X Mini Wireless**

- Type: Mechanical Keyboard
- Switch: Inductive switches
- Keycap Material: PBT
- Printing Method: Double-Shot or Dye-Sublimation
- Origin of Production: China

### **60%**


- Size 310 x 125 x 40 mm
- Weight : 895g



For more information on the specs and details of our keyboards, please contact the distributor for your region.

## Fn Layout

The Fn layout allows for additional functions when used in combination with the Fn key.



## Fn Function

Fn +	Q	=	BT1 device
	W		BT2 device
	E		BT3 device
	R		BT4 device
	Enter		Minimize all windows and mute audio
	B		Hold to see battery status
	Left Win		Enable / Disable Left Windows Key Function
	Right Win		Enable / Disable Right Windows Key Function


- Hold to see battery status (1 lights up = 10%, 1+2 lights up = 20%, etc.)
- Hold both Win keys for five seconds for factory reset.

### Wireless 2.4G pairing method


After pressing and holding Fn+T for 5 seconds, the T light will flash faster. Re-plug and unplug the 2.4G receiver for pairing. After successful pairing, T will remain on.

## Connection Function

### Wired mode

- Switch the connection mode selector to the  mode
- Connect the keyboard to a PC using the included Type-C® cable

### 2.4 GHz mode

- Switch the connection mode selector to the  mode
- Connect the included 2.4 GHz wireless dongle to a PC

### BT mode

- Switch the connection mode selector to the **BT** mode
- Press Fn + Q/W/E/R to select the desired pairing host
- Press and hold FN + Q/W/E/R for three seconds to start pairing
- Turn on the BT connection on the device
- Follow the pairing instruction on the device
- Enter the pairing passkey on the keyboard when prompted

# Ducky Software



Note : For customization, please access the customization software at <http://duckyhub.io>

[www.duckychannel.com.tw](http://www.duckychannel.com.tw)

## FAQ


### • How do I customize the Fn functions on my Ducky One X Mini?

To customize Fn functions, use the Ducky Software available at [duckyhub.io](http://duckyhub.io). You can assign different actions to specific Fn key combinations.

### • Can I use the Ducky One X Mini wirelessly?

Yes, you can use the Ducky One X Mini wirelessly by connecting the included 2.4 GHz wireless dongle to your PC and following the pairing instructions.

## Documents / Resources

	<p><a href="#">Ducky DKON2161ST One X Mini Wireless Redefining Analog Keyboard [pdf]</a> User Manual</p> <p>DKON2161ST One X Mini Wireless Redefining Analog Keyboard, DKON2161ST, One X Mini Wireless Redefining Analog Keyboard, Wireless Redefining Analog Keyboard, Redefining Analog Keyboard, Analog Keyboard</p>
---	---

## References

- [User Manual](#)

📁 Ducky

💡 Analog Keyboard, DKON2161ST, DKON2161ST One X Mini Wireless Redefining Analog Keyboard Ducky, One X Mini Wireless Redefining Analog Keyboard, Redefining Analog Keyboard, Wireless Redefining Analog Keyboard

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.