



ECHOMASTER P-BUA-RANGER Wiring Harness for Backup Alarm Instruction Manual

[Home](#) » [Echomaster](#) » ECHOMASTER P-BUA-RANGER Wiring Harness for Backup Alarm Instruction Manual 

Contents

- [1 ECHOMASTER P-BUA-RANGER Wiring Harness for Backup Alarm](#)
- [2 WHAT'S INCLUDED](#)
- [3 COMPATIBLE ACCESSORIES](#)
- [4 TOOLS REQUIRED](#)
- [5 INSTALLATION](#)
- [6 Contact Information](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



ECHOMASTER P-BUA-RANGER Wiring Harness for Backup Alarm



Thank you for purchasing the **P-BUA-RANGER**

WHAT'S INCLUDED

- Vehicle Specific Wire Harness (P-BUA-RANGER)

COMPATIBLE ACCESSORIES

- 97dB Backup Alarm (BUA-97C)
- 97dB White Noise Backup Alarm (BUA-97WNC)

TOOLS REQUIRED



1. 10mm Nut-setter
2. Impact Drill
3. Diagonal Cutters

INSTALLATION

STEP 1:

Locate the OEM tail lamp connector that is on the outside of the driver-side frame rail



STEP 2:

Unplug the OEM connector and install the P-BUA-RANGER harness between the OEM connectors



STEP 3:

Route the harness over the top side of the frame rail, toward the center of the truck

STEP 4:

Use an impact drill and 10mm nut-setter to install a compatible backup alarm on the underside of the vehicle

Note: (2) 10mm TEK screws are provided with the compatible backup alarm

**STEP 5:**

Plug the backup alarm connector into the mating connector on the P-BUA-RANGER harness. Secure any excess wiring with cable ties. Use diagonal cutters to remove excess cable tie material.

STEP 6:

Test the backup alarm

Contact Information

Phone – 866-766-2267

E-Mail – support@aampglobal.com.

EchoMaster is a Power Brand of AAMP Global

EchoMaster.com.

Documents / Resources

[ECHOMASTER P-BUA-RANGER Wiring Harness for Backup Alarm](#) [pdf] Instruction Manual
P-BUA-RANGER Wiring Harness for Backup Alarm, P-BUA-RANGER, Wiring Harness for Backup Alarm, Backup Alarm

References

- [EchoMaster – Aftermarket Vehicle Safety Products for Consumer and Commercial Drivers](#)