



ecobee Smart Sensor For Windows and Doors Instruction Manual

[Home](#) » [Ecobee](#) » ecobee Smart Sensor For Windows and Doors Instruction Manual 

ecobee

Smart Sensor For Windows and Doors
Instruction Manual




Contents

- 1 Part of your home team
- 2 Open the ecobee mobile app to get started
- 3 Made for any door or window
- 4 Approvals
- 5 FCC Compliance Statement
- 6 RF Exposure Information:
- 7 Documents / Resources
 - 7.1 References

Part of your home team


SmartSensor fits seamlessly into the ecobee ecosystem of products to make your home work for you.



Open the ecobee mobile app to get started


Once you've opened the app, add your SmartSensor for doors and windows to begin setup. Find out more at ecobee.com/setup






Made for any door or window

The setup process in the ecobee mobile app will let you customize mounting for all types of doors or windows.



**Adhesive Back**

The adhesive back sticks firmly.
Be sure you have the right
placement before sticking the base
and magnet.

Align the bottom

Aligning the bottom of the magnet and
base ensures the most accurate
readings.

Motion Sensor


The motion sensor detects occupancy.

Base

Make sure the ecobee logo is right side up.

Magnet

You can place the magnet on either side
of the base.

**Approvals**

This product was designed and built in accordance to RoHS directive 2011/65/EC and contains no hazardous substances as defined by this directive.

FCC Compliance Statement

Compliance Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment.

RF Exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm during normal operation.

Innovation, Science and Economic Development Canada (ISED) | Compliance Notice:

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic

Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

RF Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

Model: EBDWC01 FCC ID: WR968118104116

IC: 7981A-68118104116

Warning: Changes or modifications not expressly approved by ecobee Inc. could void the user's authority to operate the equipment.

This product is not designed for use outdoors. Improper installation may void warranty. Not for children under 3 years.

Legal Notice


Use of the HomeKit™ logo means that an electronic accessory has been designed to connect specifically to iPod®, iPhone®, or iPad®, respectively, and has been certified by the developer to meet Apple® performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance. Apple, iPhone, iPad, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. HomeKit is a trademark of Apple Inc.



Warning: Choking hazard. Not for children under 3 years

ecobee

Documents / Resources



[ecobee Smart Sensor For Windows and Doors](#) [pdf] Instruction Manual
Smart Sensor For Windows and Doors, Sensor For Windows and Doors, Windows and Doors, Doors

References

- [e Installation](#)