



ELECOM EC-AC6365 Type-C Adapter User Manual

[Home](#) » [ELECO](#) » ELECOM EC-AC6365 Type-C Adapter User Manual 

Contents

- [1 ELECOM EC-AC6365 Type-C Adapter](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Connection diagram](#)
- [5 How to use](#)
- [6 Product specifications](#)
- [7 Precautions on use](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

ELECOM

ELECOM EC-AC6365 Type-C Adapter



Product Information

- **Product Name:** EC-AC6365 CW152 Adapter
- **Supported Connectors:** USB Type-C, Lightning, Micro-B
- **Compatible Devices:** Smartphones, tablets, PCs, game consoles

Product Specifications:

- **Port Shape:** USB Type-C
- **Dimensions:** Approximately 125 g /approximately 4.4 oz
- **Weight:** AC 100 V to 240 V, 50/60 Hz
- **Rated Input:** AC 100 V to 240 V, 50/60 Hz
- **Rated Output:** 65 W (5 V/3 A, 9 V/3 A, 15 V/3 A, 20 V/3.25 A) PPS: 60 W (5 V to 21 V/3 A) QC: 18 W (5 V/3 A, 9 V/2 A, 12 V/1.5 A)
- **Operating Temperature Range:** Not specified

Product Usage Instructions

1. Connect the charging cable to the EC-AC6365 CW152 Adapter.
2. Connect the other end of the charging cable to the device you want to charge.
3. Pull out the prongs from the adapter.
4. Plug the adapter into an electrical outlet.
5. The connected device will start charging.

Note: Make sure to use a compatible cable for your device. USB Type-C and Lightning connectors are recommended for optimal charging speed. Using connectors or cables that convert to other terminal types may result in slower charging or no charging at all.

Precautions on Use

WARNING:

- Stop using the product immediately if there is smoke, abnormal odors, noises, wetness, foreign matter or liquid entering the product, or if the cable, power plug, or case is damaged. Consult the store where you purchased the product.
- Do not touch the power plug or cable with wet hands.
- Do not connect this product to electrical outlets outside of Japan.
- Do not forcibly pull or bend the cable, and avoid placing heavy objects on it. Always hold the connector when plugging and unplugging the cable.
- Do not overload outlets.
- Do not attempt to disassemble or modify the product.
- Firmly push the power plug all the way into a household outlet.

CAUTION:


- Before using the product, check that there is no dust or liquid in the connectors of this device or the device to be connected. Charging when the connector is wet or has foreign matter may cause fires, electric shocks, or malfunctions.

Connection diagram



- To connect this product, prepare the cable separately according to the device to be used.
- Your device may charge slower or not charge at all if connectors or cables that convert to terminals other than USB Type-C and Lightning are used.

How to use




1. Connect the charging cable to this product and connect the other end to the device you want to charge.
2. Pull out the prongs and plug the adapter into an outlet to start charging.

Product specifications

Port shape	USB Type-C port ×1		
Dimensions	(Width) approximately 45.5 × (depth) approximately 36 × (height) approximately 42 mm (Width) approximately 1.8 × (depth) approximately 1.4 × (height) approximately 1.7 in.		
Weight	Approximately 125 g / approximately 4.4 oz		
Rated input	AC 100 V to 240 V, 50/60 Hz		
Rated output	65 W(5 V/3 A, 9 V/3 A, 15 V/3 A, 20 V/3.25 A) PPS : 60 W(5 V to 21 V/3 A) QC : 18 W(5 V/3 A, 9 V/2 A, 12 V/1.5 A)		
Operating temperature range	0 °C° to 25 °C / 32 °F to 77 °F	Package contents	Main unit

Ports and wattage



- This product's output may be suspended for safety purposes, depending on situations such as temperature rise. As this is not a malfunction, disconnect it from the connected device, wait a short while then connect again. These values are the performance values of this product. The actual output value may vary depending on conditions such as the connected device and its OS version. In certain cases, charging time may be slower or the device may not charge.
- The charging output varies according to the standards of the connected devices and the specifications of the cable. It is possible your device is unable to charge at maximum output.
- This product may operate under another standard that is not USB Power Delivery depending on the specifications and conditions of the connected device. The images are for illustration purposes only and may differ from your actual product.
 - The NINTENDO SWITCH™ cannot be used simultaneously with the Nintendo Switch dock.

NINTENDO SWITCH is a registered trademark of NINTENDO Co. Ltd. in Japan and other countries. Lightning is a trademark of Apple Inc., registered in the U.S. and other countries. USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

Precautions on use

Regarding pictograms

The instructions in this manual and labels on this product use various pictograms to ensure the safe and correct use of this product and to prevent harm to you and other people as well as damage to property. These icons and their definitions are as follows. Please fully understand this before reading the main text.

WARNING: Ignoring these precautions may lead to erroneous handling that may cause death or serious injuries.

CAUTION: Ignoring these precautions may lead to erroneous handling that may cause serious injuries or damages. Be sure to observe the following precautions in order to ensure safe and correct use.

WARNING

- **Stop** using the product immediately when smoke, abnormal odours or noises are coming from the product; when it is wet; when foreign matters or a liquid enters the product; when the cable, power plug, or case is damaged, and consult the store you purchased the product from. Doing otherwise may cause fire and electric shock.
- **Do not** touch the power plug or cable with wet hands. Doing so can cause a fire or electric shock.
- **Do not** connect this product to electrical outlets outside of Japan. It could cause fires.
- Firmly push the power plug all the way into a household outlet. A loose connection may result a fire or an electric shock.
- **Do not** forcibly pull or bend the cable, and do not place any heavy objects on it. Always hold the connector when plugging and unplugging the cable. It can cause armored cord damage, disconnection, and lead to a fire or electric shock.
- **Do not** overload outlets. Doing so can cause a fire.
- **Do not** attempt to disassemble or modify the product. Fire, electric shock or injuries may result.
- Before using this product, check that there is no dust or liquid in the connectors of this device or the device to be connected. Check for the presence of water, especially if the connected waterproof device is wet. Charging when the connector is wet or has foreign matter in it may cause fires, electric shocks, or malfunctions.
- When connecting a device to the product, make sure to follow the precautions for that device.
- **Do not** use or store the product in the following places. Fire, electric shock or malfunctions may result.
 - In direct sunlight
 - In areas of high temperature such as in proximity to heating devices
 - In areas of high humidity
 - In wet or damp places
 - In dusty environments
 - In places with high levels of vibration
- **Do not** use this device with incompatible charging cables. It will cause fire, melting, or malfunctions.
- This product is not waterproof. Please do not use nor store it in a wet environment. Rain, water spray, juice, coffee, steam, sweat and other liquids may cause a breakdown.
- If the product is not used for a long period of time, disconnect the product from the household outlet.
 - Malfunctions may occur otherwise.
- **Do not** drop the product, nor subject it to strong physical shocks. Do not place objects on it.

Compliance Status

www.elecom.co.jp/global/certification/

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

In order to make improvements to this product, the design and specifications are subject to change without prior

notice.

Trademark and name of the manufacturer: ELECOM CO., LTD. Fushimimachi 4-1-1, Chuo-ku, Osaka City
www.elecom.co.jp/global/

Responsible party

ELECOM USA, Inc. 4041 MacArthur Blvd Suite 400, Newport Beach, CA 92660 USA elecomusa.com

- In order to make improvements to this product and for improved safety, the design and specifications are subject to change without prior notice.
- The company and product names on the packaging are, in general, trademarks or registered trademarks of their respective companies.
- ELECOM CO., LTD. owns the copyright of this manual.
- Unauthorised copying and/or reproducing of all or part of this manual is prohibited.
- If you have any suggestions or doubts about this Manual, please contact your dealer.
- The specifications and appearance of this product may be changed without prior notice for product improvement purposes.
- When exporting this product, check the export regulations for the country of origin.

Global Support



<https://www.elecom.co.jp/r/s536>

A customer who purchases outside Japan should contact the local retailer in the country of purchase for inquiries. In “ELECOM CO., LTD. (Japan)”, no customer support is available for inquiries about purchases or usage in/from any countries other than Japan. Also, no foreign language other than Japanese is available. Replacements will be made under stipulation of the Elecom warranty.


Adapter Manual, Safety precautions, and Compliance with regulations 1st edition, September 1, 2023

ELECOM

©2023 ELECOM Co., Ltd. All Rights Reserved.

MSC-EC-AC6365_0208_ver.111

Documents / Resources



[ELECOM EC-AC6365 Type-C Adapter](#) [pdf] User Manual
EC-AC6365, CW152, EC-AC6365 Type-C Adapter, Type-C Adapter, Adapter

References

- [!\[\]\(fd4127b9e2af37bd6ea0fa06afa8e6d8_img.jpg\) ELECOM USA](#)
- [!\[\]\(3278d6283d12f18012b5aa7d40747611_img.jpg\) ELECOM GLOBAL](#)
- [!\[\]\(bb96b32142ec45f72f12316beae3ef61_img.jpg\)](#)

Manuals+.