


ELECROW ThinkNode-M1 Meshtastic Transceiver Device User Manual

[Home](#) » [ELECROW](#) » ELECROW ThinkNode-M1 Meshtastic Transceiver Device User Manual 

ELECROW ThinkNode-M1 Meshtastic Transceiver Device




Contents

- [1 Device Parts](#)
- [2 Quick Guide](#)
- [3 Precautions](#)
- [4 Main Specifications](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Device Parts

1. Lora Antenna
2. 1.54" EPD
3. Product Status LED
4. Buzzer
5. GPS/LoRa Status LED
6. Rotary Switch
7. GPS Switch
8. Function Button
9. Page Turn Button
10. Reset Button
11. Type-C Port: 5V/1A



Quick Guide

- **Rotary Switch:** Turn the power switch clockwise to turn on the device and adjust the backlight LED brightness level; turn it counterclockwise to turn off the power.
- **GPS Switch:** toggle to enable or disable GPS positioning function.
- **Function Button:**
 - Single Click:** Send a temporary ping to the network to report the device's location.
 - Double Click:** Turn the LED backlight on/off.
 - Triple Click:** Trigger an SOS alarm signal (three short, three long, three short), activate the buzzer, and make the indicator light blink.
 - Long Press:** Enter standby power-saving mode; (can be awakened by clicking any function key or pressing the switch key).
- **Page Turn Button:** Switch screen display pages by single click.
- **Reset button:** Click to restart/reboot the device.
- **Product Status LED:**
 - a. After the device is turned on normally, the red light stays on steadily.
 - b. The red light flashes rapidly to indicate charging status, and remains steady when fully charged
 - c. When the battery level is low, the red light will flash slowly.
- **GPS/LoRa Status LED:** GPS/LoRa working/data transmission status indication, blinking blue.

Precautions


- Avoid placing the product in damp or high-temperature areas.
- Do not disassemble, impact, crush, or throw the product into fire; do not use after submersion in water.
- If the product shows physical damage or severe swelling, do not continue to use it.
- Do not use an unsuitable power supply to power the device.

Main Specifications

Product Name	Think Node-M1
Dimensions	82*51.6*26.3mm (With out antenna)
Weight	81g
Screen	1.54” EPD
Type-C port	5V/1A
Battery Capacity	1200mAh

ThinkNode-M1

Documents / Resources

	<p>ELECROW ThinkNode-M1 Meshtastic Transceiver Device [pdf] User Manual</p> <p>ThinkNode-M1 Meshtastic Transceiver Device, ThinkNode-M1, Meshtastic Transceiver Device, Transceiver Device, Device</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.