

ELECTRON E0068 Interactive Digital Signage Android Tablet User Manual

Home » ELECTRON » ELECTRON E0068 Interactive Digital Signage Android Tablet User Manual



Contents

- 1 ELECTRON E0068 Interactive Digital Signage Android
- **Tablet**
- 2 Specifications
- 3 Package Contents
- 4 Features
- **5 Product Dimension**
- 6 Powering On
- 7 Camera Usage
- **8 Connectivity**
- 9 FAQs
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

Electron

ELECTRON E0068 Interactive Digital Signage Android Tablet



Important Notices Copyright Information

All intellectual property rights in this publication are owned by and protected by applicable copyright laws and international treaty provisions. Retains all rights not expressly granted. No part of this publication may be reproduced in any form whatsoever or used to make any derivative work without prior written approval. Reserves the right to revise this publication, and/or make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time without prior notice. The information in this document is provided in good faith, but without any representation or warranty whatsoever, whether it is accurate, r complete, or otherwise, and on the express understanding that shall have no liability whatsoever to other parties in any way arising from or relating to the information or its use. All other trademarks are the property of their respective owners. Other company and brand products and service names are trademarks or registered trademarks of their respective holders. This device complies with CE and FCC regulations.

- 1. Do not push objects into holes and ventilation slots.
- 2. Do not expose this product to moisture or place any objects filled with liquids on or near the product.
- 3. Do not place a naked flame source, such as a lighted candle, on or near this product.
- 4. Do not store or operate the device in environments where the temperature is above 50 degrees Celsius or below -10 degrees Celsius.
- 5. Do not intentionally hit the device or place heavy or sharp objects on the device.
- 6. Only use accessories specified by the manufacturer.
- 7. Keep the device away from benzene, diluents, and other chemicals.
- 8. Do not attempt to repair this product yourself. Always use a qualified se vice agent to perform adjustments or repairs.

Specifications


• Dimensions: 212.20mm x 173.22mm x 147.61mm

· Weight: 80g


• Features: Camera, USB 2.0 host, DC in power supply port, 3.5mm audio jack, Micro USB OTG, RJ45 with POE, Power key, VESA 75x75mm

Package Contents

Please make sure all of the following are present when you unpack your Interactive Digital Signage.



Android Tablet



Power adapter




User manual


Features

- 8"LCD IPS panel
- Resolution 1280*800
- RK3288 Quad core cortex A17 / RK3568/RK3566 Quad core cortex A55
- 2GB, Optional 4GB (RK3568/RK3566)
- Internal memory 16G, Optional 32GB/64GB RK3568/RK3566
- Android 8.1/10.0(RK3288) / Android 11(RK3568/RK3566)
- 5-Point capacitive touch
- 2.0M/P,front camera(RK3288) / 5.0M/P,front camera(RK3568/RK3566)
- RJ45 Ethernet (Standard POE IEEE802.3at,POE+,class 4 25.5W)
- POE IEEE802.3at
- Wi-Fi 802.11b/g/n/a/ac/ax
- Bluetooth 4.2
- 2*1.5W Speaker
- USB Host*2
- Micro USB OTG
- VESA 75x75mm
- Adapter,12V/1.5A

Product Dimension



Exterior Components



No	Function	No	Function
1	Camera	6	USB 2.0 host
2	DC in power supply port	7	USB 2.0 host
3	3.5mm audio jack	8	Power key
4	Micro USB OTG	9	VESA 75x75mm
5	RJ45-with POE		

Powering On

Connect the power adapter to the DC in the power supply port on the Android Tablet and plug it into a power source. Press the Power key to turn on the device.

Camera Usage

Locate the camera on the device and use it for capturing photos or videos as needed.

Connectivity

Use the USB 2.0 host ports for connecting external devices such as a keyboard or mouse. The Micro USB OTG port can be used for data transfer between devices.

Audio Output

Plug in headphones or speakers into the 3.5mm audio jack for audio output.

Mounting

The device supports VESA 75x75mm mounting for easy installation in various settings.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

Disposable



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed of at the end of its life separately from your household waste. There are separate collection systems for recycling in your country. For more information, please contact the local authority or the retailer where you purchased the product.

FAQs

1. Q: What should I do if the device does not power on?

A: Ensure that the power adapter is properly connected to the device and the power source. Try using a different power outlet to rule out any issues with the current one.

2. Q: How can I dispose of the product at the end of its life?

A: The symbol on the product indicates that it should be disposed of separately from household waste. Contact your local authority or retailer for information on recycling options in your area.

Documents / Resources



ELECTRON E0068 Interactive Digital Signage Android Tablet [pdf] User Manual E0068, E0068 Interactive Digital Signage Android Tablet, Interactive Digital Signage Android Tablet, Digital Signage Android Tablet, Tablet

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.