

 Element
Biosciences
**Element
Biosciences
Cloudbreak
Sequencing
Kits**



Element Biosciences Cloudbreak Sequencing Kits User Guide

[Home](#) » [Element Biosciences](#) » **Element Biosciences Cloudbreak Sequencing Kits User Guide** 

Contents

- [1 Element Biosciences Cloudbreak Sequencing Kits](#)
- [2 Overview](#)
- [3 Input Recommendations](#)
- [4 Cloudbreak Workflow Summary](#)
- [5 Run Preparation](#)
- [6 Dilute Library and Custom Primers](#)
- [7 Run Setup](#)
- [8 Confirm Reagent Preparation](#)
- [9 Troubleshooting](#)
- [10 Cloudbreak Consumables](#)
- [11 Document History](#)
- [12 FAQ](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)
- [14 Related Posts](#)



Element Biosciences Cloudbreak Sequencing Kits



Overview

The Cloudbreak sequencing workflow uses a Cloudbreak Freestyle, Cloudbreak, or Cloudbreak Ultra kit to sequence DNA libraries on an AVITI System or an AVITI24 System.

- Cloudbreak Freestyle—Provides multiple read lengths and output options to meet a diversity of applications. Cloudbreak Freestyle kits enable direct loading of linear libraries without library conversion, including third-party libraries.
- Cloudbreak—Provides the same read length and output options as Cloudbreak Freestyle with potential requirements for library circularization.
- Cloudbreak UltraQ—Provides high-quality Q40 and Q50 data for highly sensitive assays.


All Cloudbreak kits are designed for minimal waste and easy disposal. Reagent overage supports the extra cycles that index sequences and unique molecular identifiers (UMIs) need to identify samples with high confidence. For a list of kit configurations and catalog numbers, see Cloudbreak Sequencing Kits on page 23. Cloudbreak kits are compatible with a variety of library preparation workflows. For more information on compatibility, see the Product Compatibility page on the Element website.

Sequencing Run Stages

AVITI Operating Software (AVITI OS) generates a recipe based on the run parameters entered during run setup. The recipe governs each stage of a run. A run is complete when the recipe is executed and primary analysis is finished. The following stages comprise a sequencing run:

- Amplification and pollination—Hybridizes the library to the flow cell and performs amplification to form colonies, each containing multiple copies of the same sequence from the library.
- Sequencing—Performs each read in the run, including imaging and primary analysis.
- Post-run wash—Automatically flushes buffer from the sequencing cartridge through the fluidic system to

remove salts and residual library.



Reads in a Sequencing Run

Up to four reads comprise a sequencing run: Index 1, Index 2, Read 1, and Read 2.

- Index reads—A run can include one, two, or no index reads.
 - Index 1 sequences the Index 1 sequence.
 - Index 2 sequences the Index 2 sequence.
 - A dual-index run sequences Index 1 and Index 2.
- Read 1 and Read 2—All runs must have a Read 1.
 - Read 1 sequences the forward strand of the DNA insert.
 - Read 2 sequences the reverse strand.
 - A paired-end run sequences Read 1 and Read 2, including a paired-end turn before Read 2 to generate the complementary strand.

Number of Cycles

Read length is the total number of cycles performed in a run. The optimal number of cycles and how to distribute the total cycles depends on your experiment. For bioinformatics purposes, adding one extra cycle to each read is recommended. For example, a 2 x 150 cycle run ideally includes 2 x 151 cycles. The additional cycle improves the accuracy of the Q score for the 150th cycle.

The software and chemistry used for the run prescribe a minimum number of cycles. Read 1 requires at least five cycles and at least 25 cycles to generate all run metrics. The maximum number of cycles depends on the kit:

- A 2 x 75 kit performs up to 184 cycles, supporting one 2 x 76 run with indexing and unique molecular identifiers (UMIs).
- A 2 x 150 kit performs up to 334 cycles, supporting one 2 x 151 run with indexing and UMIs.
- A 2 x 300 kit performs up to 634 cycles, supporting one 2 x 301 run with indexing and UMIs.

Library Considerations

Some libraries have special considerations for sequencing. Make sure to follow the applicable requirements for your library.

Low-Diversity Amplicon Libraries

For low-diversity, high-multiplex libraries, such as a 16S amplicon library, Element recommends that you enable the Low-Diversity High-Multiplex setting during run setup. This setting requires a library pool that meets the following requirements:

- Adept™ libraries or third-party libraries
- High plexity of ≥ 64 unique dual indexed (UDI) libraries
- A 1–5% spike-in of PhiX Control Library

CAUTION

Exceeding a 5% spike-in can reduce the index diversity of the pool, leading to a reduction in quality.

Bead-Based Normalization

PCR is required when sequencing a library pool that has undergone the bead-based normalization protocol. Before diluting to the target loading concentration, use amplification and Qubit kits to amplify and quantify the library pool.

- For Cloudbreak chemistry with Adept libraries, use the Adept Rapid PCR-Plus Kit for amplification.
- For Cloudbreak Freestyle chemistry with third-party libraries, use the KAPA HiFi HotStart Library Amplification Kit with Primer Mix. Follow manufacturer instructions.

Short Insert or Long Insert Libraries

Sequencing short insert or long insert libraries require that you specify the preloaded custom recipe during run setup.

Short insert libraries

If you are using Cloudbreak Freestyle chemistry and libraries with < 100 bp inserts, the short insert recipe is required. For libraries with 100–300 bp inserts, the short insert recipe is recommended. The short insert recipe is compatible with 2 x 75 and 2 x 150 kits.

Long insert libraries

If you are using Cloudbreak or Cloudbreak Freestyle chemistry and libraries with > 750 bp DNA inserts, the long insert recipe is required. The long insert recipe is compatible with 2 x 75 and 2 x 150 kits. Using a 2 x 300 kit accounts for long insert conditions.

Input Recommendations

The recommended input for sequencing is ≥ 1 nM library. The input library is normalized to 1 nM, denatured into single strands, and diluted to the target loading concentration. When starting with a 0.2–1 nM library, the library is denatured and diluted but not normalized. Library pools that start at < 0.2 nM are not supported.

PhiX Control Library Spike-In

For most applications, Element recommends a spike-in of PhiX Control Library. The following recommendations for spike-in percentages optimize the benefits of PhiX Control Library for specific experiments.

Experiment Spike-In (%)

- QC and error rate reporting > 2
- Low-complexity indexing (≤ 2 -plex) > 2
- Libraries that use Low-Diversity High-Multiplex setting 1–5
- Other low-diversity libraries* ≥ 5

* For Adept and third-party workflows, the first four cycles of Read 1 require high diversity. Index 1 includes high diversity for Elevate™ workflows.

Custom Primers

You can sequence any combination of I1, I2, R1, and R2 custom primers for third-party libraries with Cloudbreak Freestyle chemistry and Adept libraries with Cloudbreak chemistry. The custom primers must be HPLC-purified and prepared using the applicable method:

- Spike-in—Spike-in custom primers into the Cloudbreak Freestyle cartridge or the Adept Primer Set Cloudbreak tubes.

- Replacement—Replace the primers in the cartridge with buffer tubes from the Custom Primer Set Cloudbreak Freestyle or Adept Custom Primer Set Cloudbreak and add custom primers.

Sequencing Primer Compatibility

- For Cloudbreak Freestyle chemistry, Element oligonucleotides include sequencing primers that are compatible with standard Nextera, TruSeq, and small RNA libraries.
- For original Cloudbreak chemistry, sequencing primers are only compatible with standard Nextera and TruSeq libraries.
- Libraries with sequencing primer binding sites that do not meet these requirements must use custom primers.

Custom primers require special consideration and planning. To determine if your library requires custom primers and ensure a run with custom primers meets specifications, contact Element Technical Support early in experiment planning. For more information on Cloudbreak Freestyle custom primer recommendations, see [Cloudbreak Freestyle Compatibility with Third-Party Libraries](#).

Loading Concentration

Use the following recommendations as a starting point to determine your optimal loading concentration. Note the following considerations:

- The recommendations are based on libraries prepared for Element and depend on your chemistry, kit size, library prep workflow, and other lab-specific factors. Some libraries require a higher or lower concentration than the indicated ranges.
- Library size refers to the full length of the library, including the DNA insert and adapters.
- If you are sequencing pooled libraries, the pool must contain libraries with similar size distributions.

Cloudbreak Chemistry, 2 x 75 and 2 x 150 Kits

Average Library Size	Adept v1.1	Adept Rapid PCR-Plus	Elevate PCR-Free	Elevate PCR-Plus
Small (250–450 bp)	4–6 pM	10–14 pM	6–10 pM	8–11 pM
Medium (450–700 bp)	6–10 pM	10–14 pM	7–11 pM	9–12 pM
Large (≥ 700 bp)	10–14 pM	10–14 pM	7–11 pM	9–12 pM
Cloudbreak Chemistry, 2 x 300 Kits				
Average Library Size	Adept v1.1	Adept Rapid PCR-Plus	Elevate PCR-Free	Elevate PCR-Plus
Medium (450–700 bp)	4–6 pM	5–8 pM	3–5 pM	4–6 pM
Large (≥ 700 bp)	6–8 pM	5–8 pM	3–5 pM	4–6 pM
Cloudbreak Freestyle Chemistry, 2 x 75 and 2 x 150 Kits				
Average Library Size	Elevate PCR-Free	Elevate PCR-Plus	Third Party PCR-Free	Third Party PCR-Plus
Small (250–450 bp)	5–9 pM	7–10 pM	6–9 pM	7–10 pM
Medium (450–700 bp)	6–10 pM	8–11 pM	7–10 pM	9–12 pM
Large (≥ 700 bp)	6–10 pM	8–11 pM	7–10 pM	9–12 pM
Cloudbreak Freestyle Chemistry, 2 x 300 Kits				
Average Library Size	Elevate PCR-Free	Elevate PCR-Plus	Third Party PCR-Plus	Third Party PCR-Free
Medium (450–700 bp)	3–5 pM	4–8 pM	6–9 pM	4–6 pM
Large (≥ 700 bp)	3–5 pM	4–8 pM	8–12 pM	4–6 pM

Cloudbreak UltraQ Chemistry, 2 x 150 Kit

Average Library Size Elevate Libraries

- 450–550 bp 5–6 pM

Target Polony Counts

The target total polony counts associated with the loading concentration recommendations depend on your kit chemistry, output level, and size. The polony count increases as the loading concentration increases, which can compromise data quality. Low polony counts promote high data quality but lower the amount of data output.

Cloudbreak and Cloudbreak Freestyle Chemistry

Output Level	Kit Size	Target Read Counts	Output (Gb)
High	2 x 75	1 billion	150
	2 x 150	1 billion	300
	2 x 300	300 million	180
Medium	2 x 75	500 million	75
	2 x 150	500 million	150
	2 x 300	100 million	60
Low	2 x 75*	100 million	15
	2 x 150	250 million	75
* Available as Cloudbreak Freestyle chemistry only Cloudbreak UltraQ Chemistry			
Output Level	Kit Size	Target Read Counts	Output (Gb)
High	2 x 150	800 million	240

Cloudbreak Workflow Summary

Performing a Cloudbreak sequencing run includes steps to prepare reagents and dilute the library to the appropriate volume and concentration for sequencing. For more information, see Loading Concentration on page 7.

Prepare for the Run

- 1 Add primers, if applicable for Adept libraries
- 2 Thaw the reagent cartridge
- 3 Dilute and denature libraries
- 3 Prepare custom primers (optional)

Set Up the Run

- 4 Define run parameters
- 5 Add custom primers (optional)
- 6 Add library to cartridge
- 5 Load the reagent cartridge and buffer bottle
- 6 Empty waste and prime reagents
- 9 Load the flow cell
- 10 Review, start, and monitor the run

Run Preparation

Run preparation includes adding appropriate primers, if applicable, and thawing the sequencing cartridge. The subsequent dilution procedure includes the option to store a normalized library. If you intend to store a library, do not prepare the cartridge until you are ready to sequence. Prepare the cartridge within a day of sequencing.


Add Primer Tubes

1. If you are using a Cloudbreak Freestyle sequencing kit without custom primers or you are sequencing Elevate libraries, skip the following steps and proceed to Thaw Reagents on page 10.
2. Remove a cartridge and applicable primer set from -25°C to -15°C storage.

Chemistry and Library	Primer Strategy	Primer Set
Cloudbreak, Adept	No custom primers	Adept Primer Set Cloudbreak
	Custom primers (spike-in method)	Adept Primer Set Cloudbreak
	Custom primers (replacement method)	Adept Custom Primer Set Cloudbreak
Cloudbreak Freestyle, Third Party	Custom primers	Custom Primer Set Cloudbreak Freestyle

3. Twist the primer tubes in wells labeled I1, I2, R1, and R2 toward the left to unlock.

4.



Remove the primer tubes from the cartridge and discard per the SDS.

If you have trouble removing the tubes, peel the labels off and twist the tubes as you push upwards.


5. Insert the tubes from the primer set into the vacated wells. Match the abbreviation on the tube label to the well label.

6. Twist each tube right until it locks into place.

Thaw Reagents

1. If the cartridge includes a shipping cover, remove the shipping cover:

- While supporting the cartridge, lift the removal tab at the left corner until it releases from the cartridge.



- Moving across the front edge of the shipping cover, repeatedly lift the edge until the cover is fully released.
- Pull to remove the remainder of the shipping cover from the cartridge.

2. Thaw the sequencing cartridge. Protect the cartridge from light until loading onto the instrument.

Cartridge	Room Temperature Water Bath	Refrigerator
2 x 75	90 minutes	8 hours
2 x 150, 2 x 300	2.5 hours	24 hours

3. Make sure reagents are fully thawed. Inspect each well as reagents thaw at varying rates.
4. If any ice remains, continue thawing.
5. Set aside the thawed cartridge at room temperature. If not immediately initiating the run, place the thawed cartridge at 2°C to 8°C. Do not exceed 3 hours.
6. Proceed to Run Setup on page 13.

Dilute Library and Custom Primers

The library dilution procedures prepare 1.4 ml diluted library at the target loading concentration with an optional spike-in. Custom primers are diluted as applicable. If you are using the Individually Addressable Lanes add-on, follow the applicable procedures for both libraries. Both libraries use the same denature and dilution methods, resulting in a total volume of 1.4 ml for each library.

Prepare the Library

For bead-normalized libraries, perform amplification and quantification before proceeding. See Bead-Based Normalization on page 5.

1. Gather the following consumables:

- 0.2 M Tris-HCl buffer, pH 7.0
- 1 N NaOH
- 2 ml DNA LoBind tubes (4–7)
- 10 mM Tris-HCl, pH 8.0 with 0.1 mM EDTA (low TE buffer)
- Nuclease-free water

2. Combine the following reagents to prepare 0.2 N NaOH. Use 0.2 N NaOH within the day and discard.

Reagent Volume

- 1 N NaOH 20 µl
- Nuclease-free water 80 µl
- Total 100 µl

3. Remove the following components from -25°C to -15°C storage and thaw on ice:
 - Library Loading Buffer
 - Experimental library
 - [Optional] PhiX Control Library
4. Pulse vortex the thawed libraries and briefly centrifuge.
5. If the experimental library is ≥ 1 nM, normalize:
 - In a new DNA LoBind tube, use low TE buffer to dilute the library to 1 nM.
 - Proceed immediately or cap the tube, store the 1 nM library at -25°C to -15°, and sequence within the allotted time.

Denature the Library with NaOH

1. Calculate the loading concentration of each library, experimental and control, based on the target loading concentration and relative amount of each library:
 loading concentration in pM = target loading concentration in pM * library amount in %
 - For example, if the target loading concentration is 9 pM with a 2% spike-in: the experimental library concentration is 8.82 pM (9 pM * 98%) and the control library concentration is 0.18 pM (9 pM * 2%).—

NOTE

The experimental and control library concentrations do not need to match.
2. Calculate the experimental library volume based on the calculated loading concentration and a 1.4 ml loading volume: library volume in μ l = (library loading concentration in pM * 1400 μ l)/library starting concentration in pM
 - Continuing the preceding example and assuming a 1 nM starting concentration, the library volume is 12.3 μ l: (8.82 pM * 1400 μ l)/1000 pM.—
3. If you are adding a spike-in, calculate the control library volume based on the loading concentration and a 1.4 ml loading volume: control library volume in μ l = (control library loading concentration in pM * 1400 μ l)/control library concentration in pM
 - Continuing the preceding example and assuming a 1 nM PhiX Control Library, the control library volume is 0.25 μ l: (0.18 pM * 1400 μ l)/1000 pM.—
4. If step 3 calculated a volume < 1 μ l, dilute PhiX Control Library in low TE buffer to use a volume ≥ 1 μ l for accurate pipetting.
5. Record the total volume of diluted sequencing library (experimental and control) in μ l.
 - This procedure uses equal volumes of library, 0.2 N NaOH, and 0.2 M Tris-HCl buffer, pH 7.0. Therefore, the volume recorded at this step is used in two subsequent steps.—
6. Combine the library volumes calculated in steps 2 and 3 in a new DNA LoBind tube.
7. Add an equal volume of freshly prepared 0.2 N NaOH.
8. Vortex the tube to mix and briefly centrifuge.
9. Incubate the tube at room temperature for 5 minutes to denature the library.
10. Vortex the tube to mix and briefly centrifuge.
11. Add 0.2 M Tris-HCl buffer, pH 7.0 at an equal volume of 0.2 N NaOH to neutralize the reaction.
12. Vortex the tube to mix and briefly centrifuge.
 - The library is denatured, neutralized, and at 1/3 the input concentration in 3x input volume.—
13. Add a sufficient volume of Library Loading Buffer to reach a total volume of 1.4 ml: buffer volume in μ l = 1400 μ l – 3 * library volume in μ l
14. Vortex the tube to mix and briefly centrifuge.

15. Place the diluted sequencing library on ice. Use within the day.

Prepare Custom Primers

1. If you are not using custom primers, skip the following steps and proceed to Run Setup on page 13.
2. In a new DNA LoBind tube, prepare each applicable custom primer using low TE buffer:

Custom Primer	Volume	Concentration
Index 1	19 µl	100 µM
Index 2	19 µl	100 µM
Read 1	32.4 µl	100 µM
Read 2	19 µl	100 µM

3. Set aside the 100 µM custom primers on ice. Use within the day.

Run Setup

Run setup for sequencing prompts you to define run parameters, load sequencing consumables, and empty the waste bottle. Before initiating a run, review the overview, software, troubleshooting, and safety information in the user guide for your instrument.

Initiate a Sequencing Run

1. Gather the following materials:
 - Buffer bottle
 - Cartridge
 - Cartridge basket
 - Towel or wipe
 - Used flow cell
2. A used flow cell might already be present on the instrument.—
 - If applicable, stage run manifests for import:
 - If setting up the run manually, save the manifest on a USB and connect the USB drive to an instrument USB port.
 - Alternatively, you can save the manifest to the specified SMB storage connection.
 - If you planned the run in ElemBio Cloud, upload the manifest to the planned run.
3. On the Home screen, select New Run.
4. If AVITI OS prompts that the flow cell is missing, load a used flow cell:
 - Select Open Nest.
 - Place the used flow cell onto the nest and close the lid.
 - Select Close Nest.
5. Select Sequencing.
6. Select the side for sequencing:
 - Side A—Set up a run on side A.

- Both—Set up runs on sides A and B.
 - Side B—Set up a run on side B.
7. For chemistry type, select Cloudbreak, and then select Next.
 8. Proceed as follows:
 - For a planned run created in ElemBio Cloud, proceed to Select a Planned Run.
 - For a manual run, proceed to Define Manual Run Parameters on page 14.

Select a Planned Run

1. Select Planned Run.

AVITI OS displays a list of compatible planned runs for the instrument and run type. For more information on planned run compatibility, see Run Planning in the Online Help.
2. Select the run you want to use from the list of planned runs.
3. Review the run parameter fields to make sure they are correct.

If you need to edit a planned run, modify it in ElemBio Cloud. For more information, see Run Planning in the Online Help.
4. In the Storage drop-down menu, select the storage location for the run.
5. Select Next to proceed to the Prepare Reagents or the Run Side B screen.
 - After you proceed, the selected planned run becomes unavailable for other connected instruments.
 - If you exit run setup before priming, the run returns to the list of available planned runs.
6. If applicable, repeat steps 2–5 to set up a dual start run with a second planned run.
7. Proceed to Inspect and Mix Reagents on page 15.

Define Manual Run Parameters

1. Make sure Manual Run is selected for the type of run.
2. In the Run Name field, enter a unique name to identify the run.
 - The field accepts 1–64 alphanumeric characters, hyphens (-), and underscores (_).—
3. If applicable, select Browse and import the run manifest.

[Optional] In the Description field, enter a description that represents the run.
4. The field accepts ≤ 500 alphanumeric characters, hyphens, underscores, spaces, and periods (.).—
5. In the Storage drop-down menu, select a storage location:
 - To output run data to the default storage location, leave the default selection.
 - To override the default storage location for the current run, select a storage connection.
6. Select a Library Type:
 - Elevate—Sequence libraries prepared with Elevate indexes and adapters.
 - Adept—Sequence libraries prepared with the Adept Workflow. Only compatible with Cloudbreak sequencing kits.
 - Third Party—Sequence libraries prepared with a third-party workflow. Only compatible with Cloudbreak Freestyle sequencing kits.
7. If applicable, select a Library Structure:
 - Circular—Sequence libraries that complete circularization before loading.
 - Linear—Sequence libraries prepared for on-instrument circularization.
8. In the Sequencing Kit drop-down menu, select the kit you are using. For information on kit compatibility, see the

Product Compatibility page on the Element website.

- The kits listed depend on compatibility with the instrument type, and the selected library type and library structure.—
9. If you are using the Adept or Third Party library type, select a Low-Diversity High-Multiplex option.
 - Yes—Sequence low-diversity high-multiplex libraries. This option requires at least 4 cycles for Index 1.
 - No—Sequence other libraries.
 10. If you are using the Individually Addressable Lanes add-on and a compatible sequencing kit, select the number of library pools.
 11. In the Cycles fields, enter the number of cycles to perform in each read.
 - Do not exceed the maximum number of cycles for the sequencing kit. See Number of Cycles on page 5.
 - Add one cycle to the desired number of Read 1 and Read 2 cycles. For example, enter 151 in the Read 1 field to perform 150 cycles in Read 1.
 - To skip a read, enter 0.
 - See the following table for minimum and default cycle values. Aside from the minimum cycle limitations, AVITI OS lets you distribute the available cycles among reads as necessary.

Library Type	Kit Size	Minimum Values				Default Values			
		Index 1	Index 2	Read 1	Read 2	Index 1	Index 2	Read 1	Read 2
Adept or	2 x 75	0	0	5	0	Blank	Blank	76	76
Third Party	2 x 150	0	0	5	0	Blank	Blank	151	151
	2 x 300	0	0	5	0	Blank	Blank	301	301
Elevate	2 x 75	4	0	5	0	12	9	76	76
	2 x 150	4	0	5	0	12	9	151	151
	2 x 300	4	0	5	0	12	9	301	301

12. If you are using the Advanced Run Settings, select Advanced Settings and proceed to Configure Advanced Run Settings.
13. Select Next to proceed to the Run Side B or Prepare Reagents screen.
14. If applicable, repeat steps 2–13 to set up a dual start run.

Configure Advanced Run Settings

Use Advanced Run Settings to modify primary analysis and recipe configurations for a run. Available settings depend on kit compatibility. Some settings require the activation of an add-on. For more information, see the Advanced Run Settings and Add-On information in the user guide for your instrument.

1. If you are using the Polony Density setting, select a Polony Density option.
 - Standard—Uses the standard read output.
 - High Density—Increases the read output.

- If you are using the Filter Mask setting, enter a base mask to use for filtering.
 - Use the base mask format. For more information, see Base Masks in the Online Help.
 - If you do not use the Filter Mask setting, the default filter mask is R1:Y15N*-R2:Y15N*.
- If you are using the Custom Recipes setting, import the custom recipe file from preloaded recipes or a USB drive:
 - Select Browse.
 - Select Element Recipes for preloaded recipes or USB to upload from a connected USB drive.
 - Select the recipe file, and then select Open.
- If you are using the PMG Shift setting, enter the number of cycles to skip.
You cannot skip more than 20 cycles. The number of skipped cycles reduces the maximum number of cycles AVITI OS allows for the run.
- Select Next to proceed.

Inspect and Mix Reagents

- Inspect each cartridge well to make sure reagents are fully thawed.
- Make sure the cartridge contains the appropriate primers.
- Make sure the tubes in the I1, I2, R1, and R2 wells are secure. If necessary, twist each tube to the right.
- Gently invert the cartridge 10 times to mix reagents.

CAUTION

Inadequately mixed reagents can cause run failure.

- Tap the cartridge base on the benchtop to remove any large droplets from the tube tops.
- Inspect the small tubes to make sure reagents are settled at the bottom.
- Place the cartridge into a clean cartridge basket and lock the clips. Wipe any excess moisture.

Add Custom Primers to the Cartridge


- If you are not using custom primers, skip the following steps and proceed to Add Library to the Cartridge.
- Using a new 1 ml pipette tip, pierce the center of the applicable I1, I2, R1, and R2 wells to create one hole.
Push the foil to the edges.
- Discard the pipette tip.
- Add the applicable volume of 100 μ M custom primer to each pierced well.

Custom Primer	Volume	Well
Index 1	19 μ l	I1
Index 2	19 μ l	I2
Read 1	32.4 μ l	R1
Read 2	19 μ l	R2

- The final concentration of each custom primer is 1 μ M.
- Pipette the content of each tube 15 times to mix. Avoid losing existing primer volume.

Add Library to the Cartridge

1. Using a new 1 ml pipette tip, pierce the center of the Library well to create one hole. Push the foil to the edges.



2. Discard the pipette tip.
 3. Briefly centrifuge the diluted sequencing library to remove bubbles and foam from the tube lid.
 4. Transfer the entire volume of diluted sequencing library to the Library well, dispensing along the well wall.
 - Avoid aspirating any foam or dispensing air.
 - Do not allow the library to contact the foil.
 - Make sure the tube contains ≥ 1.3 ml diluted sequencing library.
 5. If you are using the Individually Addressable Lanes add-on, repeat steps 1–4 with the AUX well and the second library.
 - The library for the AUX well contains the samples for Lane 2 in the run manifest.—
- CAUTION**
- Transferring a library to the AUX well of an incompatible cartridge damages the library and the cartridge. For more information on Individually Addressable Lanes add-on compatibility, see the user guide for your instrument.
6. Inspect the Library well through the window at the front of the basket.
 - Make sure the library is free of foam and that bubbles are minimal.
 - If an air gap appears below the surface, use a new pipette tip to remove it.
 7. If the cartridge include shipping locks, twist each shipping lock left to unlock and remove them from the cartridge lid.

Confirm Reagent Preparation

1. If you selected Adept, select the Swap primer tubes checkbox to confirm that the I1, I2, R1, and R2 wells contain Adept primers or custom primers.
2. Select the Invert cartridge checkbox to confirm that reagents are mixed.
3. Select the Insert into basket checkbox to confirm that the cartridge is in the cartridge basket.
4. Select any load library checkboxes to confirm that the cartridge contains diluted library.
5. Select Next to proceed to the Load Reagents screen.

Load Reagents and Buffer

1. Open the reagent bay door.
2. Remove any materials from the reagent bay and set aside.
3. Slide the basket containing the thawed cartridge into the reagent bay until it stops.
4. Support the buffer bottle with both hands and slide it into the reagent bay until it stops.
5. Close the reagent bay door, and then select Next to proceed.

Empty Waste and Prime Reagents

1. Open the waste bay door.
2. Unscrew the transport cap from the cap holder above the waste bay.
3. Remove the waste bottle from the waste bay and close the transport cap.

CAUTION

Waste bottle contents are considered hazardous. Dispose of waste according to local, state, and regional laws and regulations.

4. [Optional] Insert a funnel into a waste receptacle. Make sure the funnel is secure.
5. Open the transport cap and the vent cap.
6. Support the waste bottle with both hands and empty the waste:
 - Position the bottle over the funnel or waste receptacle.
 - If you inserted a funnel, align the handle to the inner edge of the funnel.
 - If you did not insert a funnel, center the handle over the waste receptacle.
 - Tip the bottle forward and drain. Invert the bottle and shake to expel all droplets.
 - If necessary, wipe liquid off the bottle.
7. Close the vent cap and return the empty waste bottle to the waste bay.
8. Screw the transport cap onto the cap holder and close the waste bay door.

NOTE

Before priming, you can discard run setup and save the cartridge. Priming pierces reagent seals and prevents further use.

9. Select Next to automatically start priming.
10. During priming, which takes ~15 minutes, bring a new Cloudbreak flow cell to room temperature:
 - Remove a flow cell pouch from 2°C to 8°C storage. Do not open the pouch.
 - Set aside the pouch for ≥ 5 minutes.
11. When priming is complete, select Next to proceed to the Load Flow Cell screen.

AVITI OS moves the nest forward and opens the nest bay door. A brief delay is normal.


Load the Flow Cell

1. Make sure the nest status light is blue.
2. Press the button to the left of the nest to open the lid. Failure to fully press down on the button can cause errors when closing the lid or aligning the flow cell.
3. Remove the used flow cell from the nest. Discard or store at room temperature for use with priming or washes.
4. Unpackage the new Cloudbreak flow cell. Handle the flow cell by the gripper only.

CAUTION

Touching the glass can introduce debris, smudges, and scratches, compromising data quality.

5. Face the label up and place the flow cell over the three registration pins on the nest.
- 6.



Lower the tab on the right side of the lid until the lid snaps into place.

7. Select Close Nest to close the nest bay door and retract the stage.
8. Select Next to proceed to the Run Summary screen.

Review and Start the Run

1. Review the run parameters:

Parameter	Description
Library	The workflow that prepared the libraries and the library type
Sequencing Kit	The size and version of the sequencing kit
Storage	The location where sequencing output is stored
Manifest	The file name of the uploaded run manifest, if applicable
Cycles	The number of cycles in each read
Description	An optional description of the run
Advanced	If applicable, the advanced run settings for the run

2. Review the flow cell, cartridge, and buffer bottle information:

Field	Description
Lot Number	The number assigned to the batch the consumable was manufactured with
Expires on	The year, month, and date that the consumable expires
Serial Number	The unique identifier or all zeros indicating an unscanned barcode
Part Number	The Element-assigned identifier for the consumable

3. Select Run to start sequencing.

[Optional] If you imported run manifests from a USB drive, disconnect the USB drive:

- In the taskbar, select USB Drive, and then select Eject.
- Detach the USB drive from the instrument.

4. Process the materials removed from the reagent bay:

- For a used cartridge and buffer bottle, follow the instructions in Discard the Cartridge and Bottle on page 20.
- For a wash tray, follow the guidelines in the user guide for your instrument. Residual liquid in the wash tray is normal.

Monitor Run Metrics

1. If necessary, select Details to open run details.
2. Monitor run metrics as they appear onscreen. AVITI OS indicates the expected cycle that metrics appear.
 - The expected cycles are approximate, and all metrics are estimates. Bases2Fastq generates the final metrics.—
3. Continue monitoring the run as AVITI OS refreshes the metrics.
 - Each cycle refreshes the Q scores, error rates, base compositions, and index metrics.
 - If you are using the Individually Addressable Lanes add-on, AVITI OS displays metrics for each library pool.
 - AVITI OS refreshes the yield and reads metrics after cycle 15 of Read 2:
 - If Read 2 contains no cycles, metrics refresh after cycle 15 of Read 1.
 - If Read 1 or Read 2 contain fewer than 15 cycles, metrics refresh when the last cycle begins.
4. When the run is complete, leave all materials on the instrument.
 - To return to the Details view, select History.
 - To access run data, go to your storage location.

Initiate Flexible Start

Flexible start provides the option to start a run or recovery wash while another run is in progress. AVITI OS safely pauses the run on the adjacent side.

1. On the Home screen, select New Run.
2. When prompted to request flexible start and pause the active run, select New Run.


Step	Estimated Wait Time to Pause*
Amplification	2 hours
Index 1, Index 2, Read 1, or Read 2	A few minutes
Turn	30 minutes
Wash	1 hour

* Estimates are for 2 x 75 and 2 x 150 runs with Cloudbreak chemistry. For 2 x 300 runs, the wait time for a pause at the amplification step can exceed 2 hours.

3. Wait for the run to pause.
 - To cancel flexible start while waiting, select Cancel Request.
 - Contact Element Technical Support if the wait time exceeds 5 hours at the amplification step or 1.5 hours at any other step.
4. When the run pauses, proceed through run setup and start the second run or recovery wash.
 - For run setup instructions, proceed to Initiate a Sequencing Run on page 13.
 - For recovery wash instructions, see the user guide for your instrument.
5. To cancel setup of the second run or recovery wash, select Back to return to the Home screen, and then select Resume.


Discard the Cartridge and Bottle

The cartridge and buffer bottle contain reagents with region-specific disposal requirements, which are described in the Safety Data Sheets (SDS) at [elementbiosciences.com/resources](https://www.elementbiosciences.com/resources). The amount of reagent remaining in each well after a run depends on how many cycles the run performed. The following wells contain hazardous reagents. The position numbers in the figure align with the position numbers in the SDS.



Dispose of Reagents

1. Keep the cartridge in the basket with the clips locked.
2. Grip the lid tab and quickly and forcefully pull off the lid. Expect resistance.



3. Remove the wells indicated as hazardous from the cartridge.
 - The volume remaining in each well depends on the number of cycles performed.—
4. Using a pipette tip or a similar tool, enlarge the hole in each foil seal to form a triangle.



5. Empty each well into hazardous waste or other appropriate container per the SDS.
6. Unlock the clips and remove the cartridge from the basket.

7. Remove the remaining wells from the cartridge and enlarge the hole in each foil seal.
8. Empty each well into the appropriate container per the SDS.
9. Discard the cartridge and buffer bottle per the SDS.
10. Rinse the basket with nuclease-free water and dry upside down.

Troubleshooting

The following troubleshooting information addresses problems that can occur during run setup and sequencing with a Cloudbreak, Cloudbreak Freestyle, or Cloudbreak UltraQ kit. If a problem persists, contact Element Technical Support. For more information on troubleshooting, see the user guide for your instrument.

Run Setup Problems

Problem	Resolution
The flow cell is cracked, scratched, or otherwise damaged.	Contact Element Technical Support.
Small particulates are visible in the flow cell lane.	See Cloudbreak Flow Cell Variations on page 28 .
The lid does not engage when a flow cell is on the nest.	Remove the flow cell and wipe the nest. Inspect the flow cell for large debris and wipe with an alcohol pad if necessary. Reload the flow cell.
AVITI OS cannot detect a loaded cartridge or waste bottle.	Follow the onscreen prompt to reload the cartridge or waste bottle. Make sure the applicable bay, reagent or waste, is unobstructed, and that the cartridge is contained within a cartridge basket.
The system cannot scan or detect a barcode on the cartridge, buffer bottle, or flow cell.	Follow the onscreen prompt to reload the consumable or continue by manually entering consumable information.
The flow cell version is incompatible with the cartridge.	Load a flow cell that is the same version as the cartridge.

Sequencing Problems


Problem	Resolution
Polony density is lower or higher than expected.	Contact Element Technical Support or stop the run. For instructions on stopping a run, see the troubleshooting section of the user guide for your instrument.
The assigned or perfect match metrics are lower than expected.	Make sure that the index sequences recorded in the run manifest are correct.
The samples with low representation metric is higher than expected.	Select Sample Details to view the samples with low representation. Make sure that the index sequences recorded in the run manifest and the pooling concentration are correct.
The Q30 percentage is lower than expected.	Contact Element Technical Support.
The PhiX error rate is higher than expected.	
The flow cell contains very few colonies or no colonies.	
The user interface is frozen.	

Thumbnail Image Troubleshooting


The following figures show example thumbnail images for a standard flow cell, an underloaded flow cell, and an

overloaded flow cell. If the thumbnail image for a run indicates an underloaded flow cell, increase the loading concentration. For an overloaded flow cell, reduce the loading concentration. If problems persist, contact Element Technical Support.


- Example expected thumbnail image, full-size and zoomed



- Example thumbnail image with underloading, full-size and zoomed



- Example thumbnail image with overloading, full-size and zoomed



Cloudbreak Consumables

Cloudbreak consumables include a sequencing kit and optional controls and custom primers. The workflow also requires user-supplied consumables. For a list of required equipment, see the site prep guide for your instrument.

Cloudbreak Sequencing Kits

The following tables list the kit contents and storage requirements. Kits contain one of each part listed. The Library Loading Buffer pouch includes two tubes. For SDS information, see [elementbiosciences.com/resources](https://www.elementbiosciences.com/resources).

AVITI 2×150 Sequencing Kit Cloudbreak UltraQ, # 860-00018

Part #	Component	Shipping	Storage
820-00026	AVITI 2×150 Cartridge Cloudbreak Ultra	-25°C to -15°C	-25°C to -15°C
810-00008	AVITI Flow Cell Cloudbreak Ultra	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×75 Sequencing Kit Cloudbreak Freestyle High Output, # 860-00015

Part #	Component	Shipping	Storage
820-00022	AVITI 2×75 Cartridge Cloudbreak Freestyle High Output	-25°C to -15°C	-25°C to -15°C
810-00003	AVITI Flow Cell Cloudbreak Freestyle	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×75 Sequencing Kit Cloudbreak Freestyle Medium Output, # 860-00014

Part #	Component	Shipping	Storage
820-00021	AVITI 2×75 Cartridge Cloudbreak Freestyle Medium Output	-25°C to -15°C	-25°C to -15°C
810-00003	AVITI Flow Cell Cloudbreak Freestyle	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×75 Sequencing Kit Cloudbreak Freestyle Low Output, # 860-00034

Part #	Component	Shipping	Storage
820-00032	AVITI 2×75 Cartridge Cloudbreak Freestyle Low Output	-25°C to -15°C	-25°C to -15°C
810-00003	AVITI Flow Cell Cloudbreak Freestyle	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×150 Sequencing Kit Cloudbreak Freestyle High Output, # 860-00013

Part #	Component	Shipping	Storage
820-00020	AVITI 2×150 Cartridge Cloudbreak Freestyle High Output	-25°C to -15°C	-25°C to -15°C
810-00003	AVITI Flow Cell Cloudbreak Freestyle	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×150 Sequencing Kit Cloudbreak Freestyle Medium Output, # 860-00012

Part #	Component	Shipping	Storage
820-00019	AVITI 2×150 Cartridge Cloudbreak Freestyle Medium Output	-25°C to -15°C	-25°C to -15°C
810-00003	AVITI Flow Cell Cloudbreak Freestyle	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×150 Sequencing Kit Cloudbreak Freestyle Low Output, # 860-00011

Part #	Component	Shipping	Storage
820-00018	AVITI 2×150 Cartridge Cloudbreak Freestyle Low Output	-25°C to -15°C	-25°C to -15°C
810-00003	AVITI Flow Cell Cloudbreak Freestyle	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×300 Sequencing Kit Cloudbreak Freestyle High Output, # 860-00017

Part #	Component	Shipping	Storage
820-00023	AVITI 2×300 Cartridge Cloudbreak Freestyle Medium Output	-25°C to -15°C	-25°C to -15°C
810-00003	AVITI Flow Cell Cloudbreak Freestyle	Room temperature	2°C to 8°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×75 Sequencing Kit Cloudbreak High Output, # 860-00004

Part #	Component	Shipping	Storage
820-00015	AVITI 2×75 Cartridge Cloudbreak High Output	-25°C to -15°C	-25°C to -15°C
810-00002	AVITI Flow Cell Cloudbreak	Room temperature	2°C to 8°C
820-00010	Adept Primer Set Cloudbreak	-25°C to -15°C	-25°C to -15°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×75 Sequencing Kit Cloudbreak Medium Output, # 860-00007

Part #	Component	Shipping	Storage
820-000 14	AVITI 2×75 Cartridge Cloudbreak Medium Output	-25°C to -15°C	-25°C to -15°C
810-000 02	AVITI Flow Cell Cloudbreak	Room temperature	2°C to 8°C
820-000 10	Adept Primer Set Cloudbreak	-25°C to -15°C	-25°C to -15°C
820-000 02	AVITI Buffer Bottle	Room temperature	Room temperatur e
820-000 04	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×150 Sequencing Kit Cloudbreak High Output, # 860-00003

Part #	Component	Shipping	Storage
820-000 13	AVITI 2×150 Cartridge Cloudbreak High Output	-25°C to -15°C	-25°C to -15°C
810-000 02	AVITI Flow Cell Cloudbreak	Room temperature	2°C to 8°C
820-000 10	Adept Primer Set Cloudbreak	-25°C to -15°C	-25°C to -15°C
820-000 02	AVITI Buffer Bottle	Room temperature	Room temperatur e
820-000 04	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×150 Sequencing Kit Cloudbreak Medium Output, # 860-00006

Part #	Component	Shipping	Storage
820-000 12	AVITI 2×150 Cartridge Cloudbreak Medium Output	-25°C to -15°C	-25°C to -15°C
810-000 02	AVITI Flow Cell Cloudbreak	Room temperature	2°C to 8°C
820-000 10	Adept Primer Set Cloudbreak	-25°C to -15°C	-25°C to -15°C
820-000 02	AVITI Buffer Bottle	Room temperature	Room temperatur e
820-000 04	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×150 Sequencing Kit Cloudbreak Low Output, # 860-00005

Part #	Component	Shipping	Storage
820-00011	AVITI 2×150 Cartridge Cloudbreak Low Output	-25°C to -15°C	-25°C to -15°C
810-00002	AVITI Flow Cell Cloudbreak	Room temperature	2°C to 8°C
820-00010	Adept Primer Set Cloudbreak	-25°C to -15°C	-25°C to -15°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×300 Sequencing Kit Cloudbreak High Output, # 860-00008

Part #	Component	Shipping	Storage
820-00016	AVITI 2×300 Cartridge Cloudbreak High Output	-25°C to -15°C	-25°C to -15°C
810-00002	AVITI Flow Cell Cloudbreak	Room temperature	2°C to 8°C
820-00010	Adept Primer Set Cloudbreak	-25°C to -15°C	-25°C to -15°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

AVITI 2×300 Sequencing Kit Cloudbreak Medium Output, # 860-00009

Part #	Component	Shipping	Storage
820-00017	AVITI 2×300 Cartridge Cloudbreak Medium Output	-25°C to -15°C	-25°C to -15°C
810-00002	AVITI Flow Cell Cloudbreak	Room temperature	2°C to 8°C
820-00010	Adept Primer Set Cloudbreak	-25°C to -15°C	-25°C to -15°C
820-00002	AVITI Buffer Bottle	Room temperature	Room temperature
820-00004	Library Loading Buffer	-25°C to -15°C	-25°C to -15°C

Adept Primer Set Cloudbreak

Primers for I1, I2, R1, and R2 provided in Cloudbreak cartridges support Elevate libraries. Sequencing Adept libraries requires replacing the prepackaged primers with tubes from the Adept Primer Set Cloudbreak.

Adept Primer Set Cloudbreak, catalog # 820-00010

- Index 1—Adept Index 1 (I1) Primer Cloudbreak
- Index 2—Adept Index 2 (I2) Primer Cloudbreak
- Read 1—Adept Read 1 (R1) Primer Cloudbreak
- Read 2—Adept Read 2 (R2) Primer Cloudbreak

The Adept Primer Set Cloudbreak is not compatible with Cloudbreak Freestyle or Cloudbreak UltraQ kits.

PhiX Control Library

PhiX Control Library is a color-balanced, ready-to-use library that adds diversity to low-complexity libraries. Each type of PhiX Control Library includes unique index sequences and has a concentration of 1 nM. For a list of sequences, see Element Index Sequences.

Type	Format	Shipping and Storage
PhiX Control Library, Adept, # 830-00004	Circular	-25°C to -15°C
Cloudbreak PhiX Control Library, Elevate, # 830-00017	Linear	-25°C to -15°C
Cloudbreak Freestyle PhiX Control, Third Party, #830-00023	Linear	-25°C to -15°C

Custom Primer Sets

A custom primer set provides read-specific buffers for preparing custom primers for Adept libraries with Cloudbreak chemistry or third-party libraries with Cloudbreak Freestyle chemistry.

Problem	Resolution
Polony density is lower or higher than expected.	Contact Element Technical Support or stop the run. For instructions on stopping a run, see the troubleshooting section of the user guide for your instrument.
The assigned or perfect match metrics are lower than expected.	Make sure that the index sequences recorded in the run manifest are correct.
The samples with low representation metric is higher than expected.	Select Sample Details to view the samples with low representation. Make sure that the index sequences recorded in the run manifest and the pooling concentration are correct.
The Q30 percentage is lower than expected.	Contact Element Technical Support.
The PhiX error rate is higher than expected.	
The flow cell contains very few polonies or no polonies.	
The user interface is frozen.	

Custom Primer Set	Buffers	Shipping and Storage
Adept Custom Primer Set Cloudbreak, # 820-00009	<ul style="list-style-type: none">• Adept Custom Index 1 Buffer, Index First (I1)• Adept Custom Index 2 Buffer, Index First (I2)• Adept Custom Read 1 Buffer, Index First (R1)• Adept Custom Read 2 Buffer, Index First (R2)	-25°C to -15°C
Custom Primer Set Cloudbreak Freestyle, # 820-00025	<ul style="list-style-type: none">• Custom Index 1 (I1) Buffer Cloudbreak Freestyle• Custom Index 2 (I2) Buffer Cloudbreak Freestyle• Custom Read 1 (R1) Buffer Cloudbreak Freestyle• Custom Read 2 (R2) Buffer Cloudbreak Freestyle	-25°C to -15°C


User-Supplied Consumables and Equipment

Consumables	Supplier
DNA LoBind Tubes, 2 ml	Eppendorf, # 022431021
0.2 M Tris-HCl, pH 7.0	General lab supplier
1 N NaOH	
10 mM Tris-HCl, pH 8.0 with 0.1 mM EDTA	
Filtered pipette tips	
Low TE buffer	
Nuclease-free laboratory-grade water	

Cartridge Shipping Configuration


The Cloudbreak sequencing cartridge includes shipping protection in the form of shipping locks or a thermoform shipping cover.

- If your cartridge includes the shipping locks (A), remove the shipping locks before loading the cartridge onto the instrument.
- If your cartridge includes the thermoform shipping cover (B), remove the cover before thawing reagents.



Cloudbreak Flow Cell Variations

Cloudbreak flow cells might have small particulate within the flow cell lane. These variations are normal and do not impact data quality.



Document History

Revision	Description of Change
January 2025 Document # MA-00058 Rev. C	<ul style="list-style-type: none"> Added recommendations for using short insert and long insert recipes. Added run specifications for the Cloudbreak Freestyle 2 x 75 low output kit. Added example of different cartridge shipping configurations, such as shipping locks or shipping cover. Added statement that Cloudbreak flow cell variations do not impact data quality. Recommended a pipette tip or similar tool to enlarge hole in foil seal.
December 2024 Document # MA-00058 Rev. B	<ul style="list-style-type: none"> Added 2 x 75 Cloudbreak Freestyle Low Output kit. Updated name of sequencing basket to cartridge basket.
October 2024 Document # MA-00058 Rev. A	<ul style="list-style-type: none"> Initial release of user guide.

Technical Support

Visit the User Documentation page on the Element Biosciences website for additional guides and the most recent version of this guide. For technical assistance, contact Element Technical Support.

- Website: www.elementbiosciences.com
- Email: support@elembio.com
- Telephone: +1 866.ELEMBIO (+1 866.353.6246)

Element Biosciences

10055 Barnes Canyon Road, Suite 100M San Diego, CA 92121 elementbiosciences.com

- Telephone: 619.353.0300
- Email: info@elembio.com


ELEMENT BIOSCIENCES

For Research Use Only. Not for use in diagnostic procedures.

FAQ

- Q: Can I use this product for diagnostic procedures?**
A: No, this product is for Research Use Only and not intended for diagnostic procedures.
- Q: How many reads are typically included in a sequencing run?**
A: A sequencing run usually includes four reads: Index 1, Index 2, Read 1, and Read 2.

Documents / Resources

	<p>Element Biosciences Cloudbreak Sequencing Kits [pdf] User Guide AVITI System 880-00001, AVITI24 System 880-00004, Cloudbreak Sequencing Kits, Cloudbreak, Sequencing Kits, Kits</p>
---	--

References

-  [Element Biosciences Software Documentation | Element Biosciences Software Documentation](#)

- [📖 Run Planning | Element Biosciences Software Documentation](#)
- [📖 Run Planning | Element Biosciences Software Documentation](#)
- [📖 Element Index Sequences | Element Biosciences Software Documentation](#)
- [📖 Settings | Element Biosciences Software Documentation](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.