



# **EPH CONTROLS R17V2 1 Zone RF Time Switch Pack** Instructions

Home » EPH CONTROLS » EPH CONTROLS R17V2 1 Zone RF Time Switch Pack Instructions



#### **Contents**

- 1 EPH CONTROLS R17V2 1 Zone RF Time Switch
- **Pack**
- 2 Setting the date & time
- 3 ON/OFF settings
- 4 Factory program settings
- 5 Operating the thermostat
- 6 Introduction to your R17V2 Timeswitch
- 7 contact
- 8 Documents / Resources
  - 8.1 References
- 9 Related Posts



## **EPH CONTROLS R17V2 1 Zone RF Time Switch Pack**





# Setting the date & time

· Lower the cover on the front of the unit.

'P01 tInE' will appear on the screen. the year will begin to flash. to adjust the year. Press • Repeat the above to select the MONTH, DAY, HOUR, and MINUTE. and the time switch will return to normal operation • When this is complete Press

## **ON/OFF settings**

## 4 different settings available


#### How to select

- · Lower the cover on the front of the unit.
- By pressing the button to change between settings for the times
- · Lower the cover on the front of the unit.
- Select · By pressing the button to change between settings for the times

# **Factory program settings**

	5/2D					
	P1 ON	P1 OFF	P2 ON	P2 OFF	P3 ON	P3 OFF
Mon-Fri	6:30	8:30	12:00	12:00	16:30	22:30
Sat-Sun	7:30	10:00	12:00	12:00	17:00	23:00

#### Adjusting the program settings



• Repeat this process to adjust the ON & OFF times for P2 & P3.

• When this is complete Press and the timeswitch will return to normal operation.

#### **Boost function**

This function allows the user to turn ON the timeswitch for a period of 30mins, 1, 2, or 3 hours. This does not affect your program settings. If the zone that you wish to Boost is timed to be OFF, you have the facility to switch it ON for 30 minutes, 1, 2 or 3 hours.

- Press the Boost button once, twice, three or four times respectively.
- To cancel the boost function, simply press

  Boost the button again.

## Operating the thermostat

The thermostat will allow the timeswitch to activate provided the ambient temperature is below the setpoint.

- Adjusting the temperature setpoint: Rotate the dial clockwise to increase or decrease the temperature setpoint counterclockwise. You can press the dial to confirm or the temperature will be controlled automatically after 5 seconds.
- Boost from the thermostat You can activate the timeclock for 30mins, 1, 2 or 3 hours by pressing the button on the thermostat 1, 2, 3 or 4 times. The thermostat will display bSt 00:30, 01:00, 02:00, 03:00 to represent what is selected. To cancel the boost function, simply press

## Important: Keep this document

AUTO	operates up to 3 ON/OFF periods per day
ALL DAY	operates from1st ON time (P1 on) to last off time (P3 off)
ON	permanently on
OFF	permanently off

## Introduction to your R17V2 Timeswitch

• The R17V2 timeswitch has up to three daily heating programs called P1, P2 and P3. When in the AUTO mode, it will show when the timeswitch is next programmed to be switched ON or OFF. When the timeswitch is ON, the red LED lights up. This indicates that power is being sent from the timeswitch.

#### contact

- technical@ephcontrols.com
- www.ephcontrols.com

#### **Documents / Resources**



# EPH CONTROLS R17V2 1 Zone RF Time Switch Pack [pdf] Instructions

R17V2, R17V2 1 Zone RF Time Switch Pack, 1 Zone RF Time Switch Pack, RF Time Switch Pack, Switch Pack, Pack

#### References

## • User Manual

## Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.