



eVatmaster Cut Off Switch Versatile Device User Manual

June 10,
2025

Contents [[hide](#)]

1 Cut Off Switch User Manual

1.1 Product Overview

1.2 Safety Instructions

1.3 Installation Guide

1.4 Operation Instructions

1.5 Troubleshooting

1.6 Maintenance

1.7 Warranty Information

1.8 Contact Information

2 Documents / Resources

2.1 References

Cut Off Switch User Manual

Product Overview

The Cut Off Switch is a versatile device designed to provide a safe and efficient means of controlling electrical power to various appliances and equipment. It is engineered with safety and convenience in mind, suitable for both residential and commercial applications. This manual will guide you through the setup, operation, and maintenance of your Cut Off Switch.

Safety Instructions

1. **Read All Instructions:** Before using the Cut Off Switch, carefully read all instructions and safety information provided.
2. **Qualified Personnel:** Installation and maintenance should only be performed by qualified electricians or personnel.
3. **Power Off Before Handling:** Always ensure the power is fully off before installing, removing, or servicing the Cut Off Switch.
4. **Keep Dry:** Keep the Cut Off Switch dry and avoid exposure to moisture.
5. **Do Not Overload:** Do not exceed the maximum load rating specified for the switch.
6. **Inspect Regularly:** Periodically inspect the switch for signs of wear, damage, or corrosion.

Installation Guide

1. **Location Selection:** Choose a location that is easily accessible but protected from direct physical contact and splashing water.
2. **Shutdown Main Power:** Turn off the main power supply to the circuit where the Cut Off Switch will be installed.
3. **Wire Connection:**
 - Remove the cover plate.
 - Use appropriate wire connectors to attach the incoming power wires to the corresponding terminals on the switch (Line, Load, and Ground).
 - Ensure all connections are tight and secure.
4. **Mounting:** Secure the Cut Off Switch to the mounting box using the provided screws.
5. **Restore Power:** Once installation is complete, turn the main power back on and test the switch to ensure it operates correctly.

Operation Instructions

1. **Turning On:** To turn on the power, flip the switch lever to the "ON" position.
2. **Turning Off:** To turn off the power, flip the switch lever to the "OFF" position.
3. **Indicator Light (if equipped):** The indicator light will illuminate when the switch is in the

“ON” position, indicating that power is flowing.

Troubleshooting

1. Switch Does Not Turn On/Off:

- Check that the power is on at the main circuit breaker.
- Verify all wire connections are tight and correctly installed.
- Replace the switch if it is damaged or defective.

2. Indicator Light Does Not Work:

- Ensure the bulb (if applicable) is not burned out.
- Check for loose or disconnected wires at the indicator terminal.

Maintenance

1. **Regular Inspections:** Periodically check the switch for signs of wear, corrosion, or damage.
2. **Cleaning:** Use a dry cloth to clean the exterior of the switch. Avoid using wet or chemical-based cleaners.
3. **Tighten Connections:** Periodically check and tighten all wire connections to prevent loosening over time.

Warranty Information

This Cut Off Switch is covered by a [specific warranty period 1-year] limited warranty from the date of purchase. The warranty covers any manufacturing defects and does not apply to damage caused by misuse, abuse, or improper installation. For warranty service, contact the manufacturer or authorized service center.

Contact Information

For any questions, technical support, or warranty claims, please contact:

Customer Support Email: 1715445486@qq.com

Customer Support Phone Number: 13509693977


By following this user manual, you can ensure the safe and efficient operation of your Cut Off Switch. Thank you for choosing our product!

Customer Support:




eVatmaster Consulting GmbH
Bettinastr.30
60325 Frankfurt am Main, Germany
contact@evatmaster.com




 Please use a DC power supply with a voltage not exceeding 24V.

Documents / Resources

	<p>eVatmaster Cut Off Switch Versatile Device [pdf] User Manual</p> <p>Cut Off Switch Versatile Device, Off Switch Versatile Device, Versatile Device, Device</p>
---	---

References

- [User Manual](#)

 Cut Off Switch Versatile Device, device, evatmaster, Off Switch Versatile Device, Versatile Device

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.