Home » Feit Electric » FEIT Electric T848 Linear Lamp Instruction Manual

FEIT Electric T848 Linear Lamp Instruction Manual

Contents

- 1 FEIT Electric T848 Linear Lamp
- 2 Safety Information
- **3 Limited Warranty**
- 4 Documents / Resources
- **5 Related Posts**

FEIT Electric T848 Linear Lamp

Safety Information

PLEASE READ THESE INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. This LED tube is intended to replace fluorescent tube lamps with ANSI designation F32T8/U with G13 base. This product may not be compatible with all ballasts. For more information about ballast compatiblity please visit www.FEIT.COM.

- 1. Always follow basic safety precautions to reduce the risk of fire, electric shock and personal injury.
- 2. WARNING: RISK OF FIRE OR ELECTRIC SHOCK. LfO Retrofit Kit installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician. House electric current can cause painful shock or serious injury unless handed properly. For your safety, always remember to:
 - A. Tum OFF the power supply at the fuse or circuit breaker box before you install the lamp.
 - B. Ensure the fixture is grounded to avoid potential electric shock and to ensure reliable starting.
 - C. Wear rubber sole shoes and work on a sturdy ladder
 - D. Do not touch with wet hands.
 - E. This lamp is not intended for use with emergency exits or emergency lights.
- 3. This lamp is designed for use in a circuit protected by a fuse or circuit breaker. It is also designed to be installed in accordance with local electrical codes. If you are unsure about your wiring, consult a qualified electrician or local electrical inspector, and check your local electrical code.
- 4. Avoid looking directly into the lamp.
- 5. WARNING: RISK OF CUTS: To prevent wiring damage, abrasion or cuts, do not expose wiring to edges of sheet metal or other sharp objects and wear gloves.
- 6. Account for small parts and destroy packaging material, as these may be hazardous to children.
- 7. Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.
- 8. Installers should not disconnect existing wires from lamp holder terminals to make new connections at lamp



holder terminals. Instead, installers should cut existing lamp holder leads away from the lamp holder and make new electrical connections to lamp holder lead wires by employing applicable connectors.

9. Installers should examine all parts that are not intended to be replaced by the retrofit kit for damage and replace any damaged parts prior to installation of the retrofit kit.

WARNING: Check the luminaire (fixture) carefully before installing the lamp. Ensure the electrical lamp holders (sockets) are not damaged and will make firm contact with the lamp pins.

CAUTION: Risk of fire – If lamp or luminaire exhibits abnormal operation (buzzing, flickering, minimal or no light, etc.), immediately tum off power and contact us for more information.

CAUTION: Risk of fire – Suitable for damp locations. Do not use dimmers. Do not touch lamp pins to the metal housing when installing.

WARNING: Do not install this in a pre-heat luminaire (fixture), often with external starters.

WARNING: Install this kit only in luminaires that have the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.

WARNING: To avoid potential fire or shock hazards, do not use this retrofit kit in luminaires employing shunted bipin lamp holders.

Note: Shunted lamp holders are found only in fluorescent luminaires with Instant-Start ballasts. Instant-start ballasts can be identified by the words "Instant Start" or "I.S." marked on the ballast. This designation may be in the form of a statement pertaining to the ballast itself or may be combined with the marking for the lamps with which the ballast is intended to be used, for example, F40T12/IS. For more information, contact the LED luminaire retrofit kit manufacturer.

Limited Warranty

This product is warrantied to be free from defects in workmanship and materials for up to 5 years from date of purchase. If the product fails within the warranty period, please contact Feit Electric at info@feit.com, visit feit.com/contact-us or call 1-866-326-BULB (2852) for instructions on replacement or refund. REPLACEMENT OR REFUND IS YOUR SOLE REMEDY. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IS HEREBY EXPRESSLY EXCLUDED. Some states and provinces do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.



FEIT Electric T848 Linear Lamp [pdf] Instruction Manual T848, T850, AB, U6, LED, T848 Linear Lamp, Linear Lamp, Lamp

Manuals+,