



## Feker Alice 80 User Manual: Learn How to Use Your Keyboard

[Home](#) » [FEKER](#) » Feker Alice 80 User Manual: Learn How to Use Your Keyboard 

The Feker Alice-80 Keyboard User Manual provides comprehensive instructions on how to use the keyboard effectively. The manual contains detailed information on the switch and USB function, interface connected function, battery status indicator function, and FN+keys function. The keyboard comes in three versions: USB, wireless 2.4G, and wireless BT. Users can switch between these versions using the mode switch. The manual also provides electrical specifications for each version of the keyboard. The FN+keys function allows users to perform various tasks such as adjusting screen brightness, controlling volume, and changing backlight color. Additionally, the manual includes a statement from the FCC regarding compliance and system requirements. The keyboard is compatible with Windows 2000 and above and Mac systems. Whether you are a beginner or an experienced user, the Feker Alice-80 Keyboard User Manual is an essential guide to help you get the most out of your keyboard.


# FEKER

### ALICE-80 Keyboard User Manual

#### Contents

- [1 Switch & USB Function](#)
- [2 Interface Connected Function](#)
- [3 Battery status indicator Function](#)
- [4 Device name description](#)
- [5 FN+Keys Function](#)
- [6 FCC Statement](#)
- [7 SPECIFICATION](#)
- [8 FAQs](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

#### Switch & USB Function



**Mac** For Mac system used , key-function shift to for Mac computer or iPad;

**Win** For Windows system used , key-function shift to for standard Windows computer;

**On** For Wireless version used, including the 2.4g and bluetooth mode; USB cable only for charge in this time.


**Off** For Wired version used, in the same time ,you need insert the Type-C cable to device and USB to computer, working on USB mode ;


**Type-C** Type-C cable insert here and USB connect to computer for connect to computer ; Working on USB mode (switch to Off) and only for charge the battery ( switch to On).


## Interface Connected Function


**USB Version**— Push the mode switch  to OFF state.

1. Connect the USB-A port to computer USB port and Connect the Type-C port to keyboard;
2. Push the mode switch to OFF state for enter to wired USB device mode.

**Wireless 2.4G Version**— Push the mode switch  to ON state.

1. Connect the USB-A port to computer USB port and Connect the Type-C port to keyboard;
2. Press the Fn and G key for enter to 2.4G device mode;
3. If your want used this 2.4g device , you need connect the receiver  to USB port of computer first, that's important ; Or ( the other's solution)

1. Switch the ON/OFF button to ON , and Make sure the battery is available ;
2. Press the Fn and G key for enter to 2.4G device mode;
3. If your want used this 2.4g device , you need connect the receiver  to USB port of computer first, that's important ;

**Wireless BT Version** — Push the mode switch  to ON state.

1. Connect the USB-A port to computer USB port and Connect the Type-C port to keyboard;
2. Press the Fn and C/V/B key for enter to BT device Alice-1/2/3 mode, one by one;
3. Long press 3 seconds for pairing to new device by bluetooth ;
4. Press 1 time for re-connected to paired device by bluetooth ;
5. Press the Fn + C/V/B 1 time, You can switch between Alice-1/2/3 device;

## Battery status indicator Function



On keyboard , the right side of CTRL key's LED lighting is for indicator of battery status.

**Low battery** the right side of CTRL key's LED will lighting RED flash.

**Charging** Press 3seconds Fn and the right side of CTRL key, LED will lighting BLUE.

**Full charge** Press 3seconds Fn and the right side of CTRL key, LED will lighting GREEN.

**Battery is dead** the right side of CTRL key's LED will lighting RED continuous.

## Device name description

**USB Version** FEKER Alice80

**2.4G Version** Wireless Gaming Keyboard

**BT Version** FEKER Alice-1

FEKER Alice-2

FEKER Alice-3

## Electrical Specifications (for reference only)

Version	Item	Current(data)
USB	Wired constant lighting mode	$\leq 260 \text{ mA}$
	Wired constant Un-lighting	$\leq 10 \text{ mA}$
2.4G	2.4G constant lighting mode	$\leq 380 \text{ mA}$
	2.4G sleep mode	$\leq 0.02 \text{ mA}$
Bluetooth	BT constant lighting mode	$\leq 380 \text{ mA}$
	BT sleep mode	$\leq 0.02 \text{ mA}$
Charge	Recharging mode	$\leq 450 \text{ mA}$

## FN+Keys Function

	For Windows		For Mac	
	Function Key	Function	Function Key	Function
	Esc		Esc	~
	1!	F1	1!	Screen brightness decrease
	2@	F2	2@	Screen brightness increase
	3#	F3	3#	Multitask controller
	4 \$	F4	4 \$	Program listing
	5%	F5		
	6 ^	F6		
	7&	F7	7&	Previous track
	8*	F8	8*	Play & pause

Fn +	9(	F9	9(	Next track
	0)	F10	0)	Mute
	—	Fl 1	—	Volume decrease
	= +	F12	=+	Volume increase
	Win	Win Lock&Unlock		
	:/	Backlight colour change	11	Backlight colour change
	Del	Backlight mode change	Del	Backlight mode change
	I	Ins	I	Ins
	P	Prs	P	Prs
	L	Backlight On&Off Switch	L	Backlight On&Off Switch
	?/	My calculator	?/	My calculator
	M	Mute	M	Mute
	< ,	Volume down	< ,	Volume down
	> .	Volume up	> .	Volume up
	W	Directional keys interchange	W	Directional keys interchange
	Backspace	Press 3 s for reset	Backspace	Press 3 s for reset
	Page up	Home		
	Page down	End		
	; :	Lighting flow velocity down		
	, “	Lighting flow velocity up		
	—	Lighting flow direction to right	—	Lighting flow direction to right
	—	Lighting flow direction to left	—	Lighting flow direction to left
	I	Lighting brightness increase		
	I	Lighting brightness decrease		
	C	BT device Alice-1		
	V	BT device Alice-2		
	B	BT device Alice-3		
	G	2.4 G device		
	N	Wired USB device		

## FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part

15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **System Requirement**

Compatible with Windows 2000 and above and Mac system.

#### **SPECIFICATION**

<b>Product Specification</b>	<b>Description</b>
Keyboard Versions	USB, Wireless 2.4G, Wireless BT

Electrical Specifications	Version	Item	Current(data)
	USB	Wired constant lighting mode	≤ 260 mA
	USB	Wired constant Un-lighting	≤10 mA
	2.4G	2.4G constant lighting mode	≤ 380 mA
	2.4G	2.4G sleep mode	≤ 0.02 mA
	Bluetooth	BT constant lighting mode	≤ 380 mA
	Bluetooth	BT sleep mode	≤ 0.02 mA
	Charge	Recharging mode	≤ 450 mA
Interface Connected Function	<ul style="list-style-type: none"> <li>• USB Version: Push the mode switch to OFF state. Connect the USB-A port to computer USB port and Connect the Type-C port to keyboard. Push the mode switch to OFF state for enter to wired USB device mode.</li> <li>• Wireless 2.4G Version: Push the mode switch to ON state. Connect the USB-A port to computer USB port and Connect the Type-C port to keyboard. Press the Fn and G key for enter to 2.4G device mode. If you want to use this 2.4g device, you need to connect the receiver to USB port of computer first. Or switch the ON/OFF button to ON, and make sure the battery is available. Press the Fn and G key for enter to 2.4G device mode. If you want to use this 2.4g device, you need to connect the receiver to USB port of computer first.</li> <li>• Wireless BT Version: Push the mode switch to ON state. Connect the USB-A port to computer USB port and Connect the Type-C port to keyboard. Press the Fn and C/V/B key for enter to BT device Alice-1/2/3 mode, one by one. Long press 3 seconds for pairing to new device by bluetooth. Press 1 time for re-connected to paired device by bluetooth. Press the Fn + C/V/B 1 time, You can switch between Alice-1/2/3 device.</li> </ul>		

Batt  
ery  
stat  
us i  
ndic  
ator  
Fun  
ctio  
n

- Low battery: the right side of CTRL key's LED will lighting RED flash.
- Charging: Press 3 seconds Fn and the right side of CTRL key, LED will lighting BLUE.
- Full charge: Press 3 seconds Fn and the right side of CTRL key, LED will lighting GREEN.
- Battery is dead: the right side of CTRL key's LED will lighting RED continuous.

Fn +	Windows Function Key	Mac Function Key	Function
Esc	Esc	~	1!
2@	F2	2@	Screen brightness decrease
3#	F3	3#	Screen brightness increase
4 \$	F4	4 \$	Multitask controller
5%	F5	6 ^	Program listing
F6	F6	7&	Program listing
8*	F8	8*	Previous track
9(	F9	9(	Play & pause
0)	F10	0)	Next track
—	Fl 1	—	Mute
= +	F12	=+	Volume decrease
Win	Win Lock&Unlock	:/	Volume increase
11	Backlight colour change	Backlight colour change	Backlight mode change

FN+  
Key  
s Fu  
ncti  
on

Del	Backlight mode change	Backlight mode change	
I	Ins	I	Ins
P	Prs	P	Prs
L	Backlight On&Off Switch	L	Backlight On&Off Switch
?/	My calculator	?/	My calculator
M	Mute	M	Mute
< ,	Volume down	< ,	Volume down
> .	Volume up	> .	Volume up
W	Directional keys interchange	W	Directional keys interchange
Backspace	Press 3 s for reset	Backspace	Press 3 s for reset
Page up	Home	Page down	End
; :	Lighting flow velocity down	, “	Lighting flow velocity up
—	Lighting flow direction to right	—	Lighting flow direction to right
—	Lighting flow direction to left	—	Lighting flow direction to left
I	Lighting brightness increase	I	Lighting brightness decrease
C</			



## FAQS

### How do I reset the keyboard?

Pressing the backspace key for 3 seconds will reset the keyboard.

### What is the FCC statement regarding compliance and system requirements?

The FCC statement provides information on compliance and system requirements for the keyboard. It also includes instructions on how to correct any interference that may occur during use.

### Is the keyboard compatible with Mac systems?

Yes, the keyboard is compatible with Mac systems. You can use the key-function shift to switch to Mac mode.

### What tasks can I perform using the FN+keys function?

You can perform various tasks such as adjusting screen brightness, controlling volume, changing backlight color, and more using the FN+keys function.

### How do I know if my battery is low or fully charged?

The right side of the CTRL key's LED lighting is for the indicator of battery status. A red flash indicates low battery, blue indicates charging, green indicates full charge, and continuous red indicates a dead battery.

### How do I connect the keyboard to my computer?

The instructions for connecting the keyboard to your computer are provided in the user manual, depending on which version of the keyboard you have.

### What are the electrical specifications for each version of the keyboard?

The electrical specifications for each version of the keyboard are listed in the user manual for reference.


### How do I switch between the different versions of the keyboard?

You can switch between the different versions using the mode switch.

### What are the different versions of the Feker Alice-80 keyboard?

The Feker Alice-80 keyboard comes in three versions: USB, wireless 2.4G, and wireless BT.

## Documents / Resources



[FEKER ALICE-80 Keyboard](#) [pdf] User Manual

ALICE-80, ALICE80, 2A6HV-ALICE-80, 2A6HVALICE80, ALICE-80 Keyboard, ALICE Keyboard, Keyboard