

FELLOW TFEAAGB ally Pro Studio Edition Precision Scale



FELLOW TFEAAGB ally Pro Studio Edition Precision Scale Instruction Manual

[Home](#) » [Fellow](#) » **FELLOW TFEAAGB ally Pro Studio Edition Precision Scale Instruction Manual** 

Contents

- 1 [FELLOW TFEAAGB ally Pro Studio Edition Precision Scale](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [Product Overview](#)
- 5 [IMPORTANT SAFEGUARDS](#)
- 6 [SPECIFICATIONS](#)
- 7 [OPTIMAL TEMPERATURE FOR USING AND STORING TALLY](#)
- 8 [WHAT'S IN THE BOX?](#)
- 9 [BATTERY](#)
- 10 [CARE AND CLEANING](#)
- 11 [HOW TO REMOVE + REINSTALL WEIGH PAN](#)
- 12 [SCALE CALIBRATION](#)
- 13 [FACTORY RESET](#)
- 14 [TWO-YEAR STANDARD WARRANTY](#)
- 15 [FAQ](#)
- 16 [Documents / Resources](#)
 - 16.1 [References](#)



FELLOW TFEAAGB ally Pro Studio Edition Precision Scale



Product Information

Specifications

- **Weight Capacity:** 2500 g
- **Units:** g, oz, lbs, mL
- **Weight Range:** 0.1 g to 2500 g
- **Dimensions (LxWxH):** 176.7 mm x 150 mm x 32.9 mm
- **Electrical Requirements:** 5 V, 1 A
- **Power and Battery:** Lithium-ion rechargeable battery (3.7 V 1000 mAh)
- **Display:** OLED screen, glass
- **Warranty:** 2 years

Product Usage Instructions

Charging the Battery

The device uses a rechargeable lithium polymer battery. To charge the battery:

1. Plug the USB cable into a power supply with an output of 5 volts and 1 amp.
2. It takes approximately 1-2 hours to fully charge the battery from empty.
3. Avoid letting the battery completely run out before charging. Charge the battery as needed.

Battery Status and Conservation

When you plug in your scale, the remaining battery level will flash on the screen. Additional points to note:

- When the battery level is at 25% or below, it will be displayed when the device wakes or goes to sleep.

- To conserve battery, the screen will dim after 2 minutes and automatically turn off after 10 minutes of inactivity, unless timing.
- If the timing is, the scale will automatically turn off after 20 minutes.

Care and Cleaning


To maintain your Tally Pro scale:

- Avoid using abrasive pads or harsh chemicals for cleaning to prevent damage.
- The scale is water-resistant but not waterproof; do not put any part in the dishwasher or immerse in liquid.

To download this safety manual in another language please visit Fellowproducts.com/tallysafetymanuals or scan this QR Code.



Product Overview



TALLY PRO

Fellow Industries Inc.

- Fellowproducts.com

- Email: hello@fellowproducts.com
- San Francisco, CA 94110

Product Name: Tally Pro Studio Edition Precision Scale

Patents and Patents Pending:

- fellowproducts.com/pages/patents 2-Year Limited Warranty
- Designed in San Francisco,

Made in China

MODEL	SPECIFICATIONS
FEAAGB	3.7V 1000 mAh Li-ion Battery Weight: 591 g Dimensions (LxWxH): 176.7 mm x 150 mm x 32.9 mm Max Capacity: 2.5 kg (2500 grams)

Do not discard as unsorted waste. To be sent to separate collection facilities for recovery and recycling.

FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS

More info at [Fellowproducts.com/pages/gear-guides](https://fellowproducts.com/pages/gear-guides)

WARNING: READ ALL SAFETY WARNINGS AND INSTRUCTIONS. FAILURE TO FOLLOW THE WARNINGS AND INSTRUCTIONS MAY RESULT IN ELECTRIC SHOCK, FIRE AND/OR SERIOUS INJURY. KEEP THIS SAFETY AND MAINTENANCE MANUAL FOR FUTURE REFERENCE.

IMPORTANT SAFEGUARDS

Before use, please read these safety warnings carefully to use the scale properly. These safety warnings are indicated for the safe and proper use of this product to prevent danger to the user or others and damage to property. When using electrical appliances, basic safety precautions should always be followed, including the following:

- After unpacking the scale, dispose carefully of the plastic bags and other packaging so that children and others cannot reach them.
- The scale should be used on a flat, sturdy surface to ensure accurate measurements.
- Do not immerse any part of the scale in water or other liquid.
- The use of accessory attachments are not recommended by Fellow as it may result in fire, electric shock, or personal injury.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use it within a child's reach.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction

concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

- Do not place where the scale could touch any source of heat. For example, on or near a hot gas burner or electric burner, in a heated oven, or in a microwave.
- Disassemble your scale only as directed in the Cleaning section of this manual.
- Do not use for anything other than intended use. This appliance is intended for household use only. Use for anything other than intended use will void the warranty.
- This product is designed for indoor use.
- Handle with care. Keep the scale in a cool, dry place.
- Do not store the device with objects on the weigh pan.
- Avoid exposure to damp environments or extreme temperatures.
- The max load is 2.5 kg. Exceeding 2.5 kg may damage the device.
- This appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance.
- Use only with Listed/Certified Information Technology (Computer) Equipment or Listed/Certified ITE Power Supply or Listed Class 2 Power Unit for charging purpose.
- Recharge only with the charging requirement specified. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- To prevent unintentional starting, ensure that the switch is in the off position before connecting to a battery pack, picking up or carrying the appliance. Carrying the appliance with your finger on the switch or energizing the appliance while carrying will invite accidents.
- Use appliances only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.
- Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
- Do not use a battery pack or appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire explosion or risk of injury.
- Do not expose a battery pack or appliance to fire or excessive temperature. Exposure to fire or temperature above 130°C may cause explosion.
- Follow all charging instructions and do not charge the battery pack or appliance outside of the temperature range specified in the instructions. Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Do not modify or attempt to repair the appliance or the battery pack (as applicable) except as indicated in the instructions for use and care.
- This appliance contains batteries that are non-replaceable.
- **Warning:** Do not attempt to remove the battery. The appliance will be damaged by attempting to remove the battery. Never operate the appliance after the appliance has been disassembled or battery removed.
- For disposal of the entire assembly, contact your local jurisdiction for proper disposal methods for electronic devices that contain non-removable batteries as according to the local laws and regulations.

SPECIFICATIONS

SPECIFICATIONS	
Approximate Weight	591 g
Capacity	2500 g
Units	g, oz, lbs, mL
Weight Range	0.1 g to 2500 g
Unit Dimensions	176.7 mm x 150 mm x 32.9 mm
Electrical Requirements	5 V, 1 A
Power and Battery	Lithium-ion rechargeable battery 3.7 V 1000 mAh
Display	OLED screen, glass
Warranty	2 years

OPTIMAL TEMPERATURE FOR USING AND STORING TALLY

SPECIFICATIONS	
Approximate Weight	591 g
Capacity	2500 g
Units	g, oz, lbs, mL
Weight Range	0.1 g to 2500 g
Unit Dimensions	176.7 mm x 150 mm x 32.9 mm
Electrical Requirements	5 V, 1 A
Power and Battery	Lithium-ion rechargeable battery 3.7 V 1000 mAh
Display	OLED screen, glass
Warranty	2 years
OPTIMAL TEMPERATURE FOR USING AND STORING TALLY	
Charging / operating ambient range:	5-40° C / 40-104° F
Charging time:	1-2 hours
Storage:	-20-60° C / -4-140° F 90% Relative Humidity

WHAT'S IN THE BOX?

- Tally Pro scale
- USB-C to USB-A Charging Cable
- Get to Know You Guide
- Safety and Maintenance Manual

BATTERY

The device uses a rechargeable lithium polymer battery. You can charge the battery by plugging the USB cable into any of the power supplies listed below with an output of 5 volts and 1 amp:

- A USB wall-charger
- A computer
- A DC car-charger

It takes about 1-2 hours to fully charge the battery from empty. Try not to let the battery completely run out before charging. Charge the battery as needed. When you plug in your scale the remaining battery level will flash on the

screen. When the battery is at 25% or below, the scale's remaining battery level will show upon the device waking or going to sleep. To save battery, the scale's screen will dim after 2 minutes. It will automatically turn off after 10 minutes without use unless it is in timing. When timing the scale will automatically turn off after 20 minutes. Listed/Certified Information Technology (Computer) Equipment or Listed/Certified ITE Power Supply or Listed Class 2 Power Unit.

CARE AND CLEANING

- **CAUTION:** Do not use abrasive pads or harsh chemicals to clean. These may damage the surface of the appliance.
- Tally Pro is water resistant but NOT waterproof. Do not put any part of your scale in the dishwasher. Do not immerse the scale in water or any liquid.
- Always ensure that the scale is turned off before cleaning.
- Only clean with mild detergent cleaner or warm water. Wipe surfaces with a damp, soft cloth or sponge.
- For a more thorough clean, remove the weigh pan to wipe underneath. Use only a damp, soft cloth or sponge when cleaning underneath the weigh pan.

HOW TO REMOVE + REINSTALL WEIGH PAN

1. To remove, first unlock the weigh pan by turning counter-clockwise. A click will be felt.
2. Continue turning about 30 more degrees until the weigh pan disengages.
3. To reinstall, place the weigh pan back in position on the base.
4. Align the four engagement notches and then turn about 30 degrees until a click is felt.

SCALE CALIBRATION

In weigh mode, press both the Dial and the Timer Button for approximately 3 seconds.

IMPORTANT: Ensure you are only using a 50 gram ASTM Class 1 calibration weight for scale calibration in order to guarantee accuracy.

1. Follow instructions on the screen to complete scale calibration.
2. When the screen prompts: "Begin calibration?", select the desired response by turning the dial clockwise/counterclockwise and then press the Dial or the Timer Button to confirm the selection.
3. When the screen prompts: "Place 50 g Weight", place 50 gram weight on the center of the scale weigh pan.
4. The screen will display an animation while the scale is going through calibration.
5. Once calibration is complete, the screen will return you to your previous mode.

FACTORY RESET

1. In Brew Assist Mode, with the coffee-to-water ratio displayed, turn the dial counterclockwise until the ratio becomes 1:1. Next, keep turning the dial until the ratio changes to "rst".
2. Press the Timer Button and the display will then show: Factory Reset? (Yes/No)
3. Select the desired response by turning the dial clockwise/counterclockwise.
4. Press the Dial or the Timer Button to confirm the selection.
 - "No" returns to Brew Assist Mode.

- “Yes” will display the following: “Resetting Device”

5. Wait 3 seconds once displayed, the device will reset itself.

SERVICE

For service, repair, or any questions regarding your appliance, please visit bit.ly/getfellowsupport to submit a request. If you still have questions, reach out to us at help.fellowproducts.com. Do NOT mail the product back to the manufacturer or bring it to a service center without first talking to a Fellow customer service representative.

TWO-YEAR STANDARD WARRANTY

- Fellow warrants this product against any defects that are due
- to faulty material or workmanship for a two-year period after the original date of consumer purchase.

This warranty is valid only for:

- The original consumer.
- Scales purchased through authorized retailers.
- Scales with the original sales receipt for proof of purchase.

This warranty does not include damage to the product resulting from:

- Accidents, misuse, or repairs performed by unauthorized personnel.
- Operation with the wrong type of current or voltage.
- Failure to follow cleaning instructions for the scale.
- Failure to comply with any safeguards listed in the warnings and instructions of this document.

If the product should become defective within the warranty period, or you have questions regarding warranty or service, visit us at help.fellowproducts.com to submit a request.

More info at Fellowproducts.com/pages/gear-guides

FAQ


Q: Can I submerge my Tally Pro scale in water?

A: No, the Tally Pro scale is water-resistant but should not be submerged in water or any other liquid.

Q: How long does it take to fully charge the battery?

A: It takes approximately 1-2 hours to fully charge the battery from empty.

Documents / Resources

 <p>FELLOW TALLY PRO Precision Scale 精密电子秤 精密秤</p> <p>SAFETY AND MAINTENANCE 安全与保养 维护</p> <p>1. Download this safety manual 2. Read the safety manual 3. Follow the safety instructions 4. Do not use the scale if you are unsure 5. If you are unsure, contact your local Fellow representative for assistance</p>	<p>FELLOW TFEAAGB ally Pro Studio Edition Precision Scale [pdf] Instruction Manual TFEAAGB Studio Edition Precision Scale, TFEAAGB, Studio Edition Precision Scale, Edition Pr recision Scale, Precision Scale, Scale</p>
---	---

References

- [!\[\]\(467d80e979964f7f8c752fb22248b5b7_img.jpg\) Fellow - Brew Ridiculously Good Coffee](#)
- [!\[\]\(b71552d33dbf62adf5e5199a70ee02bf_img.jpg\) Gear Guides – Fellow](#)
- [!\[\]\(03134b765d1473836ff001925b1b0550_img.jpg\) Patents – Fellow](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.