



Fengyan 118 Bluetooth Wireless Game Controller Instruction Manual

[Home](#) » [Fengyan](#) » Fengyan 118 Bluetooth Wireless Game Controller Instruction Manual 

Contents

- 1 Fengyan 118 Bluetooth Wireless Game Controller
- 2 Specifications
- 3 Product Usage Instructions
- 4 Wired PC Connection
- 5 Audio Features
- 6 FAQ
- 7 PRODUCT OVERVIEW
- 8 PRODUCT FEATURES
- 9 HOW TO USE: THE OPERATION INSTRUCTIONS
- 10 PRODUCT DETAIL
- 11 FCC STATEMENT
- 12 Documents / Resources
 - 12.1 References

Fengyan

Fengyan 118 Bluetooth Wireless Game Controller



Specifications

- **Size:** 100*150mm
- **Front:** and back printing
- **Model:** 118
- **Platform:** PS4, PC, Android, iOS
- **Connection:** Bluetooth/Wired
- **Key Functions:** PS, SHARE, OPTIONS, touch key, up, down, left, right, L1, L2, L3, R1, R2, R3, Left joystick, Right joystick, Touchpad, Start, D-Pad, Action buttons
- **Features:** Six-axis detection system, full-colour LED lights, touch control area, speaker, voice input
- **Audio Features:** Mono speaker, 3.5mm stereo headset connector
- **Battery Capacity:** 600mAh
- **Working Hours:** 7 hours

Product Usage Instructions

Bluetooth Connection to PS4 Console

1. The first time you connect to the console, you must use a wired connection. After the connection is successful, you can automatically connect to the console by unplugging the wired controller. In the future, you can automatically connect to the console by pressing the PS key on the controller.
2. After multiple controllers are connected to the console, the color of the lights on each player's controller is different.

Bluetooth Connection to Other Devices

1. Press and hold the Share+PS button on the controller for 5 seconds to enter Bluetooth pairing mode. The controller indicator light will be white and quickly blink in double.
2. To connect to Android devices, search for the Bluetooth name "Wireless Controller" on the Android phone.
3. To connect to iOS devices, search for the Bluetooth name "DUALSHOCK 4 Wireless Controller" on the iOS device.

Wired PC Connection

1. Connect the controller to the USB interface of the PC using a USB data cable.
2. After a successful connection, it will be displayed as a “Wireless Controller” device.

Audio Features

- A mono speaker is provided on the controller, and some game voice commands will be issued through the speaker without interfering with the music and sound effects of the game itself.
- There is also a 3.5mm stereo headset connector on the controller, allowing players to choose between single voice or full sound effects as the audio output type.

Six-Axis Function

- The controller features a highly sensitive six-axis detection system, allowing for precise motion control in compatible games.

Touch Function

- The upper middle of the front of the controller is a touch control area.
- The touch area adopts capacitive two-point touch sensing, which can automatically identify single-finger touch and double-finger touch.
- Press anywhere in the touch control area for input.

FAQ

- **Q:** How long does the battery last?
- **A:** The battery has a capacity of 600mAh and can provide up to 7 hours of usage time.
- **Q:** Can I use this controller with a PC?
- **A:** Yes, you can connect the controller to a PC using a USB data cable.
- **Q:** Can I connect this controller to my Android or iOS device?
- **A:** Yes, you can connect the controller to Android devices via Bluetooth by searching for the Bluetooth name “Wireless Controller” on your Android phone. On iOS devices, search for the Bluetooth name “DUALSHOCK 4 Wireless Controller.”


PS4 BLUETOOTH WIRELESS GAME CONTROLLER
MODEL: 118

PRODUCT OVERVIEW

- This product is a DUALSHOCK4 wireless controller paired with a PS4 console.
- It uses wireless Bluetooth connectivity, a highly sensitive six-axis detection system, full-colour LED lights to display different players, and Features: touch, speaker, and voice input.

PRODUCT FEATURES

1. Platform: PS4, PC, Android, iOS.
2. Bluetooth connection/Wire connection.
3. Key: PS, SHARE, OPTIONS, touch the key, up, down, left, right, Four function buttons L1, L2, L3, R1, R2, R3, Left joystick, Right joystick.



4. LED indicator: Full-color LED indicates different players or states.
5. Interface: A Micro B port can be charged, data can also be upgraded online, a headset with a microphone interface, and an expansion connection port.
6. Support dual motor vibration
7. The PS4 console platform has a sensor six-axis body sensing function.
8. Support dual-point capacitive sensing touch control.
9. Built-in mono speaker function.
10. Supports wired PC mode.
11. RGB light effect. There are two light modes: 7-color gradient mode and gradient breathing mode. Switch the light mode and press SELECT+START while double-clicking to turn off the light.

HOW TO USE: THE OPERATION INSTRUCTIONS

BLUETOOTH CONNECTION TO PS4 CONSOLE

1. The first time you connect to the console, you must use a wired connection. After the connection is successful,

you can automatically connect to the console by unplugging the wired controller. In the future, you can automatically connect to the console by pressing the PS key controller.

2. After multiple controllers are connected to the controller, the colour of the lights on each player's controller is different.

BLUETOOTH CONNECTION TO OTHER DEVICES

1. Press and hold the Share+PS button on the controller for 5 seconds, and the controller enters Bluetooth pairing mode. At the same time, the controller indicator light is white and quickly blinking in double. Bluetooth can be used to connect Android devices; The Bluetooth name of the controller on the Android phone is Wireless Controller; The Bluetooth name on the IOS device is DUALSHOCK 4 Wireless Controller.

WIRED PC


1. Connect the console directly to the USB interface of the PC using a USB data cable. After a successful connection, it will be displayed as a Wireless Controller device.

AUDIO FEATURES

A mono speaker is provided on the controller, and some game voice commands will be issued through the speaker without interfering with the music and sound effects of the game itself. At the same time, there is also a 3.5mm stereo headset connector on the controller, which allows players to choose the audio output type of the connector in the system: single voice or full sound effects.

SIX-AXIS FUNCTION

The SIX axis consists of a three-axis gyroscope and a three-axis acceleration sensor. There are Six axes in total, including X, Y, Z, Roll, Pitch, and Yaw. X-axis: Acceleration movement in the left and right directions (X+/X-direction), left → right, right → left. Y-axis: Accelerated movement in the front and rear directions (Y+/Y-direction), front → rear, rear → front. Z-axis: acceleration movement in the up and down direction (Z+/Z-direction), up → down, down → up. Roll axis: Rotate up and down with the Y axis as the centre. Pitch axis: Rotate back and forth with the X axis as the centre. Yaw axis: rotates left and right with the Z axis as the centre.



TOUCH FUNCTION

The upper middle of the front of the controller is a touch control area. The touch adopts capacitive two-point touch sensing, which can automatically identify single-finger touch and double-finger touch. Press anywhere in the touch control area.

PRODUCT DETAIL

- **Sleep current:** 40.2uA
- **Operating current:** \approx 86.5MA
- **Battery capacity:** 600mAh
- **working hours:** \approx 7 hours

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Documents / Resources



[Fengyan 118 Bluetooth Wireless Game Controller](#) [pdf] Instruction Manual
118, 2BCMK-118, 2BCMK118, 118 Bluetooth Wireless Game Controller, Bluetooth Wireless Game Controller, Wireless Game Controller, Game Controller, Controller

References

- [User Manual](#)