



# FIRSTECH FTI-STK1 Forester STD KEY AT Installation Guide

[Home](#) » [FIRSTECH](#) » FIRSTECH FTI-STK1 Forester STD KEY AT Installation Guide 

## Contents

- [1 FIRSTECH FTI-STK1 Forester STD KEY AT Installation Guide](#)
- [2 Documents / Resources](#)
  - [2.1 References](#)
- [3 Related Posts](#)

## FIRSTECH FTI-STK1 Forester STD KEY AT Installation Guide

# FTI-STK1: Notas de preparación y cobertura del vehículo

**RSTECH, LLC.**  
SUPPORT • 1(888) 820-3690, EXT. 203

Make	Model	Year	Install	CAN	IMMO	BCM	Clutch	I/O Changes
DL-SUB9 Subaru	Forester STD KEY AT (Canada)	2019-24	Type 2	40-Pin	Type B	DSD	N/A	Green White/Blue N/A

El vehículo cubierto usa el firmware **BLADE-AL-SUB9** y los siguientes accesorios requeridos, Weblink Hub y ACC RFID1. Actualice el módulo y actualice el firmware del controlador. **Siga las instrucciones para la programación de RFID antes de intentar programe el módulo BLADE al vehículo.**

**CAN:** las conexiones CAN tipo 2 se realizan con el conector BCM de 40 pines y requieren conectar el conector hembra blanco de 2 pines al conector macho negro de 2 pines en el marcador [D] de la ilustración.

**Inmovilizador:** IMMO tipo B requiere conectar los conectores de 2 pines blanco y negro en el marcador [C] de la ilustración.

**Luces:** Las luces de estacionamiento están precableadas en el arnés FTI-STK1. Reemplace el cable verde/blanco del conector CM I/O con el cable verde/blanco preterminado del arnés.

**ACC-RFID1 (REQUERIDO):** El firmware SUB9 no proporciona datos del inmovilizador, por lo que se requiere un ACC-RFID1 para el arranque remoto

**2° ARRANQUE:** El arnés FTI-STK1 está precableado con una salida de 2° ARRANQUE roja/negro (no se requiere en el TIPO 2), corte y aísle el cable proporcionado para evitar cortocircuitos cuando no se utiliza.

**Cambios de E/S:** No se requiere ninguno

**Aviso 1: Programe ACC-RFID1 antes de intentar programar el módulo BLADE en el vehículo.**

**Aviso 2: Asegure todas las conexiones de 2 clavijas, tanto usadas como no usadas, al cuerpo del arnés principal.**

## FTI-STK1 - Notas de instalación y configuración

- A ACCESORIO REQUERIDO**
- B ADAPTADOR NO NECESARIO**
- C CONFIGURACIÓN REQUERIDA (TIPO B IMMO)**
- D CONEXIÓN REQUERIDA**
- E SIN CONEXIÓN**



COBERTURA DE FUNCIONES															
IMMOBILIZER DATA	ARM OEM ALARM	DISARM OEM ALARM	DOOR LOCK	DOOR UNLOCK	PRIORITY UNLOCK	TRUNK/HATCH RELEASE	TACH OUTPUT	DOOR STATUS	TRUNK STATUS	BRAKE STATUS	E-BRAKE STATUS	A/M ALARM CONTROL FROM OEM REMOTE	A/M RS CONTROL FROM OEM REMOTE	AUTOLIGHT CTRL	

• FT-DAS Required for manual transmission.  
• BOTH Red & Red/White MUST be connected with high current application.

**Jumper Setting**

Parking Light Accessory Ignition (Default) (+)Door Trigger In (-)Door Trigger In (Default)


Trunk Starter Ignition Starter Ignition Accessory (Default)

CM7000/7200 Cut loop for A/T

CMX


**CM900AS/900S Jumper**

START ACC IGN1



## CARTRIDGE INSTALLATION

1



Slide cartridge into unit. Notice button under LED.

2

Ready for Module Programming Procedure.

## MODULE PROGRAMMING PROCEDURE

1



For this installation, the Weblink HUB is required.

2



Remove OEM key 1 from keychain.



Place all other keyfobs at least 1 foot away from the Weblink HUB. Failure to comply may result in damage to other keyfobs or interfere with the keyfob reading process.

3



Flash the module using the Weblink HUB. Follow the on screen instructions to complete the keyfob reading process.

4



**WARNING:**  
Do not press the module programming button.  
Connect power first.  
Connect module to vehicle.

5



Using OEM key 1, turn key to ON position.

6



Wait, LED will turn solid BLUE for 2 seconds .


7




Turn key to OFF position.

8

Module Programming Procedure completed.



[FIRSTTECH FTI-STK1 Forester STD KEY AT \[pdf\] Installation Guide](#)  
Type 2 2019-24, FTI-STK1 Forester STD KEY AT, FTI-STK1, Forester STD KEY AT, STD KEY A  
T, KEY AT, AT



[FIRSTTECH FTI-STK1 Forester STD KEY AT \[pdf\] Installation Guide](#)  
SUB9, CM7000-7200, CM7X00, FTI-STK1 Forester STD KEY AT, FTI-STK1, Forester STD KEY  
AT, STD KEY AT, KEY AT, AT

References

- [iDataLink - Home](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.