



[Home](#) » [FLYDIGI](#) » **FLYDIGI APEX 5 Elite Gaming Controller User Manual** 

Contents [[hide](#)]

- [1 FLYDIGI APEX 5 Elite Gaming Controller](#)
- [2 Force Adjustable Joystick Instruction](#)
- [3 Force Feedback Trigger Instruction](#)
- [4 Connect to a Switch](#)
- [5 Connect to an Android/iOS device](#)
- [6 specifications](#)
- [7 Appearance](#)
- [8 FCC Statement](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



FLYDIGI APEX 5 Elite Gaming Controller




Scan the QR code to read the user manual




Force Adjustable Joystick Instruction


1. Remove the joystick cap by pulling it upwards vertically, and take off the D-pad.



2. Remove the magnetic cover from the gap of the grip, and take out the force adjustment paddle from the right side of the controller.



3. Adjust the joystick sensitivity by rotating the screw on the right side of the joystick using the adjustment paddle.
4. You can use the tangent position between the edge of the screw and the scale as a reference to remember the current sensitivity of the joystick.



5. Once the adjustment is complete, you can put the joystick cap back on to conveniently experience the sensitivity in real-time.

Force Feedback Trigger Instruction

Adaptive Mode





According to the real-time changes in the game scene, the force feedback sensation of the triggers is automatically switched. Please access www.flydigi.com on your computer and download “Flydigi Space Station” to enable adaptive mode.

Custom mode


Mode	Introduction
Regular	Force feedback function disabled, regular linear triggers
Race	Simulate the damping sensation when pressing the throttle
Sniper	Simulate the sensation of pressing the trigger on a sniper rifle
Recoil	Simulate the continuous oscillation of the trigger when firing a machine gun in sustained automatic fire
vibration	Simultaneously vibrate with the grip to enhance Immersion
trigger lock	Adjust the trigger travel


Open Flydigi Space Station For Customize Settings

Visit our official website www.flydigi.com to download “Flydigi Space Station”. You can customize buttons, macros, and motion sensing. Joystick and other functions.


 Button mapping	 Macro definition	 Motion sensing mapping	 Joystick adjustment
---	---	---	--

Connect Your Controller

Pull the reel switch of the controller to ON, then short-press the  button to open the menu on the screen, where you can configure the controller mode and button settings.




Connect to a PC

Open the on-screen menu, select [Connect] – [PC], and connect the computer and the controller using a receiver or a cable. Home Capture. If the controller is not used for some time, it will automatically enter sleep mode. Press the  to wake up the controller. You can modify the sleep timeout in the Flydigi Space Station.





Connect to a Switch

Adjust the controller to Switch mode, click on the controllers icon on the home page of your Nintendo Switch, and go to [Change Grip/Order]. The controller will automatically pair and connect.



At Switch mode, the button-to-key mapping is as follows:

A	B	X	Y	SELECT	START			Switch
B	A	Y	X	-	+	Home	Screenshot	

Connect to an Android/iOS device

1. Scan the QR code to download and install the Flydigi Game Hall app.



2. Enter Flydigi Game Hall – Peripheral Management and click on “Add Device”. Follow the instructions provided in the game hall to connect the controller.


specifications

Platform	Mode	Connection method	System Requirement
PC	XInput/DInput	Dongle/Cable/ BT	Win 7 and above
Switch	Switch	BT	Switch
Android	DInput/Flashplay	BT	Android 10 and above
iOS	iOS	BT	iOS 14 and above

- Input Mode: This mode is suitable for games that natively support controllers.
- Din put Mode: This mode is suitable for emulator games that natively support controllers.
- Flashplay mode: This mode is suitable for mobile games that do not support controllers.
- It requires the use of the Flydigi Game Hall app as a companion.
- Wireless RF: BT 5.0, BT 5.0 BLE
- Operating Distance: Less than 10 meters
- Battery Information: Rechargeable lithium-ion battery, battery capacity
- 1 S00mAh, charging time 3-4 hours, charging voltage sSV, charging current l000mA

- Operating Current: Current less than 80mA during use (excluding motors and force feedback triggers), current less than 0.1mA in standby mode
- Temperature Range: Use and store between -10°C and 50°C.

Appearance



The name and content of harmful substances in the product

Part Name	Toxic or Hazardous Substances and Elements					
	Pb	Hg	Cd	Cr	PBB	PBDE
PCB Borad	○	○	○	○	○	○
Shell	○	○	○	○	○	○
Packaging	○	○	○	○	○	○
Wire	○	○	○	○	○	○
Polymer battery	○	○	○	○	○	○
Silicone	○	○	○	○	○	○
Small structural parts such as metal and tape	○	○	○	○	○	○

This form has been prepared under the provisions of SJ/T 11364

- ○ Indicates that the content of the hazardous substance in all homogeneous materials of this part is within the limit specified in GB/T 26572-2011, requiring the following
- ✕ Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the provisions of GB/T 26572-2011, the limited requirements.

FCC Statement

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for Class B digital devices under Part 15 of the FCC Rules.


These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency

energy, and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The device has been evaluated to meet the general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Documents / Resources

	FLYDIGI APEX 5 Elite Gaming Controller [pdf] User Manual APEX 5, APEX 5 Elite Gaming Controller, Elite Gaming Controller, Gaming Controller, Controller
---	--

References

- [User Manual](#)

 Apex 5, APEX 5 Elite Gaming Controller, controller, Elite Gaming Controller, FLYDIGI, Gaming Controller
 FLYDIGI Controller

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.