

FLYDIGI FP2 Game Controller User Manual

Home » FLYDIGI » FLYDIGI FP2 Game Controller User Manual



Flydigi Direwolf 2 Game Controller User Manual

Contents

- 1 FP2 Game Controller
- **2 Connect With Computer**
- 3 Connect to Switch
- 4 Connect an Android/iOS device
- **5 Function**
- **6 Specification**
- 7 Appearance
- **8 FCC Statement**
- 9 Documents / Resources
- **10 Related Posts**

FP2 Game Controller




http://data.flydigi.com/api/web/link?u=1693206714


Scan QR code o read the user manual



Wireless dongle connection



- 1. Plug the dongle into the computer's USB port
- 2. Dial the back gear to



- 3. press the \triangle button, the controller will be connected automatically, and the first indicator light keep in white
- 4. The next time you use it, press the \triangle button once, and the controller will be connected automatically


Wired connection

Connect the computer and the controller through the USB cable, and the Indicator light keep In white, the connection Is successful

BT connection

Connect to Switch

NS



- 1. Clck the controller icon on the Swich
- 2. 5hit the back gear o NS homepage o enter [Change gripforder]




- 3. press the igtriangle bution the contraller il be connested automaticaly. and the frstindicator lght keep in blue
- 4. The next time you use it press the \triangle button once and th controller wil automatially connect

In Switch mode, the key and key-value mapping relationship is as follows

Α	В	Х	Y	SELECT	START	\triangle	0
В	Α	Υ	X		+	home page	Screenshot

switeh

Connect an Android/iOS device





Turn on the device's Bluetooth.con- necto the Xbox Wireless Controller, and the controlle indicator ight keep in whitelight's solid white

The next ime you use it press the \bigcirc button once and the controler wil automatially connect Flydigi Space Station For More Customize Setting

Visit Our official website <u>www.flydigi.com</u> download "Flydigi Space You can customize buttons, macros, body feeling, trigger Statior and other functions.

000	home page
	Macro definition
\$	Somatosensory mapping
2	Joystick adjustment

Function

Turbo

Set up turbo	Press the 0 and Target button at the same time to set the button as a bur st button			
Clear turbo	Press the 0 and burst buttons at the same time to clear the burst function			
Adjust the frequency	Hold down the 0 button while pushing the left stick left/right, Decreases/creases burst frequency			
Supports buttons	ABXY, L, ZL, R, ZR, D-pad, left/right stick press down			

Macro Setting

Rcorsing macro	Long rss O 3nd WLz for e seconds o et th recorang mode, s tme the mcato g o blesch 2.0parate th contrallerto ecor,prss the iz bttonsance o compete e recording "Honiyonebuto i recorded, LMz il b mapped o that uton
Clear Marco	Pressand Hold Qnd MIM21o clean p he et of henacio/mapng

Vibration

Hold down the O button while pushing the leftstick down/up to decteasefincrease the vibration force.

Basic operations

Power on: Press the button once

Power off:switch back gear: After § minutes of no operation, the contraller will automatically wrn off

Low battery: The second indicator flashes red **Charging:** The second indicator keep n red

Fully charged: The second indicator keep in green

Specification

mode	Applicable Platfo rms	Li ht	Connection m ethod	System requiremen ts
	PC	Long press0+X to switch to XInput mode, the indicator is white Long	Dongle/ Wired	Win 7 and Above
*	PC/Android /i0S	press0+A to switch to DInput mod e, the indicator is blue	ВТ	Win 7 and Above An droid 10 and Above i OS 14 and Above
NS	Switch	Blue	BT/Wired	Switch

Xinput mode: suitable or the vast majority of games that natively support controllers

Dinput mode: For emulator games that natvely support controllers

Wireless RF: Bluetooth 5.0

Service distance: lezs than 10 meters


Battery Information: rechargeable inium-fon batiary, battry capacty 800mAR. charging time 2 hours, charging


voliage SV, charging current 500mA

Operating current: fess than 45ma when in use, less than 1044 i standby

Temperature range: 5 C – 45 "C use and storage

Appearance





Q & A Q: The controller cannot be connected? k Please make sure that the back gear of the controller is correct, and press and hold the O, button for three seconds at the same time, the indicator flashes quickly, and the controller enters the pairing state – Pair the receiver: plug in the dongle and use the pin to press the pair button to finish the pairing – Pair Bluetooth: Unpair the device on the Bluetooth settings page, turn Bluetooth on and off, and reconnect

Q: How to upgrade the controller firmware? A: Install the Feizhi space station on the computer, or install the Feizhi game hall on the mobile phone, and upgrade the firmware according to the software boot

Q: Is there an abnormality in the joystick/trigger/body feeling? k Install the Feizhi space station on the computer, enter the test page, and press the guide calibration controller

The name and content of harmful substances in the product

Doub Nove o		Toxic or Hazardous Substances and Elements				
Part Name	Pb	Hg	Cd	Cr	PBB	PBDE
PCB Bored	0	0	0	0	0	0
Sheet	0	0	0	0	0	0
Packaging	0	0	0	0	0	0
%Wes	0	0	0	0	0	0
Polymer battery	0	0	0	0	0	0
Silicone	0	0	0	0	0	0
Small structural parts sucn as metal and tape	0	0	0	0	0	0

This form has been prepared in accordance with the provisions of SJ/T 11364

Indicates that the content of the hazardous substance in all homogeneous materials of this part is within the limit specified in GB/T 26572-2011 Require the following st, Indicates that the content of the hazardous substance in at least one homogeneous material of the n component exceeds the provisions of GB/T 26572-2011 The limited requirements

FCC Statement

This device complies with Pad 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference. (2)This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note:This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Pad 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequence energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an autlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.





<u>FLYDIGI FP2 Game Controller</u> [pdf] User Manual 2AORE-FP2, 2AOREFP2, FP2 Game Controller, Game Controller, Controller

Manuals+,