

FOSCAM V5P 5MP WiFi Security Camera User Guide

Contents

- [1 FOSCAM V5P 5MP WiFi Security Camera](#)
- [2 Tools Required](#)
- [3 Parts](#)
- [4 Instructions](#)
- [5 Using Stand](#)
- [6 Limited Warranty](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

FOSCAM V5P 5MP WiFi Security Camera

Product Information

The Foscam Security Camera is an outdoor FHD security camera that provides high-quality video surveillance. It comes with a network cable, waterproof lid, Wi-Fi antenna, drill hole position template, expansion screws, power adapter, and a quick setup guide. The camera features a spotlight and infrared LED, a microphone, a light sensor, a speaker, LAN and power ports, and a micro SD card slot. It also has safety precautions regarding potential strangulation hazards.

Product Usage Instructions

Setting Up Your Foscam Security Camera

Getting Started

- Check the package contents to ensure you have all the necessary components.
- Follow the provided drill hole position template to install the camera using the screw holes and expansion screws.

Security Tips

- Regularly change the camera's password using a combination of numbers, letters, and special characters.
- Update the camera's software and firmware regularly for the best experience.

Setting Up Your Camera: Connection via the Foscam App (Recommended)

Before You Get Started

- Scan the provided QR code to download and install the Foscam App.
- Ensure your smartphone meets the recommended specifications (iOS version 11 or higher, Android 5.0 or higher with GPU).
- Update the Foscam App to the latest version for the best experience.

WiFi Connection

1. Tighten the antenna clockwise in a vertical position.
2. Plug the power adapter into the camera and wait for the "Ready for WiFi configuration" prompt.
3. Connect your smartphone to your WiFi router.
4. Open the Foscam App and either register a new Foscam account or Sign in if you already have one.
5. Follow the on-screen steps:
 - Tap "My Device" and then "Tap to add a device".
 - Scan the QR code located on your camera or manually add the device using the provided information.
 - Power on the device until it prompts "Hello Foscam".
 - Keep the device and mobile phone close to the router for Wi-Fi configuration.
 - Add the camera to your account.

By following these instructions, you will be able to set up and connect your Foscam Security Camera for monitoring and surveillance purposes.

Tools Required

- 3 mm Allen key
- 5 mm Allen key
- 10 mm wrench

Parts

- Base
- Floor pads x 4
- Base beam
- V-grips x 3
- Stanchion
- Stanchion sleeve
- Stanchion extender
- Long bolt with nut
- Safety latch
- Seatpost holder
- Height adjustment knob
- Short bolts with washers x 6
- Long bolts x 4
- Wheel anchor strap
- Square nuts x 4

Compatibility

- Wheel Size: Small: 20"; Large: 24" – 29".
- Tyre Width: 2.3–6.6 cm (0.9–2.6")

- Max. Seatpost Diameter: 25.4 – 35 mm
- Not suitable for bikes with mudguards in vertical mode.

Warning

For rear wheel use only. Use stand only on a flat, stable surface. The stand is designed to support a bike only—do not sit on the bike while in the stand. Use stand in a place where it is unlikely to cause obstruction, be knocked or bumped, or be interfered with by young children.

Instructions

Assemble Stand

1. Attach floor pads to base and base beam (fig. 1).
2. Insert square nuts—flat side up—into base slot. Slide two nuts toward front of base, leaving the remaining two nuts near rear (fig. 2).
3. Attach V-grips (x 2) to base. Select one of the options below: For large bikes (24 – 29" wheels) Place one V-grip near the front of base, angled rearward over the first pair of nuts. Screw two short bolts into nuts, but do not tighten as further adjustment will be necessary. Repeat this with other V-grip, this time with it angled forward (fig. 3a). For large bikes (24 – 29" wheels) with rear carriers Place one V-grip near the front of the base, angled forward over first pair of nuts. Screw two short bolts into nuts, but do not tighten as further adjustment will be necessary. Repeat this with another V-grip, again with it angled forward (fig. 3b). For small bikes (20" wheels) Place one V-grip near the front of base, angled rearward over first pair of nuts. Screw two short bolts into nuts, but do not tighten as further adjustment will be necessary. Repeat this with another V-grip, again with it angled rearward (Fig. 3c).
4. Attach base beam, logo facing upwards to base by inserting end of base into base beam bracket, matching bolt holes on both. Screw two long bolts into holes on the bracket side that is flat, and tighten (fig. 4).
5. Press the stanchion sleeve into top of the stanchion, matching arch on sleeve with square and round bolt holes on the stanchion (fig. 5).
6. Attach third V-grip to stanchion—for large or small bikes only (do not attach if you are using a large bike with a rear carrier). For large bikes Place V-grip, angled upward over the upper and center bolt holes, screw in the remaining two short bolts, and tighten (fig. 6a). For small bikes Place V-grip, angled upward over the center and lower bolt holes, screw in the remaining two short bolts, tighten (fig. 6b).
7. Attach stanchion to base beam by inserting its bottom end into the vertical bracket—V-grip facing frontward, matching the bolt holes on both. Screw two long bolts into holes on the bracket side that is flat, and tighten (fig. 7).
8. Attach the Seatpost holder to the stanchion extender. Screw in bolt, and tighten using Allen key and wrench in unison (fig. 8).
9. Insert stanchion extender into stanchion—the safety latch must face and open rearward (fig. 9).
10. Screw in height adjustment knob to complete assembly (fig. 9, 10).

Using Stand

1. To adjust stand and store bike in horizontal mode, roll bike onto stand backward until the rear tyre rests against the vertical V-grip (if one is attached). Align the two horizontal V-grips so that they both press against each end of the tyre (fig. 11a, 11b, 11c). Slide V-grip bolts to opposite ends of their slots, and tighten (fig. 12). If your rear

tyre rests firmly against all V-grips, your bike is stored correctly in horizontal mode. Ensure all bolts are tightened securely. Recommended: for extra stability, secure front wheel to the down tube with an anchor strap (fig. 13).

- 2. To store bike in vertical mode, follow the adjustment instructions as above (1). [Note: Your seatpost must be long enough to allow your seat to sit behind the seatpost holder. Remove any bag, light, reflector, etc. attached to your seatpost.] Roll bike onto the stand backward. Secure the front wheel to the down tube with an anchor strap. Open the safety latch, lift bike by the handlebars and stand it up. Lean the bike backwards resting the seatpost in seatpost holder. Close latch. Adjust the height of holder with a knob if necessary (for best results, set the position so that the seatpost slants down slightly rearward) (fig. 14).

Note


Adjust the setup if using a different bike in the stand. To prevent rust, avoid wet environments.

Limited Warranty

Ibera warrants this product for normal usage against workmanship, and material defects to the original purchaser for two year from the purchase date. Products purchased online are not covered by this warranty unless purchased from an authorized Ibera online store.

- 1. User assumes all risk of personal injury, damage to or failure of the product when it is used in jumping, acrobatics or similar activities.
- 2. Warranty does not cover any incidental or consequential damages, such as personal injury or other losses due to accident, neglect, misuse, abuse, modification, normal wear and tear, improper care and cleaning, or failure to follow included instructions. See other Ibera products at www.ibera.info Ibera Co. Ltd.
- 3. Specifications are subject to change without notice. Ibera is a trademark of Ibera Co. Ltd. All other trademarks are the property of their respective owners. Copyright Ibera Co. Ltd. Made in Taiwan. IB-ST21

Documents / Resources

| | |
|---|--|
|  | FOSCAM V5P 5MP WiFi Security Camera [pdf] User Guide ZDEV5P, V5P, 305503000880, V5P 5MP WiFi Security Camera, 5MP WiFi Security Camera, W iFi Security Camera, Security Camera, Camera |
|---|--|