



Home » Foshan » Foshan YCUS100L-C LED String Fairy Light User Manual 📆

Contents [hide]

- 1 Foshan YCUS100L-C LED String Fairy Light
- 2 Description
- 3 Package
- 4 Technical Specifications
- 5 App Connection Instruction
- 6 Connection Precautions
- 7 Use and care instructions
- 8 FCC Statement
- 9 FAQ
- 10 Documents / Resources
 - 10.1 References

Foshan

Foshan YCUS100L-C LED String Fairy Light



Description

These string fairy lights can be used for both residential and commercial decoration. You can use them to decorate yourhomes, shops, pubs, gardens, market stalls and more. They also work great for festival decorations like Halloween, Christmas, New Year's and other holidays to help beautify your space and create a festive celebratory atmosphere.

Package

LED String Light	1 x
User Manual	1 x

Technical Specifications

Model	LED (Power (w)	Adapter to 1st LE D (ft)	String Length (ft)	Total Cable Lengt h (ft)
YCUS10 0L-C	100	6	10	33	43

- Operating Temperature (for all models): -25-40°C
- Transformer Input Voltage (for all models): 120V, ~60 Hz 0.30A
- Transformer Output Voltage (for all models): 30V
- Life (for all models): 30,000h
- The distance between LED Bulbs(for all models): 4inch

App Connection Instruction

- 1. Connect the Smart RGB light to the power adapter.
- 2. Press and hold the button on the power adapter for 4 seconds until the green indicator light flashes rapidly.
- 3. With Wi-Fi and Bluetooth enabled on your phone, launch the Tuya Smart app and search for nearby devices. Select your Smart RGB light to add it.
- 4. Enter your Wi-Fi password. The app will automatically complete the connection setup.
- 5. Once connected, use the Tuya Smart app to control your Smart RGB light (on/off,

Go to App Store/Google Play Store (or scan QR code).

Download and install the Tuya Smart app.



Connection Precautions

- 1. Make sure the device is powered up properly.
- 2. Make sure the lights are in pairing mode (long press the button on the adapter for 4 seconds, the green indicator light will flash quickly).
- 3. Make sure your Wi-Fi is 2.4GHz.
- 4. Make sure that your phone is connected to the same Wi-Fi network as your lights.
- 5. If you are having trouble connecting, try restarting your phone, your lights, and your router. Or update the system of the Tuya app to the latest version.

Attention

- 1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
- 2. Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupter (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- 3. This seasonal use product is not intended for permanent installation or use.
- 4. Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- 5. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- 6. Do not let lamps rest on the supply cord or on any wire.
- 7. Unplug the product when leaving the house, or when retiring for the night, or if left unattended.
- 8. This is an electric product not a toy! To avoid the risk of fire, burns, personal injury, and electric shock it should not be played with or placed where small children can reach it.
- 9. Do not use this product for other than its intended use.

- 10. Do not hang ornaments or other objects from the cord, wire, or light string.
- 11. Do not cover the product with cloth, paper, or any material not part of the product when in use.
- 12. Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- 13. Read and follow all instructions that are on the product or provided with the product.
- 14. SAVE THESE INSTRUCTIONS.
- 15. Do not connect the chain to the supply while it is in the packing.
- 16. Where breakage or damage to lamps occurs, the chain must not be used/energised butdisposed of safely.
- 17. The lamps are not replaceable.
- 18. WARNING- RISK OF ELECTRIC SHOCK IF LAMPS ARE BROKEN OR MISSING.
 DO NOT USE.

Use and care instructions

- a. When the product is placed on a live tree, the tree should be well-maintained and fresh. Do not place on live trees in which the needles are brown or break off easily.
 Keep the live tree holder filled with water.
- b. If the product is placed on a tree, the tree should be well-secured and stable.
- C.Before using or reusing, inspect the product carefully. Discard any products that
 have cut, damaged, or frayed wire insulation or cords, cracks in the lampholders or
 enclosures, loose connections, or exposed copper wire.d. When storing the product,
 carefully remove the product from wherever it is placed, in-cluding trees, branches, or
 bushes, to avoid any undue strain or stress ontheproductconductors, connections, and
 wires.
- e. When not in use, store neatly in a cool, dry location protected from sunlight.

FCC Statement

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with a minimum 20cm distance between the radiator and your body: Use only the supplied antenna

WARNING: To reduce the risk of fire and electric shock:

- a.Do not install on trees having needles, leaves or branch coverings of metal or materials that look like metal.
- b. Do not mount or support wires in a manner that can cut or damage wire insulation.

This equipment generates, uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

WARNING!

Do not connect the light string to the power supply while it is in the packaging. The connecting cable cannot be repaired or replaced. THE LAMPS ARE NOT REPLACEABLE. The lighting chain must not be used without all gaskets being in place. Lighting chains don't intend for interconnection. Do not connect this light string electrically to devices from another manufacturer. CAUTION! Strangulation hazard. Keep out of reach of young children.

The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal.

Manufacturer: Foshan Youcheng Electric Appliance Manufacturing Co., Ltd. Address: 5th Floor, No. 3 Wufang Road, Xijiao Village, Beijiao Town, Shunde District, Foshan, Guangdong, China Contacts: Jason Liang

- Tel: +86-18128719807
- Made in China

FAQ

Q: Can these lights be used outdoors?

 A: Only if marked suitable for indoor and outdoor use. Make sure to follow safety instructions.

- Q: Are the LED bulbs replaceable?
 - A: No, the lamps are not replaceable according to safety guidelines.
- Q: What should I do if I have trouble connecting the lights to the app?
 - A: Make sure to check your Wi-Fi connection, restart devices, and update the
 Tuya app to the latest version for troubleshooting.

Documents / Resources



Foshan YCUS100L-C LED String Fairy Light [pdf] User Manual 2BMKM-YCUS100LC, 2BMKMYCUS100LC, YCUS100L-C LED String Fairy Light, YCUS100L-C, LED String Fairy Light, String Fairy Light, Light

References

- User Manual
- Foshan

Email

◆ 2BMKM-YCUS100LC, 2BMKMYCUS100LC, Fairy Light, Foshan, LED String Fairy Light, String Fairy Light, YCUS100L-C, YCUS100L-C LED String Fairy Light

Leave a comment

Leave a Comment							
Your email address will not be published. Required fields are marked*							
Comment *							
Nama							
Name							

Website		

 $\hfill \square$ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.