

# **FUTECH 008.02 Dice 2 Line Laser Red Instructions**

Home » FUTECH » FUTECH 008.02 Dice 2 Line Laser Red Instructions

FUTECH 008.02 Dice 2 Line Laser Red



## **Contents**

- 1 Parts List
- 2 First use
- 3 Alignment
- 4 Select laser lines
- **5 Transport**
- **6 TECHNICAL**
- **SPECIFICATIONS**
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**

## **Parts List**

## Case

- 1. Laserexit
- 2. Battery compartment


- 3. Tripod thread 1/4"
- 4. Power button
- 5. On-/Off-switch / Transport lock



#### First use


Remove any protective films where applied. Open the battery compartment (5) and insert batteries, please taking care to observe the indicated polarity.

Turn the transportation lock (5) to the "ON" position. The laser is switched on, the pendulum levelling mechanism is released, and the instrument is able to align itself on its own. Make sure that the instrument is not on too much of a slope (within 3°). If the slope of the instrument should exceed 3°, the lasers will flash or will go out automatically



# **Alignment**


Place the device on a stable, horizontal base. It is recommended to install the device on working height. This improves the comfort while working and will result in a higher quality. Usage of a cross line laser with a spindle or telescopic tripod is optimal. The choice of the appropriate tripod immediately impacts the user friendliness of the device. Your device can be used on a tripod with 1/4" screw. In case you use a tripod with a different size of screw, provide the appropriate adapter.



## Select laser lines

#### DICE2

All laser lines are always visible when the laser is on.




## DICE3

When you activate the device, one horizon and one vertical line is activated. Use the (O) to switch on/off laser lines.

A Push 0x (startup) Horizontal line and vertical line

B Push 1x Vertical line

C Push 2x Horizontal line and 2 vertical lines



# **Transport**

It is very important that, during transport, the On/off switch is in the OFF position (pendulum locked). This in order to avoid damage of the device.

## **TECHNICAL SPECIFICATIONS**

| Accuracy               | ± 3mm / 10m        |
|------------------------|--------------------|
| range with receiver    | not applicable     |
| levelling range        | ± 3°               |
| Levelling              | pendulum levelling |
| slope function         | not applicable     |
| laser wavelength       | 635nm              |
| laser classification   | class ii           |
| power supply           | 3x alkaline aaa    |
| Protection             | ip44               |
| dimensions (I x w x h) | 65 x 65 x 65 mm    |
| Weight                 | 0,230 kg           |



#### **Documents / Resources**



## FUTECH 008.02 Dice 2 Line Laser Red [pdf] Instructions

008.02 Dice 2 Line Laser Red, 008.02, Dice 2 Line Laser Red, 2 Line Laser Red, Line Laser Red, Laser Red, Laser Red, Laser Red

#### References

#### • User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.