



Home » Garmin » GARMIN 04939 Navigation Device User Guide 📆

Contents [hide]

- 1 GARMIN 04939 Navigation Device
- 2 Product Information
- 3 Product Usage Instructions
- 4 IMPORTANT SAFETY AND PRODUCT INFORMATION
- 5 FCC Warnings
- 6 GPS Notice
- 7 FCC Compliance
- 8 Frequently Asked Questions (FAQ)
- 9 Documents / Resources
 - 9.1 References

GARMIN

GARMIN 04939 Navigation Device



Product Information

Specifications:

• Device Type: Navigation System

• Power Source: Lithium-ion Battery

 Warnings: Includes distraction, vehicle installation, battery, device, magnet, and hearing damage warnings

Product Usage Instructions

Navigation Warnings

When using the navigation system, always ensure safe navigation practices are followed. Avoid becoming distracted by the device while driving and maintain awareness of driving conditions. Minimize screen viewing time while driving.

Distraction Warning

Use the device for enhanced situational awareness. Avoid prolonged staring at the display to prevent distractions that could lead to accidents. Glance at the information displayed and maintain awareness of surroundings.

Vehicle Installation Warnings

Ensure the device does not obstruct the driver's view or interfere with driving controls. Do not use the device for precise measurements related to driving. Consider environmental factors before off-road activities.

Battery Warnings

Follow guidelines for lithium-ion battery use to prevent damage, fire, or injury risks.

Avoid unauthorized modifications that could damage the device or violate regulations.

Device Warnings

Avoid using devices with magnets near medical devices like pacemakers. Prevent hearing damage by limiting exposure to loud device sounds.

IMPORTANT SAFETY AND PRODUCT INFORMATION

WARNING


Failure to heed the following warnings could result in death, serious injury, or property damage.

Distraction Warning

This device is intended to enhance the situational awareness when used properly. If used improperly, you could become distracted by the display, which could lead to an accident causing serious personal injury or death. Only access the information displayed on the device with a glance. Always maintain awareness of your surroundings and do not stare at the display or become distracted by the display. Focusing on the display could prevent you from avoiding obstacles or hazards.

Vehicle Installation Warnings

When installing the device in a vehicle, do not place the device where it obstructs the
driver's view of the road or interferes with vehicle operating controls, such as the
steering wheel, foot pedals, or transmission levers. Do not place unsecured on the
vehicle dashboard. Do not place the device in front of or above any airbag.



The windshield mount may not stay attached to the windshield in all circumstances.
 Do not place the mount where it will become a distraction if it should become detached. Keep your windshield clean to help ensure that the mount stays on the windshield.

Navigation Warnings

If your Garmin® device uses or accepts map data, follow these guidelines to ensure safe navigation.

- Always use your best judgment, and operate the vehicle in a safe manner. Do not become distracted by the device while driving, and always be fully aware of all driving conditions. Minimize the amount of time spent viewing the device screen while driving.
- Do not input destinations, change settings, or access any functions requiring prolonged use of the device controls while driving. Pull over in a safe and legal manner before attempting such operations.
- Always use your best judgment and exercise common sense when making
 navigational decisions. The device is designed to provide route suggestions only. It is
 not a replacement for attentiveness and good judgement. Do not follow the route
 suggestions if they suggest an illegal course or would put you in an unsafe situation.
- Always carefully compare information displayed on the device to all available
 navigation sources, including weather conditions, maps, street/trail signs and
 conditions, waterway restrictions, and other factors that may affect safety. Always
 resolve any discrepancies or questions before continuing navigation, and defer to
 posted signs and conditions.
- Use this device only as a navigational aid. Do not attempt to use the device for any purpose requiring precise measurement of direction, distance, location, or topography.
- Always be mindful of the effects of the environment and the inherent risks of the
 activity before embarking on off-road activities, especially the impact that weather and
 weather-related trail conditions can have on the safety of your activity. Ensure that you

have the proper gear and supplies for your activity before navigating unfamiliar paths and trails.

Battery Warnings

A lithium-ion battery is used in this device. If these guidelines are not followed, batteries may experience a shortened life span or may present a risk of damage to the device, fire, chemical burn, electrolyte leak, and/or injury.

- Do not expose the device or batteries to fire, explosion, or other hazard.
- Do not disassemble, modify, remanufacture, puncture, or damage the device or batteries.
- Do not remove or attempt to remove the non-user-replaceable battery.

Device Warnings

- Do not immerse the device or batteries in water or other liquids.
- To avoid possible device damage, do not leave the device exposed to a heat source or in a high-temperature location, such as in the sun in an unattended vehicle.
- Do not operate the device outside of the following temperature range: from -20° to 55°C (from -4° to 131°F). Do not store the device for an extended time period outside of the following range: from 0° to 25°C (from 32° to 77°F).
- Do not use a power cable, data cable, and/or power adapter that is not supplied by Garmin or is not properly certified.

Magnet Warning

Both the device and its mount may contain magnets. Under certain circumstances, magnets may cause interference with some internal medical devices, including pacemakers and insulin pumps. Devices and mounts that contain magnets should be kept away from such medical devices.

Hearing Damage Warning

You can permanently damage your ears and lose hearing if you listen to the device, earbuds, or headphones at high volume. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked.

FCC Warnings

- Exposure to Radio Frequency Signals— Your device is a radio transmitter and receiver. When it is on, it receives and also sends out radio frequency (RF) signals.
- Antenna Care
 Use only the supplied antenna or a recommended antenna accessory. Unauthorized antennas, modifications, or attachments could damage the radio and may violate FCC regulations. Warning: Do not use any radio that has a damaged antenna, because if it comes into contact with your skin, a minor burn can result.
- Electronic Devices

 – Most modern electronic equipment is shielded from RF signals.
 However, certain equipment may not be shielded against the RF signals from your wireless radio.
- Pacemakers— The Health Industry Manufacturers Association (HIMA) and Wireless Technology Research recommend that a minimum separation of six inches (6") be maintained between a handheld wireless radio and a pacemaker to avoid potential interference with the pacemaker. Persons with pacemakers should ALWAYS keep the radio more than six inches from their pacemaker when the radio is turned on, should not carry the radio in a breast pocket, and should turn the radio off immediately if you have any reason to suspect that interference is taking place.
- Hearing Aids

 Some digital wireless radios may interfere with some hearing aids. In
 the event of such interference, you may want to consult your hearing aid manufacturer
 to discuss alternatives.
- Posted Facilities— Turn your radio OFF in any facility where posted notices so
 require. Vehicles—RF signals may affect improperly installed or inadequately shielded
 electronic systems in motor vehicles. Check with the manufacturer or its
 representative regarding your vehicle. You should also consult the manufacturer of
 any equipment that has been added to your vehicle.
- Commercial Aircraft

 Many commercial airlines prohibit the use of radios on board.
 Switch OFF your radio before boarding an aircraft or check the airline rules.
 Potentially Explosive Atmospheres

 Turn your radio OFF and do not remove your battery when you are in any area with a potentially explosive atmosphere. Obey all signs and instructions. Sparks from your battery in such areas could cause an explosion or fire resulting in bodily injury or even death.

NOTICE

Failure to heed the following notices could result in personal or property damage, or negatively impact the device functionality.

Windshield Mounting Legal Restrictions

Before using the device on your windshield, check the state and local laws and ordinances where you drive. Some state laws prohibit or restrict the placement of objects on the windshield of a motor vehicle. IT IS THE USER'S RESPONSIBILITY TO MOUNT THE DEVICE IN COMPLIANCE WITH ALL APPLICABLE LAWS AND ORDINANCES. Where required, other Garmin dashboard or friction mount options should be used. Always mount your Garmin device in a location that does not obstruct the driver's view of the road. Garmin does not assume any responsibility for any fines, penalties, or damages that may be incurred as a result of any state or local law or ordinance relating to the use of your Garmin device.

Battery Notices

Contact your local waste disposal department to dispose of the device/batteries in accordance with applicable local laws and regulations.

Speed Limit Notice

The speed limit feature is for information only and does not replace the driver's responsibility to abide by all posted speed limit signs and to use safe driving judgment at all times. Garmin will not be responsible for any traffic fines or citations that you may receive for failing to follow all applicable traffic laws and signs.

Magnet Notice

Both the device and its mount may contain magnets. Under certain circumstances, magnets may cause damage to some electronic devices, including hard drives in laptop computers. Use caution when devices and mounts that contain magnets are near electronic devices.

GPS Notice

The navigation device may experience degraded performance if you use it in proximity to any device that uses a terrestrial broadband network operating close to the frequencies used by any Global Navigation Satellite System (GNSS), such as the Global Positioning

Service (GPS). Use of such devices may impair reception of GNSS signals.

Product Environmental Programs

Information about the Garmin product recycling program and WEEE, RoHS, REACH, and other compliance programs can be found at garmin.com/aboutGarmin/environment.

Declaration of Conformity

Hereby, Garmin declares that this product is in compliance with the Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: garmin.com/compliance.

UK Declaration of Conformity

Hereby, Garmin declares that this product is in compliance with the relevant statutory requirements. The full text of the declaration of conformity is available at the following internet address: garmin.com/compliance.

Innovation, Science and Economic Development Canada Compliance

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. this device may not cause interference
- 2. this device must accept any interference, including interference that may cause undesired operation of the device.

Radio Frequency Radiation Exposure

This device is a mobile transmitter and receiver that uses an internal antenna to send and receive low levels of radio frequency (RF) energy for data communications. The device emits RF energy below the published limits when operating in its maximum output power mode and when used with Garmin authorized accessories. To comply with RF exposure compliance requirements, the device should be installed and operated with a minimum of 20 cm (7.87 in.) between the device and your body. The device should not be used in other configurations. This device must not be co-located or operated in conjunction with any other transmitter or antenna.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications if not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This product does not contain any user-serviceable parts. Repairs should only be made by an authorized Garmin service center. Unauthorized repairs or modifications could result in permanent damage to the equipment, and void your warranty and your authority to operate this device under Part 15 regulations.

VHF Radio Information

This product may be used only on specific radio frequencies, which vary depending on the country of use. The device allows the user to install a different antenna. Changing the antenna can result in improved radio performance and higher radiated power. You must not use the device with a third party antenna or an antenna not approved by Garmin.

Map Data Information

Garmin uses a combination of governmental and private data sources. Virtually all data sources contain some inaccurate or incomplete data. In some countries, complete and accurate map information is either not available or is prohibitively expensive.

Consumer Limited Warranty

- THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER LEGAL RIGHTS, WHICH VARY FROM STATE TO STATE (OR BY COUNTRY OR PROVINCE). GARMIN DOES NOT EXCLUDE, LIMIT OR SUSPEND OTHER LEGAL RIGHTS YOU MAY HAVE UNDER THE LAWS OF YOUR STATE (OR COUNTRY OR PROVINCE). FOR A FULL UNDERSTANDING OF YOUR RIGHTS, YOU SHOULD CONSULT THE LAWS OF YOUR STATE, COUNTRY OR PROVINCE.
- Non-aviation products are warranted to be free from defects in materials or workmanship for one year from the date of purchase. Within this period, Garmin will, at its sole option, repair or replace any components that fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor, provided that the customer shall be responsible for any transportation cost. This Limited Warranty does not apply to: (i) cosmetic damage, such as scratches, nicks and dents; (ii) consumable parts, such as batteries, unless product damage has occurred due to a defect in materials or workmanship; (iii) damage caused by accident, abuse, misuse, water, flood, fire, or other acts of nature or external causes; (iv) damage caused by service performed by anyone who is not an authorized service provider of Garmin; (v) damage to a product that has been modified or altered without the written permission of Garmin; (vi) damage to a product that has been connected to power and/or data cables that are not supplied by Garmin or damage to a product that has been connected to AC adapters and cables that are not certified by UL (Underwriters Laboratories) and are not labeled as Limited Power Source (LPS). In addition, Garmin reserves the right to refuse warranty claims against products or services that are obtained and/or used in contravention of the laws of any country. Garmin navigation products are intended to be used only as a travel aid and must not

be used for any purpose requiring precise measurement of direction, distance, location or topography. Garmin makes no warranty as to the accuracy or completeness of map data. This Limited Warranty also does not apply to, and Garmin is not responsible for, any degradation in the performance of any Garmin navigation product resulting from its use in proximity to any handset or other device that utilizes a terrestrial broadband network operating on frequencies that are close to the frequencies used by any Global Navigation Satellite System (GNSS) such as the Global Positioning Service (GPS). Use of such devices may impair reception of GNSS signals.

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE
 WARRANTIES AND REMEDIES CONTAINED IN THIS LIMITED WARRANTY ARE
 EXCLUSIVE AND IN LIEU OF, AND GARMIN EXPRESSLY DISCLAIMS, ALL OTHER
 WARRANTIES AND REMEDIES, WHETHER EXPRESS, IMPLIED, STATUTORY, OR
 OTHERWISE, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF
 MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, STATUTORY
 REMEDY OR OTHERWISE. THIS LIMITED WARRANTY GIVES YOU SPECIFIC
 LEGAL RIGHTS, AND YOU MAY HAVE OTHER LEGAL RIGHTS, WHICH VARY
 FROM STATE TO STATE AND FROM COUNTRY TO COUNTRY. IF IMPLIED
 WARRANTIES CANNOT BE DISCLAIMED UNDER THE LAWS OF YOUR STATE OR
 COUNTRY, THEN SUCH WARRANTIES ARE LIMITED IN DURATION TO THE
 DURATION OF THIS LIMITED WARRANTY. SOME STATES (AND COUNTRIES AND
 PROVINCES) DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED
 WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.
- IN NO EVENT SHALL GARMIN BE LIABLE IN A CLAIM FOR BREACH OF WARRANTY FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT OR FROM DEFECTS IN THE PRODUCT. SOME STATES (AND COUNTRIES AND PROVINCES) DO NOT ALLOW THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.
- If during the warranty period you submit a claim for warranty service in accordance
 with this Limited Warranty, then Garmin will, at its option: (i) repair the device using
 new parts or previously used parts that satisfy Garmin's quality standards, (ii) replace
 the device with a new device or a Garmin Recertified device that meets Garmin's

quality standards, or (iii) exchange the device for a full refund of your purchase price. SUCH REMEDY SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY. Repaired or replaced devices have a 90-day warranty. If the device sent in is still under its original warranty, then the new warranty is 90 days or to the end of the original 1-year warranty, whichever is longer.

- Before seeking warranty service, please access and review the online help resources
 available on support.garmin.com. If your device is still not functioning properly after
 making use of these resources, contact a Garmin Authorized service facility in the
 original country of purchase or follow the instructions on support.garmin.com to obtain
 warranty service.
- If you are in the United States, you can also call 1-800-800-1020.
- If you seek warranty service outside of the original country of purchase, Garmin cannot guarantee that the parts and products needed to repair or replace your product will be available due to differences in product offerings and applicable standards, laws and regulations. Accordingly, Garmin may, in its sole discretion and subject to applicable laws, repair your product with comparable parts or replace your product with a comparable Garmin product (new or a Garmin Recertified replacement), or require you to ship your product to a Garmin Authorized Service facility in the country of original purchase or to a Garmin Authorized service facility in another country that can service your product, in which case you will be responsible for complying with all applicable import and export laws and regulations and for paying all custom duties, V.A.T., shipping fees and other associated taxes and charges. In some cases, Garmin and its dealers may be unable to service your product in a country outside of the original country of purchase or return a repaired or replaced product to you in that country due to applicable standards, laws or regulations in that country.

Online Auction Purchases: Products purchased through online auctions are not eligible for rebates or other special offers from Garmin warranty coverage. Online auction confirmations are not accepted for warranty verification. To obtain warranty service, an original or copy of the sales receipt from the original retailer is required. Garmin will not replace missing components from any package purchased through an online auction. International

Purchases: A separate warranty may be provided by international distributors for

devices purchased outside the United States depending on the country. If applicable, this warranty is provided by the local in-country distributor and this distributor provides local service for your device. Distributor warranties are only valid in the area of intended distribution. Devices purchased in the United States or Canada must be returned to the Garmin service center in the United Kingdom, the United States, Canada, or Taiwan for service

Australian Purchases: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits under our Limited Warranty are in addition to other rights and remedies under applicable law in relation to the products. Garmin Australasia, 30 Clay Place, Eastern Creek, NSW 2766, Australia. Phone: 1800 235 822.

Frequently Asked Questions (FAQ)

- How should I clean the windshield to ensure the mount stays on?
 Use a clean cloth and mild detergent to clean the windshield. Ensure it is dry before attaching the mount.
- What should I do if I suspect hearing damage from listening to the device?

 Stop listening immediately and have your hearing checked by a professional.

Documents / Resources



GARMIN 04939 Navigation Device [pdf] User Guide 04939, IPH-04939, IPH04939, 04939 Navigation Device, 04939, Navigation Device, Device

References

User Manual

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *			
Name			
Email			
Website			
☐ Save my name, email, and website in this browser for the next time I comment.			
Post Comment			
Search:			
e.g. whirlpool wrf535swhz	Search		

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.