

GE current WWD2-2SM Daintree Networked Wireless Wall Dimmer Installation Guide

Home » GE current » GE current WWD2-2SM Daintree Networked Wireless Wall Dimmer Installation Guide






a Daintree company

WWD2-2SM Daintree Networked Wireless Wall Dimmer Installation Guide







BEFORE YOU BEGIN

Read these instructions completely and carefully. Save these instructions for future use.



RISK OF ELECTRIC SHOCK

• Disconnect power before service installation, or maintenance of the product.

RISK OF FIRE

• Follow all relevant IEC or UL instructions and local building codes.

RISK OF INJURY

Wear safety glasses and gloves during installation and servicing.

FCC / IC COMPLIANCE STATEMENTS

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science, and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

IMPORTANT

To ensure the product warranty is valid, please ensure all installation instructions and environmental conditions for storage and operation are complied with.

Installation to be performed by factory-trained or qualified personnel.

Save These Instructions

Use only in the manner intended by the manufacturer. If you have any questions, contact the manufacturer.


Contents

- 1 Installation
- 2 Network Reset
- 3 Battery Replacement
- **4 Product Dimensions**
- **5 Technical Data**
- 6 Documents /


Resources

- **6.1 References**
- **7 Related Posts**


Installation



1. Use a standard screwdriver to open the faceplate, Pull the plastic insulation strip out of the battery compartment.




2. If you want to install it on the junction box, a cross screwdriver to lock the device on the




3. Install the faceplate onto the device.

Note: The device supports the use of other standard faceplates on the market.




4. If you want to install the device on the wall, stick the device firmly on the wall.



You can also hand-held use the device in the CSM signal cover area.


Network Reset




To reset the network of the device, remove the faceplate from the device. Then press and hold the reset button for 5 seconds. Install the faceplate back onto the device.

Press either the dimming up or down button to enter the pairing mode to join the device to a network.

Battery Replacement



Product Dimensions



Technical Data


Product Specifications

Dimensions	114mm H x 70mm W x 15mm D
Weight	130g
Power Supply	(4) AAA1.5V battery
battery life	5yr (normal operation)
Operating Environment	-10°C to 40°C Indoor Use Only)
Status indicator	Network joined/Button triggered
Mounting	Surface-mounted, screw hole in the backplate, the cover could be removed, handheld
Warranty	5 years

Product Availablity

SKU	DESCRIPTION	ARTICLE-NO.
93141315	Daintree® Networked Wireless Wall Dimmer	WWD2-2SM

Product Certifications



Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Model No: WWD2-2SM

Product Name: Wireless Wall Dimmer

Suppliers Name: Current Lighting Solutions, LLC

Suppliers Address (USA): 1975 Noble Road, East Cleveland, OH 44112 Suppliers phone number and / or internet contact information: 1-866-855-8629

www.gecurrent.com

© 2020 Current Lighting Solutions, LLC. All rights reserved. GE and the GE monogram are trademarks of the General Electric Company and are used under license. Information provided is subject to change without notice. All values are design or typical values when measured under laboratory conditions.

CTRL027 (Rev 07/05/20) Enovia - A-1025984

Documents / Resources



<u>GE current WWD2-2SM Daintree Networked Wireless Wall Dimmer</u> [pdf] Installation Guide WWD2SM, 2AS3F-WWD2SM, 2AS3FWWD2SM, WWD2-2SM, Daintree Networked Wireless Wall Dimmer

References

• C Commercial Lighting and Lighting Controls | Current - GLI Brands

Manuals+,