



# GE 93983LO Random Sparkle 150 Count 43.4 ft Sparkling Clear LED Plug In Christmas String Lights Instruction Manual

[Home](#) » [GE](#) » GE 93983LO Random Sparkle 150 Count 43.4 ft Sparkling Clear LED Plug In Christmas String Lights Instruction Manual 

## Contents

- [1 GE 93983LO Random Sparkle 150 Count 43.4 ft Sparkling Clear LED Plug In Christmas String Lights](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 IMPORTANT SAFETY INSTRUCTIONS](#)
- [5 USE AND CARE INSTRUCTIONS](#)
- [6 Documents / Resources](#)



**GE 93983LO Random Sparkle 150 Count 43.4 ft Sparkling Clear LED Plug In Christmas String Lights**



## Product Information

The StayBrightRandom Sparkle 150 LED Microbright Lights are a seasonal-use lighting product designed to add sparkle and ambiance to your indoor or outdoor space. These lights are manufactured by Nicolas Holiday Ltd., a company located at 246 Spring Hill Road, Unit B, Trumbull CT 06611, United States. The NHL Model No. 93983LO is a variant of these lights specifically designed for NHL fans, featuring the official NHL branding. The lights are powered by a GV-23 Seasonal-Use LED Driver, which ensures safe and efficient electrical operation. The product is also available in a Spanish version with the name StayBrightRandom Sparkle 150 LED Luces En Microbrillantes (Modelo No. 93983LO). Nicolas Holiday Ltd. also has a business presence in Hong Kong, located at Suite 2706 Skyline Tower, 39 Wang Kwong Road, Kowloon Bay, Kowloon, Hong Kong All rights reserved. © 2023 Nicolas Holiday Ltd.

## Product Usage Instructions

1. Inspect the lights and driver for any visible damage before use. Do not use if damaged.
2. Plug the LED driver into a suitable power outlet.
3. Connect the StayBrightRandom Sparkle 150 LED Microbright Lights to the LED driver using the provided connectors.
4. Ensure all connections are secure and properly aligned.
5. Switch on the LED driver to activate the lights.
6. The lights will now emit a random sparkling effect, adding a festive touch to your space.
7. To switch off the lights, turn off the LED driver or disconnect it from the power outlet.
8. After use, carefully disconnect the lights from the LED driver and store them in a safe and dry place.
9. Do not expose the lights to excessive moisture or extreme temperatures.
10. Refer to the user manual for any additional safety precautions and maintenance instructions.

## IMPORTANT SAFETY INSTRUCTIONS

When using electric products, basic precautions should always be followed including the following:

### READ & FOLLOW ALL SAFETY INSTRUCTIONS

1. This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not

be played with or placed where small children can reach it.

2. Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
3. Do not use this product for other than its intended use.
4. This seasonal use product is not intended for permanent use or installation.
5. Unplug when leaving the house, when retiring for the night, or if left unattended.
6. Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
7. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
8. Do not hang ornaments or other objects from cord, wire, or light string.
9. Do not place lighting string on carpeting, drapes, furniture, or allow it to contact vinyl siding while the power is on.
10. Do not perform any maintenance or troubleshoot for bad or broken lamps while the power is on.
11. Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
12. Do not cover the product with cloth, paper or any material not part of the product when in use.
13. Do not let lamps rest on the supply cord or on any wire.
14. Do not use in a bathroom.
15. Please plug into a 120V 60Hz electrical outlet.
16. Mount the unit at a height greater than 1 foot(0.3m from the ground surface.
17. Read and follow all instructions that are on the product or provided with the product.

## **SAVE THESE INSTRUCTIONS**


## **USE AND CARE INSTRUCTIONS**

1. Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the lamp holders or enclosures, loose connections, or exposed copper wire.
2. Before storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
3. When not in use, store neatly in a cool, dry location protected from sunlight.
4. When the product is used on a live tree. the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
5. If the product is placed on a tree, the tree should be well secured and stable.
6. Do not impact or drop the transformer. if enclosure is broken or cracked. discard product.
7. The product and power unit shall not be installed within 10 feet of a pool, spa, fountain, or other areas of standing water.

## **WARNING:.**

1. Do not use where only part of the power unit is padded or fontah or water outlet boxes where there is only a partial cover shall not be used for outdoor installations).
2. This power unit is intended to be correctly oriented in a vertical or floor mount position.
3. If the connector of this lighting string does not properly fit into the connector of the driver, do not modify the product and discard product if the connector is damaged.

**NOTE:** Use only this GE branded, Seasonal-Use LED Driver Model TS-8W29V, manufactured by Guang Zhou Ting shen Electric Co,Ltd that was provided with this product. DO NOT use this adapter with any other product.



**NOTE:** LEDs in this set are non-replaceable. Tampering with this set will void the warranty.

## CAUTION

1. This light string is rated 192 Watts 0.16 Amps), do not overload. GE StayBright® light sets come pre-attached to a plug. For end-to-end connections up to two (2) sets, you will need only one (1) plug. To begin, choose one (1) set as your master set. This set would be the only set connected to a plug. Next, unscrew the coaxial connector between the light set on all of the sets you would connect to your master set. Lastly, connect each set of lights end-to-end using the coaxial connections, screwing each connection cap tightly.
  - **Note:** you may only add one(1) additional sets to your master set for a total of two(2) connected sets.
2. To reduce the risk of fire electric shock: a) Do not install on trees having needles, leaves or branch coverings of metal or materials that look like metal, and b) Do not mount or support strings in a manner that can cut or damage wire insulation.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For questions and/or assistance, call customer service at 1-877-398-7337 or visit us on the web at [www.GEholidaylighting.com](http://www.GEholidaylighting.com)

FOR INDOOR AND OUTDOOR USE MADE IN CHINA PRINTED IN CHINA GV-23  
Nicolas Holiday Ltd. 246 Spring Hill Road, Unit B, Trumbull CT 06611 © 2023 Nicolas Holiday Ltd., Suite 2706

Documents / Resources

	<p><a href="#">GE 93983LO Random Sparkle 150 Count 43.4 ft Sparkling Clear LED Plug In Christmas String Lights</a> [pdf] Instruction Manual</p> <p>93983LO Random Sparkle 150 Count 43.4 ft Sparkling Clear LED Plug In Christmas String Lights, 93983LO, Random Sparkle 150 Count 43.4 ft Sparkling Clear LED Plug In Christmas String Lights, Clear LED Plug In Christmas String Lights, Plug In Christmas String Lights, String Lights</p>
---	---