




Geevon Display Unit T208666 User Manual

[Home](#) » [Geevon](#) » Geevon Display Unit T208666 User Manual 



T208666 Manual



Contents

- [1 Features & Benefits:](#)
- [2 Package Contents:](#)
- [3 TROUBLESHOOTING](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Features & Benefits:

DISPLAY UNIT

1. C/F button
2. Temperature display
3. Comfort display
4. Humidity display
5. Wall mount hole
6. Stand bracket
7. Magnetic back
8. Battery Compartment 1xAAA (batteries included)

Package Contents:

1. Display Unit
2. Instructions Manual
3. 1*AAA alkaline battery

Installing or Replacing Batteries:

We recommend using high-quality batteries for the best product performance. Heavy duty or rechargeable batteries are not recommended.

Keys Details:

C/F button: Press the C/F button to confirm the temperature units.

Indoor temperature and humidity

Temperature

1. Indoor temperature -40°C ~ 70°C (-40°F ~ 158°F),display
-40°C when below -40°C and display 70°C when higher than 70°C.
2. Temperature resolution: 0.1°F
3. Temperature measurement time: every 10 seconds.

Humidity

- 1 Indoor humidity range: 10%-99%,display 10% when
below 10% and display 99% when higher than 99%.
4. Humidity resolution: 1 %RH

Accuracy

Temperature accuracy:

-40°F ~ -4°F, 140°F~158°F: $\pm 7.2^{\circ}\text{F}$

-4°F ~ 32°F, 122°F~140°F: $\pm 3.6^{\circ}\text{F}$

32°F ~122°F: $\pm 1.8^{\circ}\text{F}$

Humidity accuracy: $\pm 5\%$ RH (@25°C(77°F) , 20%RH to 90%RH)

Indoor Comfort Display:


" Low" Icon	10% to 39%
" OK" Icon	40% to 75%
"High" Icon:	76% to 99%

TROUBLESHOOTING

Problem	Possible Solution
Couldn't Power On	<ol style="list-style-type: none"> 1. Please confirm that if there's any water leaked in the unit or the internal components get damaged. 2. Please put the new battery in (use 1 AAA battery). We recommend using high-quality batteries for the best product performance. Heavy duty or rechargeable batteries are not recommended.
Numbers Of Temperature and Humidity Flashed	If you have just received the product, please leave it for a few hours after disassembly and installation.
If your Geevon product does not operate properly after trying the troubleshooting steps, contact the seller on your order page or shoot an email to : support@geevon.com .	

Inaccurate Temperature/ Humidity	<ol style="list-style-type: none"> 1. Make sure the main unit is placed out of direct sunlight and away from any heat sources or vents. 2. Make sure the display is positioned away from moisture sources. 3. Do not tamper with the internal components. 4. Temperature accuracy: -40°F ~ -4°F, 140°F~158°F: ± 7.2°F -4°F ~ 32°F, 122°F~140°F: ± 3.6°F 32°F ~122°F: ± 1.8°F 5. Humidity accuracy: +/- 5 % RH (@25°C(77°F) , 20%RH to 90%RH)
Couldn't Use It Outside	This is an indoor thermometer measuring indoor temperature and humidity. You can view the other Geevon products on Amazon to choose what you need.
Care And Maintenance	<ol style="list-style-type: none"> 1. Do not clean any part of the product with benzene, thinner, or other solvent chemicals. When necessary, clean it with a soft cloth. 2. Never immerse the product in water. This will damage the product. 3. Do not subject the product to extreme force, shock, or fluctuations in temperature.

Documents / Resources

	Geevon Display Unit T208666 [pdf] User Manual Display Unit, T208666, Geevon
---	--

