

Generic T15 Wireless Detector Instructions

Home » Generic T SWireless Detector Instructions





Contents

- 1 Product schematics
- 2 Common problem
- 3 Basic parameters
- 4 Applicable people (scope)
- 5 Scope of application
- 6 Documents / Resources
 - 6.1 References
- 7 Related Posts

Product schematics



A:Detection of radio waves (wireless cameras/eavesdroppers, etc.)

- 1. Long press the power switch of for 3-5 seconds, hear a beep sound, release your finger, and the blue indicator light will light up. When turned on, it will default to detecting the wireless camera and wireless tracker mode.
- 2. If the blue light is flashing and there is a voice prompt it means there is an emission source. The more blue light signal indicators, the stronger the signal.
- 3. Click the button to adjust the sensitivity, the more blue lights, the higher the sensitivity, which can expand the search range.
- 4. Cyclic adjustment: Adjust the sensitivity button to reduce the number of blue liahts, reduce the sensitivity, reduce the detection range, and finally find the emission source.
- 5. You can also turn on the vibration mode, press the power button to switch, and vibrate once.
- **B:** Detect hidden cameras (recommended to turn off the room lights)
- 1. Short press the mode button ** , the 3 infrared lights at the back will light up, short press the sensitivity adjustment button to control the flashing speed of the red light. Each time you press the LED sensitivity button,

the flashing frequency will be one step faster to control the flashing speed of the red light. The cycle adjustment can be adapted to the preferences of all kinds of people.

2. Move the instrument up, down, left and right to scan the surrounding environment with a laser, and observe through the special filter of the accessories of the machine. If there is a camera lens in front of you, you will find a very strong bright spot flashing.

C: GPS magnetic field detection

Press the * mode switch green light, bring the magnetic field sensing probe close to the magnetic field source, the blue light of the host will light up, and the buzzer alarm will also work, indicating that there is a magnetic field or suspicious items with strong magnetism near the magnetic probe. You can also turn on the vibration mode, press the power button to switch, and Product schematics vibrate 1 times.

D: Anti theft alarm

Short press the *\times mode button, and the sixth blue indicator light will light up to enter the anti-theft alarm mode. The anti-theft alarm will start 10 seconds later. When someone or an object triggers the machine, the machine will emit a beep alarm sound. The beep alarm sound will stop after 10 seconds, and so on. You can also turn on the vibration mode, press the power button to switch, and vibrate once

Common problem

1. Why is the silent sleep tracker not detected?

Answer: The commonly used sleep locator works once a day, and only works for 5-7 minutes at a time, so when the detector is detecting wireless signals, the locator may not send a signal.

2. Why is the position of the real-time locator not accur. ately detected?

Answer: The real-time locator generally sends a signal every 10 seconds. Please do not move back and forth during detection. It is best to fix it in one position for more than 5 minutes, and then change to another position to continue detection.

3. Why does the detector terminal beep "Di Di"

Answer: Please clear the surrounding environment, because the surrounding interference sianal is too strong. Lower one notch.

4. Why do the detectors near the windows of the house make such a loud noise?

Answer: The window is made of aluminum alloy, which forms a loop antenna, and the signal reception is particularly good.

5. Why is the camera not detected?

Answer: It is possible that the camera is not working, it is possible that the camera is a wired camera, and the infrared light detection is used instead.

Basic parameters

Volume	9.4×2.4×1 .5cm
Weight	28q
Charging interface	Type-C
Working hours	Continuous 25 hours
Antenna qrain	-56db
Charging power supply	DC5V 1A
Battery	3.7v/400mA polymer lithium battery
Sensitivity	Level 5 adjustable
Receiving frequency range	1 MHz – -6.5GHz
signal detection range	5cm-8m
Optical lenses	Special dedicated filters
Laser detection distance	10cm-6m
material quality	PC

Applicable people (scope)

- 1. People who frequently use bank cards
- 2. A group of business travelers who make hotels their homes
- 3. People who frequently consume in public entertainment venues
- 4. People who often go to various shopping malls to try on clothes
- 5. Individuals who respect their own personal stability and others' stability
- 6. Individuals who come into contact with and safeguard trade secrets
- 7. Security personnel in commercial and technical confidential premises
- 8. Is the drone camera quietly staring at your window
- 9. Mortgage car, used car, guarantee company, information finance company

Scope of application

- Detect if your car or office is equipped with wireless cameras or trackers.
- Detect if the phone is transmitting signals to the outside without any reason when in standby mode.
- Detect if your car is equipped with a GPS tracking device.
- Detect whether your working environment and residential buildings have roof base station radiation.
- Detect mobile phone SMS sending and receiving signals mobile Internet access signals, mobile phone switches and call signals.
- Detect wireless network signal, mobile phone base station signal, wireless monitoring system.
- Detect whether household appliances such as micro wave ovens leak electromagnetic radiation that is harmful to the human body.
- Detect whether there is strong radiation called "mobile phone killer" in the environment.
- Detect suspicious radio signals in the environment.
- Detect more concealed 5.8GHZ wireless camera, wireless eavesdropper, wireless monitoring signal.

- Check wireless pinhole cameras in hotels, restrooms guesthouses, entertainment venues, locker rooms.
- Business negotiation, school invigilation sites, factories, military facilities or government agencies to prevent candid photography and eavesdropping.
- Prevent wireless candid photography at AM machine withdrawals, movie theaters, concerts, art galleries or museums. etc.
- When purchasing a building, first detect whether there is electromagnetic radiation that is harmful to human health.

Documents / Resources



Generic T15 Wireless Detector [pdf] Instructions
T15 Wireless Detector, T15, Wireless Detector, Detector

References

- 9 ??????
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.