

Genius LuxeMate Q8000 Stylish Wireless Keyboard and **Mouse Combo User Guide**

Home » GENIUS » Genius LuxeMate Q8000 Stylish Wireless Keyboard and Mouse Combo User Guide 🖺



Contents

- 1 Genius LuxeMate Q8000 Stylish Wireless Keyboard and Mouse Combo User Guide
 - 1.1 Figure
 - 1.2 Replace Batteries
 - 1.3 Notes on Battery Usage
 - 1.4 Keyboard Function key Definition
- 2 Documents / Resources
 - 2.1 References
- **3 Related Posts**

Genius LuxeMate Q8000 Stylish Wireless Keyboard and Mouse Combo User Guide







Genius web: www.geniusnet.com OEM/ODM: www.kyecom.com

KYE Systems Corp.

#492, Sec. 5, Chongxin Rd., Sanchong Dist.,

New Taipei City 24160, Taiwan

Tel: 886-2-2995-6645 Fax: 886-2-2995-6649

Email: sim@geniusnet.com.tw
Email: csd@geniusnet.com.tw


(Tech. Support) http://www.geniusnet.com




12030088400-A

Figure


1. Remove the battery cover from the mouse. Install one AA battery into the mouse.



2. Remove the battery cover from the keyboard. Install one AAA battery into the keyboard.




3. Plug the receiver into your computer





Connect both devices, wait 5-10 seconds and you are ready to begin



Mouse Button Assignments:



- 1. Left Button: Provides traditional mouse functions like click, double click and drag.
- 2. Magic-Roller: Scroll the button to surf the Internet and Windows documents.
- 3. Right Button: Provides traditional mouse right click function
- 4. DPI: 800 / 1200 / 1600.

Replace Batteries

If the mouse or keyboard does not work properly, then the batteries have lost their charge, so you need to replace them.

Warning: do not mix or use different types of batteries at the same time.

Notes on Battery Usage

When you use the battery, carefully read and strictly observe the Safety Instructions and the notes described below :


- Different battery types and surrounding temperatures may affect the battery performance.
- Avoid using batteries in extremely cold environments as low temperatures can shorten the battery life and reduce wireless device performance.

- If you are using a new rechargeable battery or rechargeable battery that has not been used for an extended period of time (batteries that pass the expiry date are exceptions) it might affect the period of time according to local regulations, you can use this device. Therefore, to maximize their performance and lifetime, we recommend that you fully charge the batteries and discharge them for at least one complete cycle before use.
- The battery or wireless device may feel warm when using for an extended period of time. This is normal and not a malfunction.
- If you will not be using the batteries for an extended period of time, remove them from the wireless device to prevent leakage or corrosion.
- Always keep the terminals in a clean state.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to local regulations.

Keyboard Function key Definition

,,	Fn+F1	Media Player
◄ -	Fn+F2	Volume —
4 +	Fn+F3	Volume+
®	Fn+F4	Mute
 44	Fn+F5	Previous
▶ ▶I	Fn+F6	Track
▶/II	Fn + F7	Play / Pause
	Fn+F8	Stop Playing
凸	Fn+F9	Web / Homepage
\bowtie	Fn+F10	Email
모	Fn+F11	My computer
*	Fn + F12	My favorite

Symbol for Separate Collection in European Countries





The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

Federal Communication Commission interference statement:

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installations. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient / Relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio / TV technician for help.

FCC CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

RF exposure warning: The equipment complies with RF exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Disclaimer

The following does not apply to any country where such provisions are inconsistent with local law: KYE Systems Corp. makes no warranties with respect to this documentation, whether expressed or implied. All material is provided "as is". This includes, but is not limited to, any implied warranties of merchantability and fitness is for a particular purpose. The information covered in this document is subject to change without notice.

KYE Systems Corp. assumes no responsibility for any errors that may appear in this document. All brand names mentioned in this manual are trademarks or registered trademarks of their respective companies.

KYE Systems Corp. All rights reserved.

KYE SYSTEMS CORP.

#492, Sec. 5, Chongxin Rd., Sanchong Dist., New Taipei City 24160, Taiwan



Ricky Chen QADV Department KYE SYSTEMS CORP.



M/N: GK-210013/R FCC ID: FSUGMZM4 Rating: DC 5V 50mA(Max)

www.geniusnet.com KYE Systems Corp.

MADE IN CHINA



The frequency band of product is 2400 MHz – 2483.5 MHz and the radio-frequency transmitted maximum power (equivalent isotropic radiated power, EIRP) less than 10 mW. Operating temperature: 0-40°C Product storage conditions: Temperature: -20°C~ 50°C/ Humidity: 5%~ 85%

Documents / Resources



Genius LuxeMate Q8000 Stylish Wireless Keyboard and Mouse Combo [pdf] User Guide LuxeMate Q8000, Stylish Wireless Keyboard and Mouse Combo, LuxeMate Q8000 Stylish Wireless Keyboard and Mouse Combo



Genius LuxeMate Q8000 Stylish Wireless Keyboard and Mouse Combo [pdf] User Guide LuxeMate Q8000 Stylish Wireless Keyboard and Mouse Combo, LuxeMate Q8000, LuxeMate, Q8000, Q8000 Wireless Keyboard, Q8000 Wireless Mouse, Stylish Wireless Keyboard and Mouse Combo, Stylish Wireless Keyboard, Wireless Keyboard, Stylish Wireless Mouse Combo, Wireless Mouse Combo, Wireless Mouse

References

- Genius US Website Genius designs personal peripheral devices with a target to provide a better experience in everyone's lives. Visit Genius to find your devices with high quality, easy usage and effective cost.
- The domain name kyecom.com is for sale